



Service Manual

GREE ELECTRIC APPLIANCES, INC. OF ZHUHAI



Table of Contents

| | |
|--|-----------|
| Part I : Technical Information | 1 |
| 1. Summary | 1 |
| 2. Specifications | 5 |
| 2.1 Specification Sheet..... | 5 |
| 2.2 Capacity Variation Ratio According to Temperature | 31 |
| 2.3 Cooling and Heating Data Sheet in Rated Frequency..... | 33 |
| 3. Outline Dimension Diagram | 34 |
| 3.1 Indoor Unit..... | 34 |
| 3.2 Outdoor Unit..... | 35 |
| 4. Refrigerant System Diagram | 37 |
| 5. Electrical Part | 38 |
| 5.1 Wiring Diagram | 38 |
| 5.2 PCB Printed Diagram | 42 |
| 6. Function and Control | 48 |
| 6.1 Remote Controller Introduction for YAA1FB18(WiFi)..... | 48 |
| 6.2 Remote Controller Introduction for YBE1F/YBE1F1/YBE1FB2..... | 53 |
| 6.3 GREE+ App Operation Manual | 58 |
| 6.4 Ewpe Smart App Operation Manual..... | 59 |
| 6.5 Brief Description of Models and Functions..... | 60 |
| Part II : Installation and Maintenance | 62 |
| 7. Notes for Installation and Maintenance | 62 |
| 8. Installation | 68 |
| 8.1 Installation Dimension Diagram..... | 68 |
| 8.2 Installation Parts-checking | 70 |
| 8.3 Selection of Installation Location..... | 70 |

| | |
|--|------------|
| 8.4 Electric Connection Requirement | 70 |
| 8.5 Installation of Indoor Unit..... | 71 |
| 8.6 Installation of Outdoor Unit..... | 73 |
| 8.7 Vacuum Pumping and Leak Detection..... | 74 |
| 8.8 Check after Installation and Test Operation | 75 |
| 9. Maintenance | 76 |
| 9.1 Error Code List..... | 76 |
| 9.2 Procedure of Troubleshooting | 81 |
| 9.3 Troubleshooting for Normal Malfunction | 93 |
| 10. Exploded View and Parts List..... | 95 |
| 10.1 Indoor Unit..... | 95 |
| 10.2 Outdoor Unit | 99 |
| 11. Removal Procedure | 104 |
| 11.1 Removal Procedure of Indoor Unit | 104 |
| 11.2 Removal Procedure of Outdoor Unit..... | 114 |
| Appendix | 139 |
| Appendix 1: Reference Sheet of Celsius and Fahrenheit..... | 139 |
| Appendix 2: Configuration of Connection Pipe | 139 |
| Appendix 3: Pipe Expanding Method..... | 140 |
| Appendix 4: List of Resistance for Temperature Sensor..... | 141 |

1. Summary

Indoor Unit:

A1 panel(Blue)



A1 panel(White)




A1 panel(Silver)



A1 panel(Champagne)



A1 panel(Black)



A2 panel(White)



A2 panel(Black)




A2 panel(Silver)




Outdoor Unit:


GWH09AUCXB-K6DNA1A/O
GWH12AUCXB-K6DNA1A/O




GWH18AUDXD-K6DNA1A/O




GWH12AUCXD-K6DNA1C/O



GWH18AUDXE-K6DNA1A/O
GWH18AUDXE-K6DNA1B/O




GWH24AUDXF-K6DNA1A/O



Remote Controller:



YAA1FB18(WiFi)



YBE1F/YBE1F1/YBE1FB2

Model list:

| No. | Model | Product code | Indoor model | Indoor product code | Outdoor model | Outdoor product code | Remote Controller | |
|-----|--------------------|--------------|----------------------|---------------------|----------------------|----------------------|-------------------|-------------|
| 1 | GWH09AUCXB-K6DNA2A | CB597000400 | GWH09AUCXB-K6DNA2A/I | CB597N00400 | GWH09AUCXB-K6DNA1A/O | CB575W00300 | YBE1F | |
| 2 | | CB597000403 | | CB597N00402 | | | YBE1FB2 | |
| 3 | | CB597000404 | | CB597N00404 | | | YBE1F | |
| 4 | GWH09AUCXB-K6DNA1A | CB575000300 | GWH09AUCXB-K6DNA1A/I | CB575N00300 | GWH09AUCXB-K6DNA1A/O | | CB575W00300 | YBE1F1 |
| 5 | | CB575000302 | | CB575N00302 | | | | YBE1F |
| 6 | | CB575000303 | | CB575N00303 | | | | YBE1F |
| 7 | | CB575000304 | | CB575N00304 | | | | YBE1F |
| 8 | | CB575000307 | | CB575N00306 | | | | YBE1FB2 |
| 9 | | CB575000311 | | CB575N00311 | | | | YBE1F1 |
| 10 | | CB575000301 | | CB575N00300 | | CB575W00301 | | YBE1F1 |
| 11 | | CB575000305 | | CB575N00302 | | | | YBE1F |
| 12 | | CB575000306 | | CB575N00306 | | | | YBE1FB2 |
| 13 | CB575000308 | CB575N00308 | YAA1FB18 (WiFi) | | | | | |
| 14 | CB575000309 | CB575N00309 | YBE1F | | | | | |
| 15 | CB575000310 | CB575N00310 | YBE1F1 | | | | | |
| 16 | CB575000312 | CB575N00311 | YBE1F1 | | | | | |
| 17 | GWH09AUCXB-K6DNA2A | CB597000401 | GWH09AUCXB-K6DNA2A/I | CB597N00400 | GWH09AUCXB-K6DNA1A/O | CB575W00301 | YBE1F | |
| 18 | | CB597000402 | | CB597N00402 | | | YBE1FB2 | |
| 19 | GWH12AUCXB-K6DNA2A | CB597000100 | GWH12AUCXB-K6DNA2A/I | CB597N00100 | GWH12AUCXB-K6DNA1A/O | CB575W00200 | YBE1F | |
| 20 | | CB597000102 | | CB597N00102 | | | YBE1F | |
| 21 | | CB597000103 | | CB597N00103 | | | YBE1FB2 | |
| 22 | GWH12AUCXB-K6DNA1A | CB575000200 | GWH12AUCXB-K6DNA1A/I | CB575N00200 | GWH12AUCXB-K6DNA1A/O | | CB575W00200 | YBE1F1 |
| 23 | | CB575000202 | | CB575N00202 | | | | YBE1F |
| 24 | | CB575000203 | | CB575N00203 | | | | YBE1F |
| 25 | | CB575000204 | | CB575N00204 | | | | YBE1F |
| 26 | | CB575000207 | | CB575N00206 | | | | YBE1FB2 |
| 27 | | CB575000201 | | CB575N00200 | | | | CB575W00201 |
| 28 | | CB575000205 | | CB575N00202 | | YBE1F | | |
| 29 | | CB575000206 | | CB575N00206 | | YBE1FB2 | | |
| 30 | | CB575000208 | | CB575N00203 | | YBE1F | | |
| 31 | CB575000209 | CB575N00204 | YBE1F | | | | | |
| 32 | CB575000210 | CB575N00210 | YAA1FB18 (WiFi) | | | | | |
| 33 | GWH12AUCXB-K6DNA2A | CB597000101 | GWH12AUCXB-K6DNA2A/I | CB597N00100 | GWH12AUCXB-K6DNA1A/O | CB575W00201 | YBE1F | |
| 34 | GWH12AUCXD-K6DNA2C | CB597000602 | GWH12AUCXD-K6DNA2C/I | CB597N00602 | GWH12AUCXD-K6DNA1C/O | CB575W00700 | YBE1F | |
| 35 | GWH12AUCXD-K6DNA1C | CB575000700 | GWH12AUCXD-K6DNA1C/I | CB575N00700 | GWH12AUCXD-K6DNA1C/O | CB575W00700 | YBE1F1 | |
| 36 | | CB575000705 | | CB575N00705 | | | YBE1F | |
| 37 | | CB575000704 | | CB575N00704 | | | YBE1FB2 | |
| 38 | | CB575000701 | | CB575N00700 | | CB575W00701 | YBE1F1 | |
| 39 | | CB575000702 | | CB575N00702 | | | YBE1F | |
| 40 | | CB575000703 | | CB575N00703 | | | YBE1F1 | |
| 41 | GWH12AUCXD-K6DNA2C | CB597000601 | GWH12AUCXD-K6DNA2C/I | CB597N00600 | GWH12AUCXD-K6DNA1C/O | CB575W00701 | YBE1F | |

Model list:

| No. | Model | Product code | Indoor model | Indoor product code | Outdoor model | Outdoor product code | Remote Controller |
|-----|--------------------|--------------|----------------------|---------------------|----------------------|----------------------|-------------------|
| 42 | GWH18AUDXD-K6DNA2A | CB597000200 | GWH18AUDXD-K6DNA2A/I | CB597N00200 | GWH18AUDXD-K6DNA1A/O | CB575W00100 | YBE1F |
| 43 | | CB597000204 | | CB597N00204 | | | YBE1FB2 |
| 44 | | CB597000203 | | CB597N00203 | | | YBE1F |
| 45 | GWH18AUDXD-K6DNA1A | CB575000100 | GWH18AUDXD-K6DNA1A/I | CB575N00100 | GWH18AUDXD-K6DNA1A/O | CB575W00100 | YBE1F1 |
| 46 | | CB575000102 | | CB575N00102 | | | YBE1F |
| 47 | | CB575000103 | | CB575N00103 | | | YBE1F |
| 48 | | CB575000104 | | CB575N00104 | | | YBE1F |
| 49 | | CB575000107 | | CB575N00105 | | | YBE1FB2 |
| 50 | | CB575000101 | | CB575N00100 | | | YBE1F1 |
| 51 | | CB575000105 | | CB575N00102 | | | YBE1F |
| 52 | CB575000106 | CB575N00105 | YBE1FB2 | | | | |
| 53 | CB575000108 | CB575N00104 | YBE1F | | | | |
| 54 | CB575000109 | CB575N00103 | YBE1F | | | | |
| 55 | CB575000110 | CB575N00110 | YAA1FB18 (WiFi) | | | | |
| 56 | GWH18AUDXD-K6DNA2A | CB597000202 | GWH18AUDXD-K6DNA2A/I | CB597N00200 | | | YBE1F |
| 57 | GWH18AUDXE-K6DNA1A | CB575000900 | GWH18AUDXE-K6DNA1A/I | CB575N00900 | GWH18AUDXE-K6DNA1A/O | CB575W00900 | YBE1F1 |
| 58 | | CB575000905 | | CB575N00905 | | | YBE1FB2 |
| 59 | | CB575000906 | | CB575N00906 | | | YBE1F |
| 60 | GWH18AUDXE-K6DNA2A | CB597000702 | GWH18AUDXE-K6DNA2A/I | CB597N00702 | | | YBE1F |
| 61 | GWH18AUDXE-K6DNA1A | CB575000901 | GWH18AUDXE-K6DNA1A/I | CB575N00900 | GWH18AUDXE-K6DNA1A/O | CB575W00901 | YBE1F1 |
| 62 | | CB575000902 | | CB575N00902 | | | YBE1F |
| 63 | | CB575000903 | | CB575N00903 | | | YBE1F1 |
| 64 | GWH18AUDXE-K6DNA2A | CB597000701 | GWH18AUDXE-K6DNA2A/I | CB597N00700 | | | YBE1F |
| 65 | GWH18AUDXE-K6DNA1B | CB575001100 | GWH18AUDXE-K6DNA1B/I | CB575N01100 | GWH18AUDXE-K6DNA1B/O | CB575W01100 | YBE1F |
| 66 | | CB575001101 | | CB575N01101 | | | YBE1F1 |
| 67 | | CB575001102 | | CB575N01102 | | | YBE1FB2 |
| 68 | GWH24AUDXF-K6DNA2A | CB597000300 | GWH24AUDXF-K6DNA2A/I | CB597N00300 | GWH24AUDXF-K6DNA1A/O | CB437W04700 | YBE1F |
| 69 | | CB597000303 | | CB597N00302 | | | YBE1FB2 |
| 70 | | CB597000304 | | CB597N00304 | | | YBE1F |
| 71 | GWH24AUDXF-K6DNA1A | CB437004700 | GWH24AUDXF-K6DNA1A/I | CB437N04700 | GWH24AUDXF-K6DNA1A/O | CB437W04700 | YBE1F1 |
| 72 | | CB437004702 | | CB437N04702 | | | YBE1F |
| 73 | | CB437004703 | | CB437N04703 | | | YBE1F |
| 74 | | CB437004704 | | CB437N04704 | | | YBE1F |
| 75 | | CB437004707 | | CB437N04706 | | | YBE1FB2 |
| 76 | | CB437004712 | | CB437N04711 | | | YBE1F1 |
| 77 | | CB437004701 | | CB437N04700 | | | YBE1F1 |
| 78 | | CB437004705 | | CB437N04702 | | | YBE1F |
| 79 | | CB437004706 | | CB437N04706 | | | YBE1FB2 |
| 80 | | CB437004708 | | CB437N04704 | | | YBE1F |
| 81 | | CB437004709 | | CB437N04703 | | | YBE1F |
| 82 | CB437004710 | CB437N04710 | YAA1FB18 (WiFi) | | | | |
| 83 | CB437004711 | CB437N04711 | YBE1F1 | | | | |
| 84 | GWH24AUDXF-K6DNA2A | CB597000301 | GWH24AUDXF-K6DNA2A/I | CB597N00300 | | | YBE1F |
| 85 | | CB597000302 | | CB597N00302 | YBE1FB2 | | |

2. Specifications

2.1 Specification Sheet

| | | | |
|---------------------------------|---|-------------------|--|
| Model | | | 1.GWH09AUCXB-K6DNA1A 2.GWH09AUCXB-K6DNA2A |
| Product Code | | | 1.CB575000300/CB575000302/CB575000303/CB575000304/CB575000307/ CB575000311 2.CB597000400/CB597000403/CB597000404 |
| Power Supply | Rated Voltage | V~ | 220-240 |
| | Rated Frequency | Hz | 50 |
| | Phases | | 1 |
| Power Supply Mode | | | Outdoor |
| Cooling Capacity | | W | 2700 |
| Heating Capacity | | W | 3000 |
| Cooling Power Input | | W | 670 |
| Heating Power Input | | W | 680 |
| Cooling Current Input | | A | 3.1 |
| Heating Current Input | | A | 3.2 |
| Rated Input | | W | 1400 |
| Rated Cooling Current | | A | 6.0 |
| Rated Heating Current | | A | 6.2 |
| Air Flow Volume | | m ³ /h | 610/570/540/470/440/420/390/180 |
| Dehumidifying Volume | | L/h | 0.80 |
| EER | | W/W | 4.03 |
| COP | | W/W | 4.41 |
| SEER | | | 8.5 |
| SCOP(Average/WarmerColder) | | | 4.6/5.7/3.5 |
| Application Area | | m ² | 12-18 |
| Indoor Unit | Model | | 1.GWH09AUCXB-K6DNA1A/I 2.GWH09AUCXB-K6DNA2A/I |
| | Product Code | | 1.CB575N00300/CB575N00302/CB575N00303/CB575N00304/ CB575N00306/CB575N00311 2.CB597N00400/CB597N00402/CB597N00404 |
| | Fan Type | | Cross-flow |
| | Fan Diameter Length(DXL) | mm | Φ98×633.5 |
| | Cooling Speed | r/min | 1200/1100 /1050/950/800/700/650/500 |
| | Heating Speed | r/min | 1200/1100 /1040/950/900/880/850 |
| | Fan Motor Power Output | W | 15 |
| | Fan Motor RLA | A | 0.22 |
| | Fan Motor Capacitor | μF | / |
| | Heater Power Input | W | 25 |
| | Evaporator Form | | Aluminum Fin-copper Tube |
| | Evaporator Pipe Diameter | mm | Φ5 |
| | Evaporator Row-fin Gap | mm | 2-1.4 |
| | Evaporator Coil Length (LXD _X W) | mm | 635×22.8×306.3 |
| | Swing Motor Model | | MP24HF/MP24AK/MP24BA |
| | Swing Motor Power Output | W | 1.5/1.5/1.5 |
| | Fuse Current | A | 3.15 |
| | Sound Pressure Level | dB (A) | Cooling:38/37/34/31/26/23/22/19 Heating:39/37/34/31/30/29/28 |
| | Sound Power Level | dB (A) | Cooling:58/51/48/45/40/37/36/33 Heating:58/51/48/45/44/43/42 |
| | Dimension (WXH _X D) | mm | 837×293×200 |
| Dimension of Carton Box (LXWXH) | mm | 891×357×261 | |
| Dimension of Package (LXWXH) | mm | 896×373×272 | |
| Net Weight | kg | 9.5 | |
| Gross Weight | kg | 11.5 | |

| | | | | |
|--|---|-------------------|---------------------------------|--------------------------|
| Outdoor Unit | Outdoor Unit Model | | GWH09AUCXB-K6DNA1A/O(LCLH) | |
| | Outdoor Unit Product Code | | CB575W00300 | |
| | Compressor Manufacturer | | ZHUHAI LANDA COMPRESSOR CO.,LTD | |
| | Compressor Model | | QXF-A082zC170 | |
| | Compressor Oil | | ZE-G;ES RB68GX or equivalent | |
| | Compressor Type | | Rotary | |
| | Compressor LRA. | A | | 15.00 |
| | Compressor RLA | A | | 2.56 |
| | Compressor Power Input | W | | 756.6 |
| | Compressor Overload Protector | | | / |
| | Throttling Method | | | Capillary |
| | Set Temperature Range | °C | | 16~30 |
| | Cooling Operation Ambient Temperature Range | °C | | -15~50 |
| | Heating Operation Ambient Temperature Range | °C | | -25~30 |
| | Condenser Form | | | Aluminum Fin-copper Tube |
| | Condenser Pipe Diameter | mm | | Φ7 |
| | Condenser Rows-fin Gap | mm | | 1-1.2 |
| | Condenser Coil Length (LXDXW) | mm | | 666×19.05×527 |
| | Fan Motor Speed | rpm | | 850 |
| | Fan Motor Power Output | W | | 30 |
| | Fan Motor RLA | A | | 0.40 |
| | Fan Motor Capacitor | μF | | / |
| | Outdoor Unit Air Flow Volume | m ³ /h | | 1950 |
| | Fan Type | | | Axial-flow |
| | Fan Diameter | mm | | Φ400 |
| | Defrosting Method | | | Automatic Defrosting |
| | Climate Type | | | T1 |
| | Isolation | | | I |
| | Moisture Protection | | | IPX4 |
| | Permissible Excessive Operating Pressure for the Discharge Side | MPa | | 4.3 |
| | Permissible Excessive Operating Pressure for the Suction Side | MPa | | 2.5 |
| | Sound Pressure Level | dB (A) | | 50 |
| | Sound Power Level | dB (A) | | 61 |
| Dimension(WXHxD) | mm | | 732×555×330 | |
| Dimension of Carton Box (LXWXH) | mm | | 791×373×590 | |
| Dimension of Package(LXWXH) | mm | | 794×376×615 | |
| Net Weight | kg | | 25 | |
| Gross Weight | kg | | 27.5 | |
| Refrigerant | | | R32 | |
| Refrigerant Charge | kg | | 0.53 | |
| Connection Pipe | Connection Pipe Length | m | 5 | |
| | Connection Pipe Gas Additional Charge | g/m | 16 | |
| | Outer Diameter Liquid Pipe | | 1/4" | |
| | Outer Diameter Gas Pipe | | 3/8" | |
| | Max Distance Height | m | 10 | |
| | Max Distance Length | m | 15 | |
| Note: The connection pipe applies metric diameter. | | | | |

The above data is subject to change without notice. Please refer to the nameplate of the unit.

| | | | |
|------------------------------|---------------------------------|-------------------|--|
| Model | | | 1.GWH09AUCXB-K6DNA1A 2.GWH09AUCXB-K6DNA2A |
| Product Code | | | 1.CB575000301/CB575000305/CB575000306/CB575000308/CB575000309/ CB575000310/CB575000312 2.CB597000401/CB597000402 |
| Power Supply | Rated Voltage | V~ | 220-240 |
| | Rated Frequency | Hz | 50 |
| | Phases | | 1 |
| Power Supply Mode | | | Outdoor |
| Cooling Capacity | | W | 2700 |
| Heating Capacity | | W | 3000 |
| Cooling Power Input | | W | 670 |
| Heating Power Input | | W | 680 |
| Cooling Current Input | | A | 3.1 |
| Heating Current Input | | A | 3.2 |
| Rated Input | | W | 1400 |
| Rated Cooling Current | | A | 6.0 |
| Rated Heating Current | | A | 6.2 |
| Air Flow Volume | | m ³ /h | 610/570/540/470/440/420/390/180 |
| Dehumidifying Volume | | L/h | 0.80 |
| EER | | W/W | 4.03 |
| COP | | W/W | 4.41 |
| SEER | | | 8.5 |
| SCOP(Average/WarmerColder) | | | 4.6/5.7/3.5 |
| Application Area | | m ² | 12-18 |
| Indoor Unit | Model | | 1.GWH09AUCXB-K6DNA1A/I 2.GWH09AUCXB-K6DNA2A/I |
| | Product Code | | 1.CB575N00300/CB575N00302/CB575N00306/CB575N00308/ CB575N00309/CB575N00310/CB575N00311 2.CB597N00400/CB597N00402 |
| | Fan Type | | Cross-flow |
| | Fan Diameter Length(DXL) | mm | Φ98×633.5 |
| | Cooling Speed | r/min | 1200/1100 /1050/950/800/700/650/500 |
| | Heating Speed | r/min | 1200/1100 /1040/950/900/880/850 |
| | Fan Motor Power Output | W | 15 |
| | Fan Motor RLA | A | 0.22 |
| | Fan Motor Capacitor | μF | / |
| | Heater Power Input | W | 25 |
| | Evaporator Form | | Aluminum Fin-copper Tube |
| | Evaporator Pipe Diameter | mm | Φ5 |
| | Evaporator Row-fin Gap | mm | 2-1.4 |
| | Evaporator Coil Length (LXDXW) | mm | 635×22.8×306.3 |
| | Swing Motor Model | | MP24HF/MP24AK/MP24BA |
| | Swing Motor Power Output | W | 1.5/1.5/1.5 |
| | Fuse Current | A | 3.15 |
| | Sound Pressure Level | dB (A) | Cooling:38/37/34/31/26/23/22/19 Heating:39/37/34/31/30/29/28 |
| | Sound Power Level | dB (A) | Cooling:58/51/48/45/40/37/36/33 Heating:58/51/48/45/44/43/42 |
| | Dimension (WXHXD) | mm | 837×293×200 |
| | Dimension of Carton Box (LXWXH) | mm | 891×357×261 |
| Dimension of Package (LXWXH) | mm | 896×373×272 | |
| Net Weight | kg | 9.5 | |
| Gross Weight | kg | 11.5 | |

| | | | | |
|---------------------------------|---|-------------------|---------------------------------|--------------------------|
| Outdoor Unit | Outdoor Unit Model | | GWH09AUCXB-K6DNA1A/O(LC) | |
| | Outdoor Unit Product Code | | CB575W00301 | |
| | Compressor Manufacturer | | ZHUHAI LANDA COMPRESSOR CO.,LTD | |
| | Compressor Model | | QXF-A082zC170 | |
| | Compressor Oil | | ZE-G;ES RB68GX or equivalent | |
| | Compressor Type | | Rotary | |
| | Compressor LRA. | A | | 15.00 |
| | Compressor RLA | A | | 2.56 |
| | Compressor Power Input | W | | 756.6 |
| | Compressor Overload Protector | | | / |
| | Throttling Method | | | Capillary |
| | Set Temperature Range | °C | | 16~30 |
| | Cooling Operation Ambient Temperature Range | °C | | -15~50 |
| | Heating Operation Ambient Temperature Range | °C | | -15~30 |
| | Condenser Form | | | Aluminum Fin-copper Tube |
| | Condenser Pipe Diameter | mm | | Φ7 |
| | Condenser Rows-fin Gap | mm | | 1-1.2 |
| | Condenser Coil Length (LXDXW) | mm | | 666×19.05×527 |
| | Fan Motor Speed | rpm | | 850 |
| | Fan Motor Power Output | W | | 30 |
| | Fan Motor RLA | A | | 0.40 |
| | Fan Motor Capacitor | μF | | / |
| | Outdoor Unit Air Flow Volume | m ³ /h | | 1950 |
| | Fan Type | | | Axial-flow |
| | Fan Diameter | mm | | Φ400 |
| | Defrosting Method | | | Automatic Defrosting |
| | Climate Type | | | T1 |
| | Isolation | | | I |
| | Moisture Protection | | | IPX4 |
| | Permissible Excessive Operating Pressure for the Discharge Side | MPa | | 4.3 |
| | Permissible Excessive Operating Pressure for the Suction Side | MPa | | 2.5 |
| | Sound Pressure Level | dB (A) | | 50 |
| | Sound Power Level | dB (A) | | 61 |
| Dimension(WXHxD) | mm | | 732×555×330 | |
| Dimension of Carton Box (LXWXH) | mm | | 791×373×590 | |
| Dimension of Package(LXWXH) | mm | | 794×376×615 | |
| Net Weight | kg | | 25 | |
| Gross Weight | kg | | 27.5 | |
| Refrigerant | | | R32 | |
| Refrigerant Charge | kg | | 0.53 | |
| Connection Pipe | Connection Pipe Length | m | 5 | |
| | Connection Pipe Gas Additional Charge | g/m | 16 | |
| | Outer Diameter Liquid Pipe | | 1/4" | |
| | Outer Diameter Gas Pipe | | 3/8" | |
| | Max Distance Height | m | 10 | |
| | Max Distance Length | m | 15 | |
| | Note: The connection pipe applies metric diameter. | | | |

The above data is subject to change without notice. Please refer to the nameplate of the unit.

| | | | |
|----------------------------|---|-------------------|--|
| Model | | | 1.GWH12AUCXB-K6DNA1A 2.GWH12AUCXB-K6DNA2A |
| Product Code | | | 1.CB575000200/CB575000202/CB575000203/CB575000204/CB575000207 2.CB597000100/CB597000102/CB597000103 |
| Power Supply | Rated Voltage | V~ | 220-240 |
| | Rated Frequency | Hz | 50 |
| | Phases | | 1 |
| Power Supply Mode | | | Outdoor |
| Cooling Capacity | | W | 3510 |
| Heating Capacity | | W | 3810 |
| Cooling Power Input | | W | 989 |
| Heating Power Input | | W | 977 |
| Cooling Current Input | | A | 4.4 |
| Heating Current Input | | A | 4.4 |
| Rated Input | | W | 1650 |
| Rated Cooling Current | | A | 6.2 |
| Rated Heating Current | | A | 7.4 |
| Air Flow Volume | | m ³ /h | 680/620/560/490/450/420/390/220 |
| Dehumidifying Volume | | L/h | 1.40 |
| EER | | W/W | 3.55 |
| COP | | W/W | 3.90 |
| SEER | | | 7.2 |
| SCOP(Average/WarmerColder) | | | 4.1/5.2/3.1 |
| Application Area | | m ² | 16-24 |
| Indoor Unit | Model | | 1.GWH12AUCXB-K6DNA1A/I 2.GWH12AUCXB-K6DNA2A/I |
| | Product Code | | 1.CB575N00200/CB575N00202/CB575N00203/CB575N00204/CB575N00206 2.CB597N00100/CB597N00102/CB597N00103 |
| | Fan Type | | Cross-flow |
| | Fan Diameter Length(DXL) | mm | Φ98×630 |
| | Cooling Speed | r/min | 1300/1200/1100/1000/900/800/750/500 |
| | Heating Speed | r/min | 1300/1200/1100/1000/900/850/800 |
| | Fan Motor Power Output | W | 15 |
| | Fan Motor RLA | A | 0.20 |
| | Fan Motor Capacitor | μF | / |
| | Heater Power Input | W | 25 |
| | Evaporator Form | | Aluminum Fin-copper Tube |
| | Evaporator Pipe Diameter | mm | Φ5 |
| | Evaporator Row-fin Gap | mm | 2-1.4 |
| | Evaporator Coil Length (LXD _X W) | mm | 634×22.8×304.8 |
| | Swing Motor Model | | MP24BA/MP24AK/MP24HF |
| | Swing Motor Power Output | W | 1.5/1.5/1.5 |
| | Fuse Current | A | 3.15 |
| | Sound Pressure Level | dB (A) | Cooling:41/38/36/33/30/27/25/19 Heating:41/38/36/33/29/27/26 |
| | Sound Power Level | dB (A) | Cooling:60/52/50/47/44/41/39/33 Heating:55/52/50/47/43/41/40 |
| | Dimension (WXH _X D) | mm | 837×293×200 |
| | Dimension of Carton Box (LXWXH) | mm | 891×357×261 |
| | Dimension of Package (LXWXH) | mm | 896×373×272 |
| | Net Weight | kg | 9.5 |
| Gross Weight | kg | 11.5 | |

| | | | | |
|--|---|-------------------|----------------------------------|--------------------------|
| Outdoor Unit | Outdoor Unit Model | | GWH12AUCXB-K6DNA1A/O(LCLH) | |
| | Outdoor Unit Product Code | | CB575W00200 | |
| | Compressor Manufacturer | | ZHUHAI LANDA COMPRESSOR CO., LTD | |
| | Compressor Model | | FTz-AN108ACBD | |
| | Compressor Oil | | FW68DA or equivalent | |
| | Compressor Type | | Rotary | |
| | Compressor LRA. | A | | / |
| | Compressor RLA | A | | 4.40 |
| | Compressor Power Input | W | | / |
| | Compressor Overload Protector | | | / |
| | Throttling Method | | | Electron expansion valve |
| | Set Temperature Range | °C | | 16~30 |
| | Cooling Operation Ambient Temperature Range | °C | | -15~50 |
| | Heating Operation Ambient Temperature Range | °C | | -25~30 |
| | Condenser Form | | | Aluminum Fin-copper Tube |
| | Condenser Pipe Diameter | mm | | Φ7.94 |
| | Condenser Rows-fin Gap | mm | | 1-1.2 |
| | Condenser Coil Length (LXDXW) | mm | | 666×19.05×527 |
| | Fan Motor Speed | rpm | | 900 |
| | Fan Motor Power Output | W | | 30 |
| | Fan Motor RLA | A | | 0.40 |
| | Fan Motor Capacitor | μF | | / |
| | Outdoor Unit Air Flow Volume | m ³ /h | | 1950 |
| | Fan Type | | | Axial-flow |
| | Fan Diameter | mm | | Φ400 |
| | Defrosting Method | | | Automatic Defrosting |
| | Climate Type | | | T1 |
| | Isolation | | | I |
| | Moisture Protection | | | IPX4 |
| | Permissible Excessive Operating Pressure for the Discharge Side | MPa | | 4.3 |
| | Permissible Excessive Operating Pressure for the Suction Side | MPa | | 2.5 |
| | Sound Pressure Level | dB (A) | | 52 |
| | Sound Power Level | dB (A) | | 63 |
| Dimension(WXHxD) | mm | | 732×555×330 | |
| Dimension of Carton Box (LXWXH) | mm | | 791×373×590 | |
| Dimension of Package(LXWXH) | mm | | 794×376×615 | |
| Net Weight | kg | | 25.5 | |
| Gross Weight | kg | | 28 | |
| Refrigerant | | | R32 | |
| Refrigerant Charge | kg | | 0.57 | |
| Connection Pipe | Connection Pipe Length | m | 5 | |
| | Connection Pipe Gas Additional Charge | g/m | 16 | |
| | Outer Diameter Liquid Pipe | | 1/4" | |
| | Outer Diameter Gas Pipe | | 3/8" | |
| | Max Distance Height | m | 10 | |
| | Max Distance Length | m | 15 | |
| Note: The connection pipe applies metric diameter. | | | | |

The above data is subject to change without notice. Please refer to the nameplate of the unit.

| | | | | |
|----------------------------|---------------------------------|-------------------|--|---|
| Model | | | 1.GWH12AUCXB-K6DNA1A 2.GWH12AUCXB-K6DNA2A | |
| Product Code | | | 1.CB575000201/CB575000205/CB575000206/CB575000208/ CB575000209/CB575000210 2.CB597000101 | |
| Power Supply | Rated Voltage | V~ | 220-240 | |
| | Rated Frequency | Hz | 50 | |
| | Phases | | 1 | |
| Power Supply Mode | | | Outdoor | |
| Cooling Capacity | | W | 3510 | |
| Heating Capacity | | W | 3810 | |
| Cooling Power Input | | W | 989 | |
| Heating Power Input | | W | 977 | |
| Cooling Current Input | | A | 4.4 | |
| Heating Current Input | | A | 4.4 | |
| Rated Input | | W | 1650 | |
| Rated Cooling Current | | A | 6.2 | |
| Rated Heating Current | | A | 7.4 | |
| Air Flow Volume | | m ³ /h | 680/620/560/490/450/420/390/220 | |
| Dehumidifying Volume | | L/h | 1.40 | |
| EER | | W/W | 3.55 | |
| COP | | W/W | 3.90 | |
| SEER | | | 7.2 | |
| SCOP(Average/WarmerColder) | | | 4.1/5.2/3.1 | |
| Application Area | | m ² | 16-24 | |
| Indoor Unit | Model | | 1.GWH12AUCXB-K6DNA1A/I 2.GWH12AUCXB-K6DNA2A/I | |
| | Product Code | | 1.CB575N00200/CB575N00202/CB575N00206/CB575N00203/ CB575N00204/CB575N00210 2.CB597N00100 | |
| | Fan Type | | Cross-flow | |
| | Fan Diameter Length(DXL) | | mm | Φ98×630 |
| | Cooling Speed | | r/min | 1300/1200/1100/1000/900/800/750/500 |
| | Heating Speed | | r/min | 1300/1200/1100/1000/900/850/800 |
| | Fan Motor Power Output | | W | 15 |
| | Fan Motor RLA | | A | 0.20 |
| | Fan Motor Capacitor | | μF | / |
| | Heater Power Input | | W | 25 |
| | Evaporator Form | | | Aluminum Fin-copper Tube |
| | Evaporator Pipe Diameter | | mm | Φ5 |
| | Evaporator Row-fin Gap | | mm | 2-1.4 |
| | Evaporator Coil Length (LXDXW) | | mm | 634×22.8×304.8 |
| | Swing Motor Model | | | MP24BA/MP24AK/MP24HF |
| | Swing Motor Power Output | | W | 1.5/1.5/1.5 |
| | Fuse Current | | A | 3.15 |
| | Sound Pressure Level | | dB (A) | Cooling:41/38/36/33/30/27/25/19 Heating:41/38/36/33/29/27/26 |
| | Sound Power Level | | dB (A) | Cooling:60/52/50/47/44/41/39/33 Heating:55/52/50/47/43/41/40 |
| | Dimension (WXHxD) | | mm | 837×293×200 |
| | Dimension of Carton Box (LXWXH) | | mm | 891×357×261 |
| | Dimension of Package (LXWXH) | | mm | 896×373×272 |
| | Net Weight | | kg | 9.5 |
| Gross Weight | | kg | 11.5 | |

| | | | |
|--|---|-------------------|----------------------------------|
| Outdoor Unit | Outdoor Unit Model | | GWH12AUCXB-K6DNA1A/O(LC) |
| | Outdoor Unit Product Code | | CB575W00201 |
| | Compressor Manufacturer | | ZHUHAI LANDA COMPRESSOR CO., LTD |
| | Compressor Model | | FTz-AN108ACBD |
| | Compressor Oil | | FW68DA or equivalent |
| | Compressor Type | | Rotary |
| | Compressor LRA. | A | / |
| | Compressor RLA | A | 4.40 |
| | Compressor Power Input | W | / |
| | Compressor Overload Protector | | / |
| | Throttling Method | | Electron expansion valve |
| | Set Temperature Range | °C | 16~30 |
| | Cooling Operation Ambient Temperature Range | °C | -15~50 |
| | Heating Operation Ambient Temperature Range | °C | -15~30 |
| | Condenser Form | | Aluminum Fin-copper Tube |
| | Condenser Pipe Diameter | mm | Φ7.94 |
| | Condenser Rows-fin Gap | mm | 1-1.2 |
| | Condenser Coil Length (LXDXW) | mm | 666×19.05×527 |
| | Fan Motor Speed | rpm | 900 |
| | Fan Motor Power Output | W | 30 |
| | Fan Motor RLA | A | 0.40 |
| | Fan Motor Capacitor | μF | / |
| | Outdoor Unit Air Flow Volume | m ³ /h | 1950 |
| | Fan Type | | Axial-flow |
| | Fan Diameter | mm | Φ400 |
| | Defrosting Method | | Automatic Defrosting |
| | Climate Type | | T1 |
| | Isolation | | I |
| | Moisture Protection | | IPX4 |
| | Permissible Excessive Operating Pressure for the Discharge Side | MPa | 4.3 |
| | Permissible Excessive Operating Pressure for the Suction Side | MPa | 2.5 |
| | Sound Pressure Level | dB (A) | 52 |
| | Sound Power Level | dB (A) | 63 |
| Dimension(WXHxD) | mm | 732×555×330 | |
| Dimension of Carton Box (LXWXH) | mm | 791×373×590 | |
| Dimension of Package(LXWXH) | mm | 794×376×615 | |
| Net Weight | kg | 25.5 | |
| Gross Weight | kg | 28 | |
| Refrigerant | | R32 | |
| Refrigerant Charge | kg | 0.57 | |
| Connection Pipe | Connection Pipe Length | m | 5 |
| | Connection Pipe Gas Additional Charge | g/m | 16 |
| | Outer Diameter Liquid Pipe | | 1/4" |
| | Outer Diameter Gas Pipe | | 3/8" |
| | Max Distance Height | m | 10 |
| | Max Distance Length | m | 15 |
| Note: The connection pipe applies metric diameter. | | | |

The above data is subject to change without notice. Please refer to the nameplate of the unit.

| | | | |
|---------------------------------|---|-------------------|---|
| Model | | | 1.GWH12AUCXD-K6DNA1C 2.GWH12AUCXD-K6DNA2C |
| Product Code | | | 1.CB575000700/CB575000705/CB575000704 2.CB597000602 |
| Power Supply | Rated Voltage | V~ | 220-240 |
| | Rated Frequency | Hz | 50 |
| | Phases | | 1 |
| Power Supply Mode | | | Outdoor |
| Cooling Capacity | | W | 3510 |
| Heating Capacity | | W | 3810 |
| Cooling Power Input | | W | 877 |
| Heating Power Input | | W | 952 |
| Cooling Current Input | | A | 4.1 |
| Heating Current Input | | A | 4.5 |
| Rated Input | | W | 1800 |
| Rated Cooling Current | | A | 6.5 |
| Rated Heating Current | | A | 8.0 |
| Air Flow Volume | | m ³ /h | 720/600/570/530/500/460/430 |
| Dehumidifying Volume | | L/h | 1.40 |
| EER | | W/W | 4.00 |
| COP | | W/W | 4.00 |
| SEER | | | 8.5 |
| SCOP(Average/WarmerColder) | | | 4.6/5.6/3.6 |
| Application Area | | m ² | 16-24 |
| Indoor Unit | Model | | 1.GWH12AUCXD-K6DNA1C/I 2.GWH12AUCXD-K6DNA2C/I |
| | Product Code | | 1.CB575N00700/CB575N00705/CB575N00704 2.CB597N00602 |
| | Fan Type | | Cross-flow |
| | Fan Diameter Length(DXL) | | mm Φ98×630 |
| | Cooling Speed | | r/min 1400/1200/1120/1050/980/920/750/500 |
| | Heating Speed | | r/min 1400/1200/1140/1080/1020/960/900 |
| | Fan Motor Power Output | | W 15 |
| | Fan Motor RLA | | A 0.2 |
| | Fan Motor Capacitor | | μF / |
| | Heater Power Input | | W / |
| | Evaporator Form | | Aluminum Fin-copper Tube |
| | Evaporator Pipe Diameter | | mm Φ5 |
| | Evaporator Row-fin Gap | | mm 2-1.4 |
| | Evaporator Coil Length (LXD _X W) | | mm 634×22.8×304.8 |
| | Swing Motor Model | | MP24BA/MP24AK/MP24HF |
| | Swing Motor Power Output | | W 1.5/1.5/1.5 |
| | Fuse Current | | A 3.15 |
| | Sound Pressure Level | | dB (A) Cooling:43/39/37/35/32/30/24/19 Heating:44/39/37/35/33/31/29 |
| | Sound Power Level | | dB (A) Cooling:60/53/51/49/46/44/38/33 Heating:60/53/51/49/47/45/43 |
| | Dimension (WXHXD) | | mm 837×293×200 |
| Dimension of Carton Box (LXWXH) | | mm 891×357×261 | |
| Dimension of Package (LXWXH) | | mm 896×373×272 | |
| Net Weight | | kg 9.5 | |
| Gross Weight | | kg 11.5 | |

| | | | | |
|--|---|-------------------|----------------------------------|--------------------------|
| Outdoor Unit | Outdoor Unit Model | | GWH12AUCXD-K6DNA1C/O(LCLH) | |
| | Outdoor Unit Product Code | | CB575W00700 | |
| | Compressor Manufacturer | | ZHUHAI LANDA COMPRESSOR CO., LTD | |
| | Compressor Model | | QXF-A098zE170 | |
| | Compressor Oil | | ZE-GLES RB68GX or equivalent | |
| | Compressor Type | | Rotary | |
| | Compressor LRA. | A | | / |
| | Compressor RLA | A | | 3.9 |
| | Compressor Power Input | W | | / |
| | Compressor Overload Protector | | | / |
| | Throttling Method | | | Electron expansion valve |
| | Set Temperature Range | °C | | 16~30 |
| | Cooling Operation Ambient Temperature Range | °C | | -15~50 |
| | Heating Operation Ambient Temperature Range | °C | | -25~30 |
| | Condenser Form | | | Aluminum Fin-copper Tube |
| | Condenser Pipe Diameter | mm | | Φ7 |
| | Condenser Rows-fin Gap | mm | | 2-1.4 |
| | Condenser Coil Length (LXDXW) | mm | | 761.5×38.1×528 |
| | Fan Motor Speed | rpm | | 850 |
| | Fan Motor Power Output | W | | 30 |
| | Fan Motor RLA | A | | 0.4 |
| | Fan Motor Capacitor | μF | | / |
| | Outdoor Unit Air Flow Volume | m ³ /h | | 2200 |
| | Fan Type | | | Axial-flow |
| | Fan Diameter | mm | | Φ420 |
| | Defrosting Method | | | Automatic Defrosting |
| | Climate Type | | | T1 |
| | Isolation | | | I |
| | Moisture Protection | | | IPX4 |
| | Permissible Excessive Operating Pressure for the Discharge Side | MPa | | 4.3 |
| | Permissible Excessive Operating Pressure for the Suction Side | MPa | | 2.5 |
| | Sound Pressure Level | dB (A) | | 53 |
| | Sound Power Level | dB (A) | | 64 |
| Dimension(WXHxD) | mm | | 802×555×350 | |
| Dimension of Carton Box (LXWXH) | mm | | 869×395×594 | |
| Dimension of Package(LXWXH) | mm | | 872×398×620 | |
| Net Weight | kg | | 30 | |
| Gross Weight | kg | | 32.5 | |
| Refrigerant | | | R32 | |
| Refrigerant Charge | kg | | 0.8 | |
| Connection Pipe | Connection Pipe Length | m | 5 | |
| | Connection Pipe Gas Additional Charge | g/m | 16 | |
| | Outer Diameter Liquid Pipe | | 1/4" | |
| | Outer Diameter Gas Pipe | | 3/8" | |
| | Max Distance Height | m | 10 | |
| | Max Distance Length | m | 20 | |
| Note: The connection pipe applies metric diameter. | | | | |

The above data is subject to change without notice. Please refer to the nameplate of the unit.

| | | | |
|---------------------------------|---|-------------------|---|
| Model | | | 1.GWH12AUCXD-K6DNA1C 2.GWH12AUCXD-K6DNA2C |
| Product Code | | | 1.CB575000701/CB575000702/CB575000703 2.CB597000601 |
| Power Supply | Rated Voltage | V~ | 220-240 |
| | Rated Frequency | Hz | 50 |
| | Phases | | 1 |
| Power Supply Mode | | | Outdoor |
| Cooling Capacity | | W | 3510 |
| Heating Capacity | | W | 3810 |
| Cooling Power Input | | W | 877 |
| Heating Power Input | | W | 952 |
| Cooling Current Input | | A | 4.1 |
| Heating Current Input | | A | 4.5 |
| Rated Input | | W | 1800 |
| Rated Cooling Current | | A | 6.5 |
| Rated Heating Current | | A | 8.0 |
| Air Flow Volume | | m ³ /h | 720/600/570/530/500/460/430/320 |
| Dehumidifying Volume | | L/h | 1.40 |
| EER | | W/W | 4.00 |
| COP | | W/W | 4.00 |
| SEER | | | 8.5 |
| SCOP(Average/WarmerColder) | | | 4.6/5.6/3.6 |
| Application Area | | m ² | 16-24 |
| Indoor Unit | Model | | 1.GWH12AUCXD-K6DNA1C/I 2.GWH12AUCXD-K6DNA2C/I |
| | Product Code | | 1.CB575N00700/CB575N00702/CB575N00703 2.CB597N00600 |
| | Fan Type | | Cross-flow |
| | Fan Diameter Length(DXL) | | mm Φ98×630 |
| | Cooling Speed | | r/min 1400/1200/1120/1050/980/920/750/500 |
| | Heating Speed | | r/min 1400/1200/1140/1080/1020/960/900 |
| | Fan Motor Power Output | | W 15 |
| | Fan Motor RLA | | A 0.2 |
| | Fan Motor Capacitor | | μF / |
| | Heater Power Input | | W / |
| | Evaporator Form | | Aluminum Fin-copper Tube |
| | Evaporator Pipe Diameter | | mm Φ5 |
| | Evaporator Row-fin Gap | | mm 2-1.4 |
| | Evaporator Coil Length (LXD _X W) | | mm 634×22.8×304.8 |
| | Swing Motor Model | | MP24BA/MP24AK/MP24HF |
| | Swing Motor Power Output | | W 1.5/1.5/1.5 |
| | Fuse Current | | A 3.15 |
| | Sound Pressure Level | | dB (A) Cooling:43/39/37/35/32/30/24/19 Heating:44/39/37/35/33/31/29 |
| | Sound Power Level | | dB (A) Cooling:60/53/51/49/46/44/38/33 Heating:60/53/51/49/47/45/43 |
| | Dimension (WXHXD) | | mm 837×293×200 |
| Dimension of Carton Box (LXWXH) | | mm 891×357×261 | |
| Dimension of Package (LXWXH) | | mm 896×373×272 | |
| Net Weight | | kg 9.5 | |
| Gross Weight | | kg 11.5 | |

| | | | | |
|--|---|-------------------|----------------------------------|--------------------------|
| Outdoor Unit | Outdoor Unit Model | | GWH12AUCXD-K6DNA1C/O(LC) | |
| | Outdoor Unit Product Code | | CB575W00701 | |
| | Compressor Manufacturer | | ZHUHAI LANDA COMPRESSOR CO., LTD | |
| | Compressor Model | | QXF-A098zE170 | |
| | Compressor Oil | | ZE-GLES RB68GX or equivalent | |
| | Compressor Type | | Rotary | |
| | Compressor LRA. | A | | / |
| | Compressor RLA | A | | 3.9 |
| | Compressor Power Input | W | | / |
| | Compressor Overload Protector | | | / |
| | Throttling Method | | | Electron expansion valve |
| | Set Temperature Range | °C | | 16~30 |
| | Cooling Operation Ambient Temperature Range | °C | | -15~50 |
| | Heating Operation Ambient Temperature Range | °C | | -15~30 |
| | Condenser Form | | | Aluminum Fin-copper Tube |
| | Condenser Pipe Diameter | mm | | Φ7 |
| | Condenser Rows-fin Gap | mm | | 2-1.4 |
| | Condenser Coil Length (LXDXW) | mm | | 761.5×38.1×528 |
| | Fan Motor Speed | rpm | | 850 |
| | Fan Motor Power Output | W | | 30 |
| | Fan Motor RLA | A | | 0.4 |
| | Fan Motor Capacitor | μF | | / |
| | Outdoor Unit Air Flow Volume | m ³ /h | | 2200 |
| | Fan Type | | | Axial-flow |
| | Fan Diameter | mm | | Φ420 |
| | Defrosting Method | | | Automatic Defrosting |
| | Climate Type | | | T1 |
| | Isolation | | | I |
| | Moisture Protection | | | IPX4 |
| | Permissible Excessive Operating Pressure for the Discharge Side | MPa | | 4.3 |
| | Permissible Excessive Operating Pressure for the Suction Side | MPa | | 2.5 |
| | Sound Pressure Level | dB (A) | | 53 |
| | Sound Power Level | dB (A) | | 64 |
| Dimension(WXHxD) | mm | | 802×555×350 | |
| Dimension of Carton Box (LXWXH) | mm | | 869×395×594 | |
| Dimension of Package(LXWXH) | mm | | 872×398×620 | |
| Net Weight | kg | | 30 | |
| Gross Weight | kg | | 32.5 | |
| Refrigerant | | | R32 | |
| Refrigerant Charge | kg | | 0.8 | |
| Connection Pipe | Connection Pipe Length | m | 5 | |
| | Connection Pipe Gas Additional Charge | g/m | 16 | |
| | Outer Diameter Liquid Pipe | | 1/4" | |
| | Outer Diameter Gas Pipe | | 3/8" | |
| | Max Distance Height | m | 10 | |
| | Max Distance Length | m | 20 | |
| Note: The connection pipe applies metric diameter. | | | | |

The above data is subject to change without notice. Please refer to the nameplate of the unit.

| | | | |
|------------------------------|---------------------------------|-------------------|--|
| Model | | | 1.GWH18AUDXD-K6DNA1A 2.GWH18AUDXD-K6DNA2A |
| Product Code | | | 1.CB575000100/CB575000102/CB575000103/CB575000104/CB575000107 2.CB597000200/CB597000204/CB597000203 |
| Power Supply | Rated Voltage | V~ | 220-240 |
| | Rated Frequency | Hz | 50 |
| | Phases | | 1 |
| Power Supply Mode | | | Outdoor |
| Cooling Capacity | | W | 5300 |
| Heating Capacity | | W | 5350 |
| Cooling Power Input | | W | 1582 |
| Heating Power Input | | W | 1393 |
| Cooling Current Input | | A | 7.2 |
| Heating Current Input | | A | 6.3 |
| Rated Input | | W | 2350 |
| Rated Cooling Current | | A | 10 |
| Rated Heating Current | | A | 10.5 |
| Air Flow Volume | | m ³ /h | 1000/850/760/650/580/520/450 |
| Dehumidifying Volume | | L/h | 1.90 |
| EER | | W/W | 3.35 |
| COP | | W/W | 3.84 |
| SEER | | | 7.3 |
| SCOP(Average/WarmerColder) | | | 4.2/5.7/3.5 |
| Application Area | | m ² | 23-34 |
| Indoor Unit | Model | | 1.GWH18AUDXD-K6DNA1A/I 2.GWH18AUDXD-K6DNA2A/I |
| | Product Code | | 1.CB575N00100/CB575N00102/CB575N00103/CB575N00104/CB575N00105 2.CB597N00200/CB597N00204/CB597N00203 |
| | Fan Type | | Cross-flow |
| | Fan Diameter Length(DXL) | mm | Φ106×739 |
| | Cooling Speed | r/min | 1250/1150/1030/960/800/700/650/500 |
| | Heating Speed | r/min | 1300/1150/1040/950/900/880/800 |
| | Fan Motor Power Output | W | 45 |
| | Fan Motor RLA | A | 0.25 |
| | Fan Motor Capacitor | μF | / |
| | Heater Power Input | W | / |
| | Evaporator Form | | Aluminum Fin-copper Tube |
| | Evaporator Pipe Diameter | mm | Φ5 |
| | Evaporator Row-fin Gap | mm | 2-1.3 |
| | Evaporator Coil Length (LXDXW) | mm | 745×22.8×342.9 |
| | Swing Motor Model | | MP24AK/MP24BA/MP24HF |
| | Swing Motor Power Output | W | 1.5/1.5 /1.5 |
| | Fuse Current | A | 3.15 |
| | Sound Pressure Level | dB (A) | Cooling:45/42/40/37/34/29/26/23 Heating:48/44/42/37/36/35/32 |
| | Sound Power Level | dB (A) | Cooling:60/55/53/50/47/42/39/36 Heating:60/57/55/50/49/48/45 |
| | Dimension (WXHXD) | mm | 993×311×222 |
| | Dimension of Carton Box (LXWXH) | mm | 1050×377×288 |
| Dimension of Package (LXWXH) | mm | 1055×385×298 | |
| Net Weight | kg | 12.5 | |
| Gross Weight | kg | 15 | |

| | | | | |
|---------------------------------|---|-------------------|---------------------------------|--------------------------|
| Outdoor Unit | Outdoor Unit Model | | GWH18AUDXD-K6DNA1A/O(LCLH) | |
| | Outdoor Unit Product Code | | CB575W00100 | |
| | Compressor Manufacturer | | ZHUHAI LANDA COMPRESSOR CO.,LTD | |
| | Compressor Model | | QXF-A120zH170A | |
| | Compressor Oil | | FW68DA or equivalent | |
| | Compressor Type | | Rotary | |
| | Compressor LRA. | A | | 18.00 |
| | Compressor RLA | A | | 5.00 |
| | Compressor Power Input | W | | 1096 |
| | Compressor Overload Protector | | | HPC115/95U1/KSD115°C |
| | Throttling Method | | | Electron expansion valve |
| | Set Temperature Range | °C | | 16~30 |
| | Cooling Operation Ambient Temperature Range | °C | | -15~50 |
| | Heating Operation Ambient Temperature Range | °C | | -25~30 |
| | Condenser Form | | | Aluminum Fin-copper Tube |
| | Condenser Pipe Diameter | mm | | Φ7 |
| | Condenser Rows-fin Gap | mm | | 2-1.4 |
| | Condenser Coil Length (LXDXW) | mm | | 895×38.1×528 |
| | Fan Motor Speed | rpm | | 880 |
| | Fan Motor Power Output | W | | 30 |
| | Fan Motor RLA | A | | 0.40 |
| | Fan Motor Capacitor | μF | | / |
| | Outdoor Unit Air Flow Volume | m ³ /h | | 2200 |
| | Fan Type | | | Axial-flow |
| | Fan Diameter | mm | | Φ420 |
| | Defrosting Method | | | Automatic Defrosting |
| | Climate Type | | | T1 |
| | Isolation | | | I |
| | Moisture Protection | | | IPX4 |
| | Permissible Excessive Operating Pressure for the Discharge Side | MPa | | 4.3 |
| | Permissible Excessive Operating Pressure for the Suction Side | MPa | | 2.5 |
| | Sound Pressure Level | dB (A) | | 56 |
| | Sound Power Level | dB (A) | | 65 |
| Dimension(WXHXD) | mm | | 802×555×350 | |
| Dimension of Carton Box (LXWXH) | mm | | 869×395×594 | |
| Dimension of Package(LXWXH) | mm | | 872×398×620 | |
| Net Weight | kg | | 31.5 | |
| Gross Weight | kg | | 34 | |
| Refrigerant | | | R32 | |
| Refrigerant Charge | kg | | 0.85 | |
| Connection Pipe | Connection Pipe Length | m | 5 | |
| | Connection Pipe Gas Additional Charge | g/m | 16 | |
| | Outer Diameter Liquid Pipe | | 1/4" | |
| | Outer Diameter Gas Pipe | | 1/2" | |
| | Max Distance Height | m | 10 | |
| | Max Distance Length | m | 25 | |
| | Note: The connection pipe applies metric diameter. | | | |

The above data is subject to change without notice. Please refer to the nameplate of the unit.

| | | | | |
|---------------------------------|---|-------------------|--|---|
| Model | | | 1.GWH18AUDXD-K6DNA1A 2.GWH18AUDXD-K6DNA2A | |
| Product Code | | | 1.CB575000101/CB575000105/CB575000106/CB575000108/ CB575000109/CB575000110 2.CB597000202 | |
| Power Supply | Rated Voltage | V~ | 220-240 | |
| | Rated Frequency | Hz | 50 | |
| | Phases | | 1 | |
| Power Supply Mode | | | Outdoor | |
| Cooling Capacity | | W | 5300 | |
| Heating Capacity | | W | 5350 | |
| Cooling Power Input | | W | 1582 | |
| Heating Power Input | | W | 1393 | |
| Cooling Current Input | | A | 7.2 | |
| Heating Current Input | | A | 6.3 | |
| Rated Input | | W | 2350 | |
| Rated Cooling Current | | A | 10 | |
| Rated Heating Current | | A | 10.5 | |
| Air Flow Volume | | m ³ /h | 1000/850/760/650/580/520/450 | |
| Dehumidifying Volume | | L/h | 1.90 | |
| EER | | W/W | 3.35 | |
| COP | | W/W | 3.84 | |
| SEER | | | 7.3 | |
| SCOP(Average/WarmerColder) | | | 4.2/5.7/3.5 | |
| Application Area | | m ² | 23-34 | |
| Indoor Unit | Model | | 1.GWH18AUDXD-K6DNA1A/I 2.GWH18AUDXD-K6DNA2A/I | |
| | Product Code | | 1.CB575N00100/CB575N00102/CB575N00105/CB575N00104/ CB575N00103/CB575N00110 2.CB597N00200 | |
| | Fan Type | | Cross-flow | |
| | Fan Diameter Length(DXL) | | mm | Φ106×739 |
| | Cooling Speed | | r/min | 1250/1150/1030/960/800/700/650/500 |
| | Heating Speed | | r/min | 1300/1150/1040/950/900/880/800 |
| | Fan Motor Power Output | | W | 45 |
| | Fan Motor RLA | | A | 0.25 |
| | Fan Motor Capacitor | | μF | / |
| | Heater Power Input | | W | / |
| | Evaporator Form | | | Aluminum Fin-copper Tube |
| | Evaporator Pipe Diameter | | mm | Φ5 |
| | Evaporator Row-fin Gap | | mm | 2-1.3 |
| | Evaporator Coil Length (LXD _X W) | | mm | 745×22.8×342.9 |
| | Swing Motor Model | | | MP24AK/MP24BA/MP24HF |
| | Swing Motor Power Output | | W | 1.5/1.5 /1.5 |
| | Fuse Current | | A | 3.15 |
| | Sound Pressure Level | | dB (A) | Cooling:45/42/40/37/34/29/26/23 Heating:48/44/42/37/36/35/32 |
| | Sound Power Level | | dB (A) | Cooling:60/55/53/50/47/42/39/36 Heating:60/57/55/50/49/48/45 |
| | Dimension (WXH _X D) | | mm | 993×311×222 |
| Dimension of Carton Box (LXWXH) | | mm | 1050×377×288 | |
| Dimension of Package (LXWXH) | | mm | 1055×385×298 | |
| Net Weight | | kg | 12.5 | |
| Gross Weight | | kg | 15 | |

| | | | | |
|---------------------------------|---|-------------------|---------------------------------|--------------------------|
| Outdoor Unit | Outdoor Unit Model | | GWH18AUDXD-K6DNA1A/O(LC) | |
| | Outdoor Unit Product Code | | CB575W00101 | |
| | Compressor Manufacturer | | ZHUHAI LANDA COMPRESSOR CO.,LTD | |
| | Compressor Model | | QXF-A120zH170A | |
| | Compressor Oil | | FW68DA or equivalent | |
| | Compressor Type | | Rotary | |
| | Compressor LRA. | A | | 18.00 |
| | Compressor RLA | A | | 5.00 |
| | Compressor Power Input | W | | 1096 |
| | Compressor Overload Protector | | | HPC115/95U1/KSD115°C |
| | Throttling Method | | | Electron expansion valve |
| | Set Temperature Range | °C | | 16~30 |
| | Cooling Operation Ambient Temperature Range | °C | | -15~50 |
| | Heating Operation Ambient Temperature Range | °C | | -15~30 |
| | Condenser Form | | | Aluminum Fin-copper Tube |
| | Condenser Pipe Diameter | mm | | Φ7 |
| | Condenser Rows-fin Gap | mm | | 2-1.4 |
| | Condenser Coil Length (LXDXW) | mm | | 895×38.1×528 |
| | Fan Motor Speed | rpm | | 880 |
| | Fan Motor Power Output | W | | 30 |
| | Fan Motor RLA | A | | 0.40 |
| | Fan Motor Capacitor | μF | | / |
| | Outdoor Unit Air Flow Volume | m ³ /h | | 2200 |
| | Fan Type | | | Axial-flow |
| | Fan Diameter | mm | | Φ420 |
| | Defrosting Method | | | Automatic Defrosting |
| | Climate Type | | | T1 |
| | Isolation | | | I |
| | Moisture Protection | | | IPX4 |
| | Permissible Excessive Operating Pressure for the Discharge Side | MPa | | 4.3 |
| | Permissible Excessive Operating Pressure for the Suction Side | MPa | | 2.5 |
| | Sound Pressure Level | dB (A) | | 56 |
| | Sound Power Level | dB (A) | | 65 |
| Dimension(WXHxD) | mm | | 802×555×350 | |
| Dimension of Carton Box (LXWXH) | mm | | 869×395×594 | |
| Dimension of Package(LXWXH) | mm | | 872×398×620 | |
| Net Weight | kg | | 31.5 | |
| Gross Weight | kg | | 34 | |
| Refrigerant | | | R32 | |
| Refrigerant Charge | kg | | 0.85 | |
| Connection Pipe | Connection Pipe Length | m | 5 | |
| | Connection Pipe Gas Additional Charge | g/m | 16 | |
| | Outer Diameter Liquid Pipe | | 1/4" | |
| | Outer Diameter Gas Pipe | | 1/2" | |
| | Max Distance Height | m | 10 | |
| | Max Distance Length | m | 25 | |
| | Note: The connection pipe applies metric diameter. | | | |

The above data is subject to change without notice. Please refer to the nameplate of the unit.

| | | | | |
|----------------------------|---|-------------------|--|---|
| Model | | | 1.GWH18AUDXE-K6DNA1A 2.GWH18AUDXE-K6DNA2A | |
| Product Code | | | 1.CB575000900/CB575000905/CB575000906 2.CB597000702 | |
| Power Supply | Rated Voltage | V~ | 220-240 | |
| | Rated Frequency | Hz | 50 | |
| | Phases | | 1 | |
| Power Supply Mode | | | Outdoor | |
| Cooling Capacity | | W | 5300 | |
| Heating Capacity | | W | 5600 | |
| Cooling Power Input | | W | 1472 | |
| Heating Power Input | | W | 1365 | |
| Cooling Current Input | | A | 6.6 | |
| Heating Current Input | | A | 6.2 | |
| Rated Input | | W | 2300 | |
| Rated Cooling Current | | A | 11.5 | |
| Rated Heating Current | | A | 11.5 | |
| Air Flow Volume | | m ³ /h | 1000/880/760/650/620/600/550 | |
| Dehumidifying Volume | | L/h | 1.8 | |
| EER | | W/W | 3.6 | |
| COP | | W/W | 4.1 | |
| SEER | | | 8 | |
| SCOP(Average/WarmerColder) | | | 4.6/5.8/3.6 | |
| Application Area | | m ² | 23-34 | |
| Indoor Unit | Model | | 1.GWH18AUDXE-K6DNA1A/I 2.GWH18AUDXE-K6DNA2A/I | |
| | Product Code | | 1.CB575N00900/CB575N00905/CB575N00906 2.CB597N00702 | |
| | Fan Type | | Cross-flow | |
| | Fan Diameter Length(DXL) | | mm | Φ106×739 |
| | Cooling Speed | | r/min | 1250/1150/1030/960/800/700/650/500 |
| | Heating Speed | | r/min | 1300/1150/1040/950/900/880/800 |
| | Fan Motor Power Output | | W | 45 |
| | Fan Motor RLA | | A | 0.25 |
| | Fan Motor Capacitor | | μF | / |
| | Heater Power Input | | W | / |
| | Evaporator Form | | | Aluminum Fin-copper Tube |
| | Evaporator Pipe Diameter | | mm | Φ5 |
| | Evaporator Row-fin Gap | | mm | 2-1.3 |
| | Evaporator Coil Length (LXD _X W) | | mm | 745×22.8×342.9 |
| | Swing Motor Model | | | MP24AK/MP24BA/MP24HF |
| | Swing Motor Power Output | | W | 1.5/1.5 /1.5 |
| | Fuse Current | | A | 3.15 |
| | Sound Pressure Level | | dB (A) | Cooling:45/42/40/37/34/29/26/23 Heating:48/44/42/38/36/35/32 |
| | Sound Power Level | | dB (A) | Cooling:60/57/55/52/49/44/41/38 Heating:60/56/54/50/48/47/44 |
| | Dimension (WXHXD) | | mm | 993×311×222 |
| | Dimension of Carton Box (LXWXH) | | mm | 1050×377×288 |
| | Dimension of Package (LXWXH) | | mm | 1055×385×298 |
| | Net Weight | | kg | 13 |
| Gross Weight | | kg | 15.5 | |

| | | | | |
|---------------------------------|---|-------------------|---------------------------------|--------------------------|
| Outdoor Unit | Outdoor Unit Model | | GWH18AUDXE-K6DNA1A/O(LCLH) | |
| | Outdoor Unit Product Code | | CB575W00900 | |
| | Compressor Manufacturer | | ZHUHAI LANDA COMPRESSOR CO.,LTD | |
| | Compressor Model | | QXF-M130ZF170 | |
| | Compressor Oil | | FW68DA or equivalent | |
| | Compressor Type | | Rotary | |
| | Compressor LRA. | A | | / |
| | Compressor RLA | A | | / |
| | Compressor Power Input | W | | 1196 |
| | Compressor Overload Protector | | | / |
| | Throttling Method | | | Electron expansion valve |
| | Set Temperature Range | °C | | 16~30 |
| | Cooling Operation Ambient Temperature Range | °C | | -15~50 |
| | Heating Operation Ambient Temperature Range | °C | | -25~30 |
| | Condenser Form | | | Aluminum Fin-copper Tube |
| | Condenser Pipe Diameter | mm | | Φ7.94 |
| | Condenser Rows-fin Gap | mm | | 2-1.4 |
| | Condenser Coil Length (LXDXW) | mm | | 833×38.1×528 |
| | Fan Motor Speed | rpm | | 970 |
| | Fan Motor Power Output | W | | 40 |
| | Fan Motor RLA | A | | 0.7 |
| | Fan Motor Capacitor | μF | | / |
| | Outdoor Unit Air Flow Volume | m ³ /h | | 3000 |
| | Fan Type | | | Axial-flow |
| | Fan Diameter | mm | | Φ445 |
| | Defrosting Method | | | Automatic Defrosting |
| | Climate Type | | | T1 |
| | Isolation | | | I |
| | Moisture Protection | | | IPX4 |
| | Permissible Excessive Operating Pressure for the Discharge Side | MPa | | 4.3 |
| | Permissible Excessive Operating Pressure for the Suction Side | MPa | | 2.5 |
| | Sound Pressure Level | dB (A) | | 59 |
| | Sound Power Level | dB (A) | | 65 |
| Dimension(WXHxD) | mm | | 873×555×376 | |
| Dimension of Carton Box (LXWXH) | mm | | 948×428×591 | |
| Dimension of Package(LXWXH) | mm | | 951×431×620 | |
| Net Weight | kg | | 37 | |
| Gross Weight | kg | | 40 | |
| Refrigerant | | | R32 | |
| Refrigerant Charge | kg | | 0.95 | |
| Connection Pipe | Connection Pipe Length | m | 5 | |
| | Connection Pipe Gas Additional Charge | g/m | 16 | |
| | Outer Diameter Liquid Pipe | | 1/4" | |
| | Outer Diameter Gas Pipe | | 1/2" | |
| | Max Distance Height | m | 10 | |
| | Max Distance Length | m | 25 | |
| | Note: The connection pipe applies metric diameter. | | | |

The above data is subject to change without notice. Please refer to the nameplate of the unit.

| | | | |
|------------------------------|---|-------------------|---|
| Model | | | 1.GWH18AUDXE-K6DNA1A 2.GWH18AUDXE-K6DNA2A |
| Product Code | | | 1.CB575000901/CB575000902/CB575000903 2.CB597000701 |
| Power Supply | Rated Voltage | V~ | 220-240 |
| | Rated Frequency | Hz | 50 |
| | Phases | | 1 |
| Power Supply Mode | | | Outdoor |
| Cooling Capacity | | W | 5300 |
| Heating Capacity | | W | 5600 |
| Cooling Power Input | | W | 1472 |
| Heating Power Input | | W | 1365 |
| Cooling Current Input | | A | 6.6 |
| Heating Current Input | | A | 6.2 |
| Rated Input | | W | 2300 |
| Rated Cooling Current | | A | 11.5 |
| Rated Heating Current | | A | 11.5 |
| Air Flow Volume | | m ³ /h | 1000/880/760/650/620/600/550 |
| Dehumidifying Volume | | L/h | 1.8 |
| EER | | W/W | 3.6 |
| COP | | W/W | 4.1 |
| SEER | | | 8 |
| SCOP(Average/WarmerColder) | | | 4.6/5.8/3.6 |
| Application Area | | m ² | 23-34 |
| Indoor Unit | Model | | 1.GWH18AUDXE-K6DNA1A/I 2.GWH18AUDXE-K6DNA2A/I |
| | Product Code | | 1.CB575N00900/CB575N00902/CB575N00903 2.CB597N00700 |
| | Fan Type | | Cross-flow |
| | Fan Diameter Length(DXL) | mm | Φ106×739 |
| | Cooling Speed | r/min | 1250/1150/1030/960/800/700/650/500 |
| | Heating Speed | r/min | 1300/1150/1040/950/900/880/800 |
| | Fan Motor Power Output | W | 45 |
| | Fan Motor RLA | A | 0.25 |
| | Fan Motor Capacitor | μF | / |
| | Heater Power Input | W | / |
| | Evaporator Form | | Aluminum Fin-copper Tube |
| | Evaporator Pipe Diameter | mm | Φ5 |
| | Evaporator Row-fin Gap | mm | 2-1.3 |
| | Evaporator Coil Length (LXD _X W) | mm | 745×22.8×342.9 |
| | Swing Motor Model | | MP24AK/MP24BA/MP24HF |
| | Swing Motor Power Output | W | 1.5/1.5 /1.5 |
| | Fuse Current | A | 3.15 |
| | Sound Pressure Level | dB (A) | Cooling:45/42/40/37/34/29/26/23 Heating:48/44/42/38/36/35/32 |
| | Sound Power Level | dB (A) | Cooling:60/57/55/52/49/44/41/38 Heating:60/56/54/50/48/47/44 |
| | Dimension (WXHXD) | mm | 993×311×222 |
| | Dimension of Carton Box (LXWXH) | mm | 1050×377×288 |
| Dimension of Package (LXWXH) | mm | 1055×385×298 | |
| Net Weight | kg | 13 | |
| Gross Weight | kg | 15.5 | |

| | | | |
|---------------------------------|---|-------------------|---------------------------------|
| Outdoor Unit | Outdoor Unit Model | | GWH18AUDXE-K6DNA1A/O(LC) |
| | Outdoor Unit Product Code | | CB575W00901 |
| | Compressor Manufacturer | | ZHUHAI LANDA COMPRESSOR CO.,LTD |
| | Compressor Model | | QXF-M130ZF170 |
| | Compressor Oil | | FW68DA or equivalent |
| | Compressor Type | | Rotary |
| | Compressor LRA. | A | / |
| | Compressor RLA | A | / |
| | Compressor Power Input | W | 1196 |
| | Compressor Overload Protector | | / |
| | Throttling Method | | Electron expansion valve |
| | Set Temperature Range | °C | 16~30 |
| | Cooling Operation Ambient Temperature Range | °C | -15~50 |
| | Heating Operation Ambient Temperature Range | °C | -15~30 |
| | Condenser Form | | Aluminum Fin-copper Tube |
| | Condenser Pipe Diameter | mm | Φ7.94 |
| | Condenser Rows-fin Gap | mm | 2-1.4 |
| | Condenser Coil Length (LXDXW) | mm | 833×38.1×528 |
| | Fan Motor Speed | rpm | 970 |
| | Fan Motor Power Output | W | 40 |
| | Fan Motor RLA | A | 0.7 |
| | Fan Motor Capacitor | μF | / |
| | Outdoor Unit Air Flow Volume | m ³ /h | 3000 |
| | Fan Type | | Axial-flow |
| | Fan Diameter | mm | Φ445 |
| | Defrosting Method | | Automatic Defrosting |
| | Climate Type | | T1 |
| | Isolation | | I |
| | Moisture Protection | | IPX4 |
| | Permissible Excessive Operating Pressure for the Discharge Side | MPa | 4.3 |
| | Permissible Excessive Operating Pressure for the Suction Side | MPa | 2.5 |
| | Sound Pressure Level | dB (A) | 59 |
| | Sound Power Level | dB (A) | 65 |
| Dimension(WXHxD) | mm | 873×555×376 | |
| Dimension of Carton Box (LXWXH) | mm | 948×428×591 | |
| Dimension of Package(LXWXH) | mm | 951×431×620 | |
| Net Weight | kg | 37 | |
| Gross Weight | kg | 40 | |
| Refrigerant | | R32 | |
| Refrigerant Charge | kg | 0.95 | |
| Connection Pipe | Connection Pipe Length | m | 5 |
| | Connection Pipe Gas Additional Charge | g/m | 16 |
| | Outer Diameter Liquid Pipe | | 1/4" |
| | Outer Diameter Gas Pipe | | 1/2" |
| | Max Distance Height | m | 10 |
| | Max Distance Length | m | 25 |
| | Note: The connection pipe applies metric diameter. | | |

The above data is subject to change without notice. Please refer to the nameplate of the unit.

| | | | | |
|------------------------------|---------------------------------|---------------------------------------|---------------------------------------|---|
| Model | | 1.GWH18AUDXE-K6DNA1B | | |
| Product Code | | 1.CB575001100/CB575001101/CB575001102 | | |
| Power Supply | Rated Voltage | V~ | 220-240 | |
| | Rated Frequency | Hz | 50 | |
| | Phases | | 1 | |
| Power Supply Mode | | Outdoor | | |
| Cooling Capacity | | W | 5100 | |
| Heating Capacity | | W | 5600 | |
| Cooling Power Input | | W | 1417 | |
| Heating Power Input | | W | 1365 | |
| Cooling Current Input | | A | 6.4 | |
| Heating Current Input | | A | 6.2 | |
| Rated Input | | W | 2300 | |
| Rated Cooling Current | | A | 11.5 | |
| Rated Heating Current | | A | 11.5 | |
| Air Flow Volume | | m ³ /h | 1000/880/760/650/620/600/550 | |
| Dehumidifying Volume | | L/h | 1.8 | |
| EER | | W/W | 3.6 | |
| COP | | W/W | 4.1 | |
| SEER | | | 8.5 | |
| SCOP(Average/WarmerColder) | | | 4.6/5.8/3.6 | |
| Application Area | | m ² | 23-34 | |
| Indoor Unit | Model | | 1.GWH18AUDXE-K6DNA1B/I | |
| | Product Code | | 1.CB575N01100/CB575N01101/CB575N01102 | |
| | Fan Type | | Cross-flow | |
| | Fan Diameter Length(DXL) | | mm | Φ106×739 |
| | Cooling Speed | | r/min | 1250/1150/1030/960/800/700/650/500 |
| | Heating Speed | | r/min | 1300/1150/1040/950/900/880/800 |
| | Fan Motor Power Output | | W | 45 |
| | Fan Motor RLA | | A | 0.25 |
| | Fan Motor Capacitor | | μF | / |
| | Heater Power Input | | W | / |
| | Evaporator Form | | | Aluminum Fin-copper Tube |
| | Evaporator Pipe Diameter | | mm | Φ5 |
| | Evaporator Row-fin Gap | | mm | 2-1.3 |
| | Evaporator Coil Length (LXDXW) | | mm | 745×22.8×342.9 |
| | Swing Motor Model | | | MP24AK/MP24BA/MP24HF |
| | Swing Motor Power Output | | W | 1.5/1.5 /1.5 |
| | Fuse Current | | A | 3.15 |
| | Sound Pressure Level | | dB (A) | Cooling:45/42/40/37/34/29/26/23 Heating:48/44/42/38/36/35/32 |
| | Sound Power Level | | dB (A) | Cooling:60/57/55/52/49/44/41/38 Heating:60/56/54/50/48/47/44 |
| | Dimension (WXHXD) | | mm | 993×311×222 |
| | Dimension of Carton Box (LXWXH) | | mm | 1050×377×288 |
| Dimension of Package (LXWXH) | | mm | 1055×385×298 | |
| Net Weight | | kg | 13 | |
| Gross Weight | | kg | 15.5 | |

| | | | | |
|---------------------------------|---|-------------------|---------------------------------|--------------------------|
| Outdoor Unit | Outdoor Unit Model | | GWH18AUDXE-K6DNA1B/O(LCLH) | |
| | Outdoor Unit Product Code | | CB575W01100 | |
| | Compressor Manufacturer | | ZHUHAI LANDA COMPRESSOR CO.,LTD | |
| | Compressor Model | | QXF-M130ZF170 | |
| | Compressor Oil | | FW68DA or equivalent | |
| | Compressor Type | | Rotary | |
| | Compressor LRA. | A | | / |
| | Compressor RLA | A | | / |
| | Compressor Power Input | W | | 1196 |
| | Compressor Overload Protector | | | / |
| | Throttling Method | | | Electron expansion valve |
| | Set Temperature Range | °C | | 16~30 |
| | Cooling Operation Ambient Temperature Range | °C | | -15~50 |
| | Heating Operation Ambient Temperature Range | °C | | -25~30 |
| | Condenser Form | | | Aluminum Fin-copper Tube |
| | Condenser Pipe Diameter | mm | | Φ7.94 |
| | Condenser Rows-fin Gap | mm | | 2-1.4 |
| | Condenser Coil Length (LXDXW) | mm | | 833×38.1×528 |
| | Fan Motor Speed | rpm | | 970 |
| | Fan Motor Power Output | W | | 40 |
| | Fan Motor RLA | A | | 0.7 |
| | Fan Motor Capacitor | μF | | / |
| | Outdoor Unit Air Flow Volume | m ³ /h | | 3000 |
| | Fan Type | | | Axial-flow |
| | Fan Diameter | mm | | Φ445 |
| | Defrosting Method | | | Automatic Defrosting |
| | Climate Type | | | T1 |
| | Isolation | | | I |
| | Moisture Protection | | | IPX4 |
| | Permissible Excessive Operating Pressure for the Discharge Side | MPa | | 4.3 |
| | Permissible Excessive Operating Pressure for the Suction Side | MPa | | 2.5 |
| | Sound Pressure Level | dB (A) | | 59 |
| | Sound Power Level | dB (A) | | 65 |
| Dimension(WXHxD) | mm | | 873×555×376 | |
| Dimension of Carton Box (LXWXH) | mm | | 948×428×591 | |
| Dimension of Package(LXWXH) | mm | | 951×431×620 | |
| Net Weight | kg | | 37 | |
| Gross Weight | kg | | 40 | |
| Refrigerant | | | R32 | |
| Refrigerant Charge | kg | | 0.95 | |
| Connection Pipe | Connection Pipe Length | m | 5 | |
| | Connection Pipe Gas Additional Charge | g/m | 16 | |
| | Outer Diameter Liquid Pipe | | 1/4" | |
| | Outer Diameter Gas Pipe | | 1/2" | |
| | Max Distance Height | m | 10 | |
| | Max Distance Length | m | 25 | |
| | Note: The connection pipe applies metric diameter. | | | |

The above data is subject to change without notice. Please refer to the nameplate of the unit.

| | | | |
|---------------------------------|--------------------------------|--|---|
| Model | | 1.GWH24AUDXF-K6DNA1A 2.GWH24AUDXF-K6DNA2A | |
| Product Code | | 1.CB437004700/CB437004702/CB437004703/CB437004704/CB437004707/ CB437004712 2.CB597000300/CB597000303/CB597000304 | |
| Power Supply | Rated Voltage | V~ | 220-240 |
| | Rated Frequency | Hz | 50 |
| | Phases | | 1 |
| Power Supply Mode | | Outdoor | |
| Cooling Capacity | | W | 7100 |
| Heating Capacity | | W | 7300 |
| Cooling Power Input | | W | 2030 |
| Heating Power Input | | W | 1870 |
| Cooling Current Input | | A | 9 |
| Heating Current Input | | A | 9.3 |
| Rated Input | | W | 3500 |
| Rated Cooling Current | | A | 13 |
| Rated Heating Current | | A | 14 |
| Air Flow Volume | | m ³ /h | 1000/850/760/580/520/450/400/280 |
| Dehumidifying Volume | | L/h | 2.40 |
| EER | | W/W | 3.51 |
| COP | | W/W | 3.90 |
| SEER | | | 7 |
| SCOP(Average/WarmerColder) | | | 4.30/5.50/3.40 |
| Application Area | | m ² | 27-42 |
| Indoor Unit | Model | 1.GWH24AUDXF-K6DNA1A/I 2.GWH24AUDXF-K6DNA2A/I | |
| | Product Code | 1.CB437N04700/CB437N04702CB437N04703/CB437N04704CB437N04706/ CB437N04711 2.CB597N00300/CB597N00302/CB597N00304 | |
| | Fan Type | Cross-flow | |
| | Fan Diameter Length(DXL) | mm | Φ106×739 |
| | Cooling Speed | r/min | 1400/1200/1120/1050/980/860/750/550 |
| | Heating Speed | r/min | 1400/1200/1120/1050/950/850/750 |
| | Fan Motor Power Output | W | 45 |
| | Fan Motor RLA | A | 0.25 |
| | Fan Motor Capacitor | μF | / |
| | Heater Power Input | W | / |
| | Evaporator Form | Aluminum Fin-copper Tube | |
| | Evaporator Pipe Diameter | mm | Φ7 |
| | Evaporator Row-fin Gap | mm | 2-1.4 |
| | Evaporator Coil Length (LXDXW) | mm | 745×22.8×342.9 |
| | Swing Motor Model | MP24AK/MP24HF/MP24BA | |
| | Swing Motor Power Output | W | 1.5/1.5/1.5 |
| | Fuse Current | A | 3.15 |
| | Sound Pressure Level | dB (A) | Cooling:48/44/41/40/38/36/33/27 Heating:50/47/43/41/40/36/35 |
| | Sound Power Level | dB (A) | Cooling:65/59/56/55/53/51/48/42 Heating:64/62/58/56/55/51/50 |
| | Dimension (WXHXD) | mm | 993×311×222 |
| Dimension of Carton Box (LXWXH) | mm | 1050×377×288 | |
| Dimension of Package (LXWXH) | mm | 1055×385×298 | |
| Net Weight | kg | 13 | |
| Gross Weight | kg | 15.5 | |

| | | | | |
|--|---|-------------------|---------------------------------|--------------------------|
| Outdoor Unit | Outdoor Unit Model | | GWH24AUDXF-K6DNA1A/O(LCLH) | |
| | Outdoor Unit Product Code | | CB437W04700 | |
| | Compressor Manufacturer | | ZHUHAI LANDA COMPRESSOR CO.,LTD | |
| | Compressor Model | | QXFS-M180zX170 | |
| | Compressor Oil | | / | |
| | Compressor Type | | Rotary | |
| | Compressor LRA. | A | | 24.00 |
| | Compressor RLA | A | | 3.50 |
| | Compressor Power Input | W | | 1350 |
| | Compressor Overload Protector | | | HPC 115/95U1 KSD115°C |
| | Throttling Method | | | Electron expansion valve |
| | Set Temperature Range | °C | | 16~30 |
| | Cooling Operation Ambient Temperature Range | °C | | -15~50 |
| | Heating Operation Ambient Temperature Range | °C | | -25~30 |
| | Condenser Form | | | Aluminum Fin-copper Tube |
| | Condenser Pipe Diameter | mm | | Φ7.94 |
| | Condenser Rows-fin Gap | mm | | 2-1.4 |
| | Condenser Coil Length (LXDXW) | mm | | 934×38.1×616 |
| | Fan Motor Speed | rpm | | 800 |
| | Fan Motor Power Output | W | | 60 |
| | Fan Motor RLA | A | | 0.65 |
| | Fan Motor Capacitor | μF | | / |
| | Outdoor Unit Air Flow Volume | m ³ /h | | 3600 |
| | Fan Type | | | Axial-flow |
| | Fan Diameter | mm | | Φ520 |
| | Defrosting Method | | | Automatic Defrosting |
| | Climate Type | | | T1 |
| | Isolation | | | I |
| | Moisture Protection | | | IPX4 |
| | Permissible Excessive Operating Pressure for the Discharge Side | MPa | | 4.3 |
| | Permissible Excessive Operating Pressure for the Suction Side | MPa | | 2.5 |
| | Sound Pressure Level | dB (A) | | 59 |
| | Sound Power Level | dB (A) | | 70 |
| Dimension(WXHxD) | mm | | 958×660×402 | |
| Dimension of Carton Box (LXWXH) | mm | | 1029×453×715 | |
| Dimension of Package(LXWXH) | mm | | 1032×456×737 | |
| Net Weight | kg | | 45 | |
| Gross Weight | kg | | 49.5 | |
| Refrigerant | | | R32 | |
| Refrigerant Charge | kg | | 1.4 | |
| Connection Pipe | Connection Pipe Length | m | 5 | |
| | Connection Pipe Gas Additional Charge | g/m | 40 | |
| | Outer Diameter Liquid Pipe | | 1/4" | |
| | Outer Diameter Gas Pipe | | 5/8" | |
| | Max Distance Height | m | 10 | |
| | Max Distance Length | m | 25 | |
| Note: The connection pipe applies metric diameter. | | | | |

The above data is subject to change without notice. Please refer to the nameplate of the unit.





| | | | | |
|------------------------------|---|-------------------|--|---|
| Model | | | 1.GWH24AUDXF-K6DNA1A 2.GWH24AUDXF-K6DNA2A | |
| Product Code | | | 1.CB437004701/CB437004705/CB437004706/CB437004708/ CB437004709/CB437004710/CB437004711 2.CB597000301/CB597000302 | |
| Power Supply | Rated Voltage | V~ | 220-240 | |
| | Rated Frequency | Hz | 50 | |
| | Phases | | 1 | |
| Power Supply Mode | | | Outdoor | |
| Cooling Capacity | | W | 7100 | |
| Heating Capacity | | W | 7300 | |
| Cooling Power Input | | W | 2030 | |
| Heating Power Input | | W | 1870 | |
| Cooling Current Input | | A | 9 | |
| Heating Current Input | | A | 9.3 | |
| Rated Input | | W | 3500 | |
| Rated Cooling Current | | A | 13 | |
| Rated Heating Current | | A | 14 | |
| Air Flow Volume | | m ³ /h | 1000/850/760/580/520/450/400/280 | |
| Dehumidifying Volume | | L/h | 2.40 | |
| EER | | W/W | 3.51 | |
| COP | | W/W | 3.90 | |
| SEER | | | 7 | |
| SCOP(Average/WarmerColder) | | | 4.30/5.50/3.40 | |
| Application Area | | m ² | 27-42 | |
| Indoor Unit | Model | | 1.GWH24AUDXF-K6DNA1A/I 2.GWH24AUDXF-K6DNA2A/I | |
| | Product Code | | 1.CB437N04700/CB437N04702/CB437N04706/CB437N04704/ CB437N04703/CB437N04710/CB437N04711 2.CB597N00300/CB597N00302 | |
| | Fan Type | | Cross-flow | |
| | Fan Diameter Length(DXL) | | mm | Φ106×739 |
| | Cooling Speed | | r/min | 1400/1200/1120/1050/980/860/750/550 |
| | Heating Speed | | r/min | 1400/1200/1120/1050/950/850/750 |
| | Fan Motor Power Output | | W | 45 |
| | Fan Motor RLA | | A | 0.25 |
| | Fan Motor Capacitor | | μF | / |
| | Heater Power Input | | W | / |
| | Evaporator Form | | | Aluminum Fin-copper Tube |
| | Evaporator Pipe Diameter | | mm | Φ7 |
| | Evaporator Row-fin Gap | | mm | 2-1.4 |
| | Evaporator Coil Length (LXD _X W) | | mm | 745×22.8×342.9 |
| | Swing Motor Model | | | MP24AK/MP24HF/MP24BA |
| | Swing Motor Power Output | | W | 1.5/1.5/1.5 |
| | Fuse Current | | A | 3.15 |
| | Sound Pressure Level | | dB (A) | Cooling:48/44/41/40/38/36/33/27 Heating:50/47/43/41/40/36/35 |
| | Sound Power Level | | dB (A) | Cooling:65/59/56/55/53/51/48/42 Heating:64/62/58/56/55/51/50 |
| | Dimension (WXH _X D) | | mm | 993×311×222 |
| | Dimension of Carton Box (LXWXH) | | mm | 1050×377×288 |
| Dimension of Package (LXWXH) | | mm | 1055×385×298 | |
| Net Weight | | kg | 13 | |
| Gross Weight | | kg | 15.5 | |

| | | | | |
|--|---|-------------------|---------------------------------|--------------------------|
| Outdoor Unit | Outdoor Unit Model | | GWH24AUDXF-K6DNA1A/O(LC) | |
| | Outdoor Unit Product Code | | CB437W04701 | |
| | Compressor Manufacturer | | ZHUHAI LANDA COMPRESSOR CO.,LTD | |
| | Compressor Model | | QXFS-M180zX170 | |
| | Compressor Oil | | / | |
| | Compressor Type | | Rotary | |
| | Compressor LRA. | A | | 24.00 |
| | Compressor RLA | A | | 3.50 |
| | Compressor Power Input | W | | 1350 |
| | Compressor Overload Protector | | | HPC 115/95U1 KSD115°C |
| | Throttling Method | | | Electron expansion valve |
| | Set Temperature Range | °C | | 16~30 |
| | Cooling Operation Ambient Temperature Range | °C | | -15~50 |
| | Heating Operation Ambient Temperature Range | °C | | -15~30 |
| | Condenser Form | | | Aluminum Fin-copper Tube |
| | Condenser Pipe Diameter | mm | | Φ7.94 |
| | Condenser Rows-fin Gap | mm | | 2-1.4 |
| | Condenser Coil Length (LXDXW) | mm | | 934×38.1×616 |
| | Fan Motor Speed | rpm | | 800 |
| | Fan Motor Power Output | W | | 60 |
| | Fan Motor RLA | A | | 0.65 |
| | Fan Motor Capacitor | μF | | / |
| | Outdoor Unit Air Flow Volume | m ³ /h | | 3600 |
| | Fan Type | | | Axial-flow |
| | Fan Diameter | mm | | Φ520 |
| | Defrosting Method | | | Automatic Defrosting |
| | Climate Type | | | T1 |
| | Isolation | | | I |
| | Moisture Protection | | | IPX4 |
| | Permissible Excessive Operating Pressure for the Discharge Side | MPa | | 4.3 |
| | Permissible Excessive Operating Pressure for the Suction Side | MPa | | 2.5 |
| | Sound Pressure Level | dB (A) | | 59 |
| | Sound Power Level | dB (A) | | 70 |
| Dimension(WXHxD) | mm | | 958×660×402 | |
| Dimension of Carton Box (LXWXH) | mm | | 1029×453×715 | |
| Dimension of Package(LXWXH) | mm | | 1032×456×737 | |
| Net Weight | kg | | 45 | |
| Gross Weight | kg | | 49.5 | |
| Refrigerant | | | R32 | |
| Refrigerant Charge | kg | | 1.4 | |
| Connection Pipe | Connection Pipe Length | m | 5 | |
| | Connection Pipe Gas Additional Charge | g/m | 40 | |
| | Outer Diameter Liquid Pipe | | 1/4" | |
| | Outer Diameter Gas Pipe | | 5/8" | |
| | Max Distance Height | m | 10 | |
| | Max Distance Length | m | 25 | |
| Note: The connection pipe applies metric diameter. | | | | |





The above data is subject to change without notice. Please refer to the nameplate of the unit.

2.2 Capacity Variation Ratio According to Temperature

Heating operation ambient temperature range is -25°C~30°C



Heating operation ambient temperature range is -15°C~30°C



2.3 Cooling and Heating Data Sheet in Rated Frequency

Cooling:

| Rated cooling condition(°C) (DB/WB) | | Model | Pressure of gas pipe connecting indoor and outdoor unit | Inlet and outlet pipe temperature of heat exchanger | | Fan speed of indoor unit | Fan speed of outdoor unit |
|-------------------------------------|---------|-------|---|---|---------|--------------------------|---------------------------|
| Indoor | Outdoor | | | P (MPa) | T1 (°C) | | |
| 27/19 | 35/24 | 09K | 0.8~1.1 | 12 ~ 15 | 65 ~ 38 | Super High | High |
| 27/19 | 35/24 | 12K | 0.9~1.1 | 12 ~ 14 | 75 ~ 37 | Super High | High |
| 27/19 | 35/24 | 18K | 0.9~1.1 | 12 ~ 14 | 75 ~ 37 | Super High | High |
| 27/19 | 35/24 | 24K | 0.9~1.1 | 12 ~ 14 | 75 ~ 37 | Super High | High |

Heating:

| Rated heating condition(°C) (DB/WB) | | Model | Pressure of gas pipe connecting indoor and outdoor unit | Inlet and outlet pipe temperature of heat exchanger | | Fan speed of indoor unit | Fan speed of outdoor unit |
|-------------------------------------|---------|-------|---|---|---------|--------------------------|---------------------------|
| Indoor | Outdoor | | | P (MPa) | T1 (°C) | | |
| 20/- | 7/6 | 09K | 2.8~3.2 | 63 ~ 35 | 2 ~ 5 | Super High | High |
| 20/- | 7/6 | 12K | 2.2~2.4 | 70 ~ 35 | 2 ~ 4 | Super High | High |
| 20/- | 7/6 | 18K | 2.2~2.4 | 70 ~ 40 | 1 ~ 5 | Super High | High |
| 20/- | 7/6 | 24K | 2.2~2.4 | 70 ~ 35 | 2 ~ 4 | Super High | High |

Instruction:

T1: Inlet and outlet pipe temperature of evaporator


T2: Inlet and outlet pipe temperature of condenser

P: Pressure at the side of big valve

Connection pipe length: 5 m.

3. Outline Dimension Diagram




3.1 Indoor Unit



| Model (-The first three characters) | W | H | D | W1 | W2 | W3 |
|---|-----|-----|-----|-----|-------|-------|
| AUC | 837 | 293 | 200 | 119 | 542 | 176 |
| AUD | 993 | 311 | 222 | 128 | 707.5 | 157.5 |




3.2 Outdoor Unit

GWH09AUCXB-K6DNA1A/O GWH12AUCXB-K6DNA1A/O




Unit:mm

GWH18AUDXD-K6DNA1A/O GWH12AUCXD-K6DNA1C/O
(The front grill appearance is for reference only)




Unit:mm

GWH18AUDXE-K6DNA1A/O GWH18AUDXE-K6DNA1B/O




GWH24AFE-K6DNA2I/O




4. Refrigerant System Diagram

09K



Connection pipe specification:
 Liquid pipe: 1/4"
 Gas pipe: 3/8"

12/18/24K




Connection pipe specification:
 Liquid pipe: 1/4"
 Gas pipe: 3/8" (09/12K(XB))
 Gas pipe: 1/2" (12K(XD)/18K)
 Gas pipe: 5/8" (24K)

5. Electrical Part

5.1 Wiring Diagram


•Instruction

| Symbol | Symbol Color | Symbol | Symbol Color | Symbol | Name |
|--------|--------------|--------|--------------|---|----------------|
| WH | White | GN | Green | CAP | Jumper cap |
| YE | Yellow | BN | Brown | COMP | Compressor |
| RD | Red | BU | Blue |  | Grounding wire |
| YEGN | Yellow/Green | BK | Black | / | / |
| VT | Violet | OG | Orange | / | / |


Note: Jumper cap is used to determine fan speed and the swing angle of horizontal lover for this model.

• Indoor Unit


09K(except:CB575N00311/CB597N00404)/12K(XB)




18K(XD)/24K(except:CB437N04711/CB597N00304)



09K(CB575N00311/CB597N00404)/12K(XD)






● Outdoor Unit

GWH09AUCXB-K6DNA1A/O

GWH12AUCXB-K6DNA1A/O

GWH12AUCXD-K6DNA1C/O




GWH18AUDXD-K6DNA1A/O

GWH18AUDXE-K6DNA1A/O

GWH18AUDXE-K6DNA1B/O

GWH24AUDXF-K6DNA1A/O



These wiring diagrams are subject to change without notice; please refer to the one supplied with the unit.

5.2 PCB Printed Diagram

Indoor Unit

GWH09AUCXB-K6DNA1A/I(except:CB575N00311/CB597N00404)

GWH24AUDXF-K6DNA1A/I(except:CB437N04711/CB597N00304)

GWH12AUCXB-K6DNA1A/I


GWH18AUDXD-K6DNA1A/I

GWH09AUCXB-K6DNA2A/I

GWH12AUCXB-K6DNA2A/I


GWH18AUDXD-K6DNA2A/I

GWH24AUDXF-K6DNA2A/I



| No. | Name |
|-----|-------------------------|
| 1 | Earthing wire |
| 2 | Live wire |
| 3 | Communication interface |
| 4 | Neutral wire |
| 5 | DC fan |
| 6 | Cold plasma |
| 7 | Ultraviolet clean |
| 8 | Up&down swing 2 |

| No. | Name |
|-----|----------------------------|
| 9 | Up&down swing 1 |
| 10 | Left&right swing |
| 11 | Interface of display board |
| 12 | Interface of WIFI |
| 13 | Temperature sensor |
| 14 | Door control |
| 15 | Wired controller |



| No. | Name |
|-----|-----------------------------------|
| 1 | Neutral Wire Insertion |
| 2 | Fuse |
| 3 | Live Wire Insertion |
| 4 | Earthing Wire Insertion |
| 5 | Communication Wire Insertion |
| 6 | Brushless DC Motor Needle Stand |
| 7 | Ultraviolet cleaning Needle Stand |
| 8 | Health Function Needle Stand |
| 9 | Up & Down Swing Needle Stand 1 |
| 10 | Up & Down Swing Needle Stand 3 |


| No. | Name |
|-----|---------------------------------|
| 11 | Up & Down Swing Needle Stand 2 |
| 12 | Up & Down Swing Needle Stand 4 |
| 13 | Left & Right Swing Needle Stand |
| 14 | Display Board Needle Stand |
| 15 | Fresh air Function Needle Stand |
| 16 | Temperature Sensor Needle Stand |
| 17 | Door Control Needle Stand |
| 18 | Wired Controller Needle Stand |
| 19 | Jumper Needle Stand |

Outdoor Unit


GWH09AUCXB-K6DNA1A/O

GWH12AUCXB-K6DNA1A/O

GWH12AUCXD-K6DNA1C/O




| No. | Name |
|-----|---|
| 1 | Earthing wire |
| 2 | Neutral wire, live wire and communication cable |
| 3 | 4-way valve |
| 4 | Electric heating belt of chassis |
| 5 | Outdoor fan |
| 6 | Electronic expansion valve |
| 7 | Temperature sensor |
| 8 | Three-phase terminal of compressor |



| No. | Name |
|-----|----------------------------------|
| 1 | Earthing wire |
| 2 | Live wire |
| 3 | Neutral wire |
| 4 | communication cable |
| 5 | 4-way valve |
| 6 | Electric heating belt of chassis |
| 7 | DRED-DC(preliminary) |

| No. | Name |
|-----|------------------------------------|
| 8 | Outdoor fan |
| 9 | DRED(preliminary) |
| 10 | Electronic expansion valve |
| 11 | Overload |
| 12 | Temperature sensor |
| 13 | EE flash drive |
| 14 | Three-phase terminal of compressor |



| No. | Name | No. | Name |
|-----|----------------------------------|-----|------------------------------------|
| 1 | Earthing wire | 7 | Outdoor fan |
| 2 | Live wire | 8 | Temperature sensor |
| 3 | Neutral wire | 9 | Overload |
| 4 | communication cable | 10 | Three-phase terminal of compressor |
| 5 | 4-way valve | 11 | Electronic expansion valve |
| 6 | Electric heating belt of chassis | | |

6. Function and Control

6.1 Remote Controller Introduction for YAA1FB18(WiFi)

Introduction for icons on display screen



Introduction for icons on display screen

| | | |
|----------------|--------------------------|-----------|
| | Quiet | |
| | Set fan speed | |
| | Turbo mode | |
| | Send signal | |
| Operation mode | | Auto mode |
| | | Cool mode |
| | | Dry mode |
| | | Fan mode |
| | | Heat mode |
| | X-FAN function | |
| | Humidity control | |
| | Power limiting operation | |
| | Set temperature | |
| | Indoor ambient temp. | |
| | Indoor ambient humidity | |
| | TIMER ON / TIMER OFF | |
| | Left & right swing | |
| | Up & down swing | |
| | Child lock | |
| | Fast cool | |
| | Health and UVC functions | |
| | WiFi function | |
| | LED | |
| | Auto LED | |
| | I feel | |
| | Sleep mode | |

Introduction for buttons on remote controller

NOTE:


- This is a general use remote controller. It could be used for the air conditioner with multifunction. For the functions which the model doesn't have, if press the corresponding button on the remote controller, the unit will keep the original running status.
- After putting through the power, the air conditioner will give out a sound. Power indicator "⏻" is ON. After that, you can operate the air conditioner by using remote controller.
- Under on status, pressing the button on the remote controller, the signal icon "📶" on the display of remote controller will blink once and the air conditioner will give out a "di" sound, which means the signal has been sent to the air conditioner.

ON/OFF button

Press this button to turn on the unit. Press this button again to turn off the unit.

MODE button

Press this button to select your required operation mode.



- When selecting auto mode, air conditioner will operate automatically according to the sensed temperature. Press "FAN" button can adjust fan speed. Press "🌀" / "🌀" button can adjust fan blowing angle.
- After selecting cool mode, air conditioner will operate under cool mode. Press " + " or " - " button to adjust set temperature. Press "FAN" button to adjust fan speed. Press "🌀" / "🌀" button to adjust fan blowing angle.
- When selecting dry mode, the air conditioner operates at low speed under dry mode. Under dry mode, fan speed can't be adjusted. Press "🌀" / "🌀" button to adjust fan blowing angle.
- When selecting fan mode, the air conditioner will only blow fan, no cooling and no heating. Press "FAN" button to adjust fan speed. Press "🌀" / "🌀" button to adjust fan blowing angle.
- When selecting heat mode, the air conditioner operates under heat mode. Press " + " or " - " button to adjust set temperature. Press "FAN" button to adjust fan speed. Press "🌀" / "🌀" button to adjust fan blowing angle.

NOTE:

- For preventing cold air, after starting up heat mode, indoor unit will delay 1~5 minutes to blow air (Actual delay time depends on indoor ambient temperature).
- Set temperature range from remote controller: 16~30°C(61-86°F).
- This mode indicator is not available for some models.
- Cooling only unit won't receive heat mode signal. If setting heat mode with remote controller, press " ON/OFF " button can't start up the unit.

FAST COOL button

Press this button under cooling mode can select 25°C(77°F) fast cooling mode, 16°C(61°F) fast cooling mode and normal cooling mode circularly. " " icon will be displayed on the remote controller under fast cooling mode.

Once it enters into fast cooling mode, the fan speed is auto fan and the set temperature is 25°C(77°F) or 16°C(61°F). At this time, the set temperature flashes to display for 5s. In the flashing period, press " + " or " - " button to adjust the set temperature.

Press "FAN" button to adjust the fan speed. If the set temperature and the fan speed haven't been adjusted during that time, the remote controller and the indoor unit will operate under current set temperature and fan speed for 20 minutes. 20 minutes later, the set temperature and the fan speed for the remote controller and the indoor unit will turn to the status before quick cooling.

NOTE:

- If the set temperature and the fan speed have been adjusted during the operation under fast cooling mode, the unit will exit from the fast cooling mode. Then the indoor unit operates continuously under the adjusted status.
- Fast cooling function is only applicable for some models. If this function is unavailable for this indoor unit, 20 minutes later, the remote controller will turn back to the status before fast cooling. Indoor unit operates continuously according to current status. At this time, status of indoor unit and the display status on the remote controller may be different.
- This function is only available for some models.

I FEEL button

Press this button to start I FEEL function and " " will be displayed on the remote controller. After this function is set, the remote controller will send the detected ambient temperature to the controller and the unit will automatically adjust the indoor temperature according to the detected temperature. Press this button again to turn off I FEEL function and " " will disappear.

- Please put the remote controller near user when this function is set. Do not put the remote controller near the object of high temperature or low temperature in order to avoid detecting inaccurate ambient temperature. When I FEEL function is turned on, the remote controller should be put within the area where indoor unit can receive the signal sent by the remote controller.

AUTO CLEAN button

Under unit off status, press this button to turn on or turn off the auto clean function. When the auto clean function is turned on, indoor unit displays "CL".

During the auto clean process of evaporator, the unit will perform fast cooling or fast heating. There may be some noise, which is the sound of flowing liquid or thermal expansion or cold shrinkage. The air conditioner may blow cool or warm air, which is a normal phenomenon. During cleaning process, please make sure the room is well ventilated to avoid affecting the comfort.

NOTE:


- The auto clean function can only work under normal ambient temperature. If the room is dusty, clean it once a month; if not,

clean it once every three months. After the auto clean function is turned on, you can leave the room. When auto clean is finished, the air conditioner will enter standby status.

- This function is only available for some models.

HEALTH button

Press this button to turn on or turn off the health and UVC functions in operation status.



- When selecting " " with remote controller, Cold Plasma will be turn on.
- When selecting " " with remote controller, UVC sterilization function will be turn on.
- When selecting " " with remote controller, Cold Plasma and UVC sterilization function will be turn on together.

NOTE:

- Health and UVC sterilization are only available for some models.

TEMP HUM. button

By pressing this button, you can see indoor ambient temperature or indoor ambient humidity on indoor unit's display. The setting on remote controller is selected circularly as below:



- When selecting " " with remote controller, temperature indicator on indoor unit displays indoor ambient temperature.
- When selecting " " with remote controller, temperature indicator on indoor unit displays indoor ambient humidity.

TIMER button

- At ON status, press this button once can set TIMER OFF. The character of HOUR and OFF will flash. Press "+" or "-" button within 5s can adjust the time of TIMER ON. After each pressing of "+" or "-" button, time will increase or decrease half an hour. When holding "+" or "-" button, 2s later, the time will change quickly until to reach to your required time. After that, press "TIMER" button to confirm it. The character of HOUR and OFF won't flash again. Cancel TIMER OFF: Press "TIMER" button again under TIMER OFF status.


- At OFF status, press this button once can set TIMER ON. Please refer to TIMER off for detailed operation. Cancel TIMER ON: Press "TIMER" button again under TIMER ON status.

NOTE:

- Time setting range: 0.5-24 hours.
- Time interval between two operations can't exceed 5s. Otherwise, remote controller will exit the setting status automatically.

LIGHT button

Press this button to control the LED status on the display, the circulation change is as follow:



When selecting "☀" (Auto LED) with remote controller, LED indicator on indoor unit will adjust the luminance automatically according to the ambient intensity of illumination.

SLEEP button

Press this button, can select Sleep 1 (☾), Sleep 2 (☾), Sleep 3 (☾) and cancel the Sleep, circulate between these, after electrified, Sleep Cancel is defaulted.

- Sleep 1 is Sleep mode 1, in Cool modes; sleep status after run for one hour, the main unit setting temperature will increase 1, two hours, setting temperature increased 2, then the unit will run at this setting temperature; In Heat mode: sleep status after run for one hour, the setting temperature will decrease 1, two hours, setting temperature will decrease 2, then the unit will run at this setting temperature.

- Sleep 2 is sleep mode 2, that is air conditioner will run according to the presetting a group of sleep temperature curve.

- Sleep 3 the sleep curve setting under Sleep mode by DIY;

(1) Under Sleep 3 mode, press "AUTO CLEAN" button for a long time, remote controller enters into user individuation sleep setting status, at this time, the time of remote controller will display "1hour", the setting temperature "88" will display the corresponding temperature of last setting sleep curve and blink (The first entering will display according to the initial curve setting value of original factory);

(2) Adjust "+" and "-" button, could change the corresponding setting temperature, after adjusted, press "Turbo" button for confirmation;

(3) At this time, 1hour will be automatically increased at the timer position on the remote control, (that are "2hours" or "3hours" or "8hours"), the place of setting temperature "88" will display the corresponding temperature of last setting sleep curve and blink;

(4) Repeat the above step (2)~(3) operation, until 8 hours temperature setting finished, sleep,curvesetting finished, at this time, the remote controller will resume the original timer display; temperature display will resume to original setting temperature.

- Sleep 3 the sleep curve setting under Sleep mode by DIY could be inquired:

The user could accord to sleep curve setting method to inquire the presetting sleep curve, enter into user individuation sleep setting status, but do not change the temperature, press "AUTO CLEAN" button directly for confirmation. Note: In the above presetting or enquiry procedure, if continuously within 10s, there is no button pressed, the sleep curve setting within 10s, there is no button pressed, the sleep curve setting status will be automatically quit and resume to display the original displaying. In the presetting or enquiry procedure, press "ON/OFF" button, "MODE" button, "TIMER" button or "SLEEP" button, the sleep curve setting or enquiry status will quit similarly.

WiFi button

Press "WiFi" button to turn on WiFi function, "WiFi" icon will be displayed on the remote controller;

Hold "WiFi" button for 5s to turn off WiFi function and "WiFi" icon will disappear.

Under off status, press "MODE" and "WiFi" buttons simultaneously for 1s, WiFi module will restore factory settings.

NOTE:

- This function is only available for some models.

Function introduction for combination buttons

Energy-saving function

Under cooling mode, press "TEMP/HUM." and "TIMER" buttons simultaneously to start up or turn off energy-saving function. When energy-saving function is started up, "SE" will be shown on remote controller, and air conditioner will adjust the set temperature automatically according to ex-factory setting to reach to the best energy-saving effect. Press "TEMP/HUM." and "TIMER" buttons simultaneously again to exit energy-saving function.

NOTE:

- Under energy-saving function, fan speed is defaulted at auto speed and it can't be adjusted.

- Under energy-saving function, set temperature can't be adjusted.

- Sleep function and energy-saving function can't operate at the same time. If energy-saving function has been set under cool mode, press "SLEEP" button will cancel energy-saving function. If sleep function has been set under cool mode, start up the energy-saving function will cancel sleep function.

Child lock function

Press "+" and "-" simultaneously to turn on or turn off child lock function. When child lock function is on, "🔒" icon is displayed on remote controller. If you operate the remote controller, the "🔒" icon will blink three times without sending signal to the unit.

Temperature display switchover function

Under OFF status, press "-" and "MODE" buttons simultaneously to switch temperature display between °C and °F.

Volume control of IDU Buzzer

Press "LIGHT" and "MODE" buttons simultaneously to reduce the sound level of the indoor unit' buzzer.

NOTE:

- This function is only available for some models.

Clean reminder function of filter

The reminder function is defaulted to be OFF. Hold TEMP/HUM. button on the remote controller for 5s to turn it on. The buzzer will give out sound for 0.5s and the dual-8 nixie tube on the display will be on for 3s;


Once the reminder function is turned on, when the air conditioner has reached to the set time, the dual-8 nixie tube will flash about 30s when the unit is turned on each time to remind the user to clean the filter; you can turn off this cycle reminder by holding the TEMP/HUM. button on the remote controller for 5s and then the air conditioner will count time again.

NOTE:


- Once the reminder function is turned on, only this cycle reminder can be cleared.

- This function is only available for some models.

function

 function is for limiting power of the whole unit.

Press "SLEEP" and "MODE" buttons simultaneously, the remote controller will circularly display as the following:





- Maximum power limited under the mode is lower than that of mode.
- If you want to cancel the power limiting function, press the button till the icon in remote controller is not displayed.
- When the remote controller is turned off, power limiting function is cancelled. If you want to activate the function, please repress this button.
- If the current power is lower than the maximum power of mode, then the power will not be limited after entering into such mode.
- For the model with one outdoor unit and two indoor units, if any one of indoor units enters into power limiting function, the outdoor unit will enter into the set limiting power mode of indoor unit; when two indoor units enter into power limiting mode, then the power of outdoor unit will be limited according to the lower power of the two indoor units.

NOTE:

- This button is only available for the model with such function.

Replacement of batteries in remote controller



1. Press the back side of remote controller marked with "", as shown in the fig, and then push out the cover of battery box along the arrow direction.
2. Replace two 7# (AAA 1.5V) dry batteries, and make sure the position of "+" polar and "-" polar are correct.
3. Reinstall the cover of battery box.

NOTICE:

- During operation, point the remote control signal sender at the receiving window on indoor unit.
- The distance between signal sender and receiving window should be no more than 8m, and there should be no obstacles between them.
- Signal may be interfered easily in the room where there is fluorescent lamp or wireless telephone; remote controller should be close to indoor unit during operation.
- Replace new batteries of the same model when replacement is required.
- When you don't use remote controller for a long time, please take out the batteries.
- If the display on remote controller is fuzzy or there's no display, please replace batteries.

6.2 Remote Controller Introduction for YBE1F/YBE1F1/YBE1FB2

Introduction for icons on display screen




Introduction for buttons on remote controller

NOTE:

- This is a general use remote controller. It could be used for the air conditioner with multifunction. For the functions which the model doesn't have, if press the corresponding button on the remote controller, the unit will keep the original running status.
- After putting through the power, the air conditioner will give out a sound. Power indicator "⏻" is ON. After that, you can operate the air conditioner by using remote controller.
- Under on status, pressing the button on the remote controller, the signal icon "📶" on the display of remote controller will blink once and the air conditioner will give out a "di" sound, which means the signal has been sent to the air conditioner.

 On/Off button

Press this button to turn on the unit. Press this button again to turn off the unit.

 Mode button

Press this button to select your required operation mode.



- When selecting auto mode, air conditioner will operate automatically according to the sensed temperature. Press "Fan" button can adjust fan speed. Press "🌀" / "🌀" button can adjust fan

blowing angle.

- After selecting cool mode, air conditioner will operate under cool mode. Press " + " or " - " button to adjust set temperature. Press "Fan" button to adjust fan speed. Press "🌀" / "🌀" button to adjust fan blowing angle.

- When selecting dry mode, the air conditioner operates at low speed under dry mode. Under dry mode, fan speed can't be adjusted. Press "🌀" / "🌀" button to adjust fan blowing angle.

- When selecting fan mode, the air conditioner will only blow fan, no cooling and no heating. Press "Fan" button to adjust fan speed. Press "🌀" / "🌀" button to adjust fan blowing angle.

- When selecting heat mode, the air conditioner operates under heat mode. Press " + " or " - " button to adjust set temperature. Press "Fan" button to adjust fan speed. Press "🌀" / "🌀" button to adjust fan blowing angle.

NOTE:

























- For preventing cold air, after starting up heat mode, indoor unit will delay 1~5 minutes to blow air (Actual delay time depends on indoor ambient temperature).

- Set temperature range from remote controller: 16~30°C(61~86°F).

- This mode indicator is not available for some models.


- Cooling LED only unit won't receive heat mode signal. If setting heat mode with remote controller, press " ON/OFF " button can't start up the unit.

Introduction for icons on display screen

| | | |
|---|---|-----------|
|  | Quiet | |
|  | Set fan speed | |
|  | Turbo mode | |
|  | Send signal | |
| Operation mode |  | Auto mode |
| |  | Cool mode |
| |  | Dry mode |
| |  | Fan mode |
| |  | Heat mode |
|  | X-FAN function | |
|  | Humidity control | |
|  | Power limiting operation | |
|  | Set temperature | |
|  | Indoor ambient temp. | |
| | Indoor ambient humidity | |
| ONOFF | TIMER ON / TIMER OFF | |
|  | Set time | |
|  | Left & right swing | |
|  | Up & down swing | |
|  | Child lock | |
|  | Fast cool | |
|  | Health and UVC functions | |
| WIFI | WiFi function | |
|  | LED | |
|  | Auto LED | |
|  | I feel | |
|  | Sleep mode | |

Fan button

This button is used for setting Fan Speed in the sequence that goes from AUTO, , , , , , , to , then back to Auto.



- Low speed
- Low-Medium speed
- Medium speed
- Medium-High speed
- High speed
- Turbo speed
- Quiet speed

NOTE:

- It's low fan speed under dry mode.
- X-FAN function Hold fan speed button for 2s in cool or dry mode, the icon " " is displayed and the indoor fan will continue operation for a few minutes in order to dry the indoor unit even though you have turned off the unit. After energization, X-FAN OFF is defaulted. X-FAN is not available in auto, fan or heat mode.
- This function indicates that moisture on evaporator of indoor unit will be blown after the unit is stopped to avoid mould.
- Having set X-FAN function on: After turning off the unit by pressing " On/Off " button indoor fan will continue running for a few minutes. at low speed. In this period, hold fan speed button for 2s to stop indoor fan directly.
- Having set X-FAN function off: After turning off the unit by pressing " On/Off " button, the complete unit will be off directly.

+ / - button

Press " + " or " - " button once increase or decrease set temperature 1°C(°F). Holding " + " or " - " button, 2s later, set temperature on remote controller will change quickly. On releasing button after setting is finished, temperature indicator on indoor unit will change accordingly.

Wifi button


Press "Wifi" button to turn on WiFi function, "Wifi" icon will be displayed on the remote controller;
Hold "Wifi" button for 5s to turn off WiFi function and "Wifi" icon will disappear.
Under off status, press "Mode" and "Wifi" buttons simultaneously for 1s, WiFi module will restore factory settings.

NOTE:

- This function is only available for some models.

Health button

Press this button to turn on or turn off the health function and UVC lamp in operation status.




- When selecting " " with remote controller, Cold Plasma will be turn on.
- When selecting " " with remote controller, UVC lamp will be turn on.
- When selecting " " with remote controller, Cold Plasma and UVC lamp will be turn on together.

NOTE:

- Health function and UVC lamp are only available for some models.

UD-swing button

Press this button can select up & down swing angle. Fan blow angle can be selected circularly as below:




- When selecting " ", air conditioner is blowing fan automatically. Horizontal louver will automatically swing up & down at maximum angle.
- When selecting " , , , , ", a ir conditioner is blowing fan at fixed position. Horizontal louver will stop at the fixed position.
- Hold " " button above 2s to set your required swing angle. When reaching your required angle, release the button.

NOTE:

- Press this button continuously more than 2s, the main unit will swing back and forth from up to down, and then loosen the button, the unit will stop swinging and present position of guide louver will be kept immediately.
- Under swing up and down mode, when the status is switched from off to , if press this button again 2s later, status will switch to off status directly; if press this button again within 2s, the change of swing status will also depend on the circulation sequence stated above.

Humidity button

Under cooling mode, press this button can select humidity control with cooling mode, smart dehumidification with cooling mode, and general cooling mode, and they can be set to operate circularly.



- When humidity control with cooling mode is set, the remote controller will display " " , and humidity value "88" and "%" icon will blink for 5s; you can press "+" and "-" buttons to set the humidity value within 5s.
- Under humidity control with cooling mode, humidity setting range for the remote controller: 40%-80%.
Temperature can be adjusted under humidity control with cooling mode.
- When smart dehumidification with cooling mode is set, the remote controller will display " " ; the remote controller and indoor unit will display "Ao" for 5 seconds.
Temperature can be adjusted under smart dehumidification with cooling mode.
- The humidity for smart dehumidification is automatically adjusted according to human body comfort; no need to set the humidity manually.
- Under dry mode, press this button can select humidity control with dehumidification mode, continuous dehumidification mode, general dehumidification mode, and they can be set to operate circularly.



- When humidity control with dehumidification mode is set, the remote controller will display "☺", "%", and humidity value "88"; you can press "+" and "-" buttons to set the humidity value. Humidity setting range for the remote controller: 30%-70%. Temperature can't be adjusted under humidity control with dehumidification mode.

- When continuous dehumidification is set, the remote controller will display "☺"; the remote controller and indoor unit will display "Co".

Temperature can't be adjusted under continuous dehumidification mode.


- Under continuous dehumidification mode, the unit always works under dehumidification status; no need to set temperature and humidity.

NOTE:

- The air conditioner is mainly used for controlling the temperature, while the humidity control is the auxiliary function. The humidity will be affected by the factors such as indoor and outdoor environment, degree of indoor sealing and indoor flow.
- When the set humidity is higher than current atmospheric humidity, the set humidity can't be reached.
- If the humidity sensor is with malfunction, humidity setting under cooling mode or dehumidification mode will stop and the unit operates under general cooling mode or dehumidification mode.

LR-swing button

Press this button can select left & right swing angle. Fan blow angle can be selected circularly as below:



NOTE:

- Press this button continuously more than 2s, the main unit will swing back and forth from left to right, and then loosen the button, the unit will stop swinging and present position of guide louver will be kept immediately.
- Under swing left and right mode, when the status is switched from off to , if press this button again 2s later, status will switch to off status directly; if press this button again within 2s, the change of swing status will also depend on the circulation sequence stated above.
- This function only applicable for some models.

Timer button

- At ON status, press this button once can set TIMER OFF. The character of HOUR and OFF will flash. Press "+" or "-" button within 5s can adjust the time of TIMER OFF. After each pressing of "+" or "-" button, time will increase or decrease half an hour. When holding "+" or "-" button, 2s later, the time will change quickly until to reach to your required time. After that, press "Timer" button to confirm it. The character of HOUR and OFF won't flash again. Cancel TIMER OFF: Press "Timer" button again under TIMER

OFF status.

- At OFF status, press this button once can set TIMER ON. Please refer to TIMER off for detailed operation. Cancel TIMER ON: Press "Timer" button again under TIMER ON status.

NOTE:

- Time setting range: 0.5-24 hours.
- Time interval between two operations can't exceed 5s. Otherwise, remote controller will exit the setting status automatically.

Sleep button

Press this button, can select Sleep 1 (☺), Sleep 2 (☺), Sleep 3 (☺) and cancel the Sleep, circulate between these, after electrified, Sleep Cancel is defaulted.

- Sleep 1 is Sleep mode 1, in Cool modes: sleep status after run for one hour, the main unit setting temperature will increase 1, two hours, setting temperature increased 2, then the unit will run at this setting temperature; In Heat mode: sleep status after run for one hour, the setting temperature will decrease 1, two hours, setting temperature will decrease 2, then the unit will run at this setting temperature.
- Sleep 2 is sleep mode 2, that is air conditioner will run according to the presetting a group of sleep temperature curve.
- Sleep 3 the sleep curve setting under Sleep mode by DIY;

(1) Under Sleep 3 mode, press "Health" button for a long time, remote controller enters into user individuation sleep setting status, at this time, the time of remote controller will display "1HOUR", the setting temperature "88" will display the corresponding temperature of last setting sleep curve and blink (The first entering will display according to the initial curve setting value of original factory);

(2) Adjust "+" and "-" button, could change the corresponding setting temperature, after adjusted, press "Health" button for confirmation;

(3) At this time, 1hour will be automatically increased at the timer position on the remote control, (that are "2HOUR" or "3HOUR" or "8HOUR"), the place of setting temperature "88" will display the corresponding temperature of last setting sleep curve and blink;


(4) Repeat the above step (2)~(3) operation, until 8 hours temperature setting finished, sleep,curve setting finished, at this time, the remote controller will resume the original timer display; temperature display will resume to original setting temperature.


- Sleep 3 the sleep curve setting under Sleep mode by DIY could be inquired:

The user could accord to sleep curve setting method to inquire the presetting sleep curve, enter into user individuation sleep setting status, but do not change the temperature, press "Health" button directly for confirmation. Note: In the above presetting or enquiry procedure, if continuously within 10s, there is no button pressed, the sleep curve setting within 10s, there is no button pressed, the sleep curve setting status will be automatically quit and resume to display the original displaying. In the presetting or enquiry procedure, press " On/Off " button, "Mode" button, "Timer" button or "Sleep" button, the sleep curve setting or enquiry status will quit similarly.

Light button

Press this button to control the LED status on the display, the circulation change is as follow:



When selecting "  " (Auto LED) with remote controller, LED indicator on indoor unit will adjust the luminance automatically according to the ambient intensity of illumination.

Function introduction for combination buttons

Energy-saving function



Under cooling mode, press "Mode" and "Timer" buttons simultaneously to start up or turn off energy-saving function. When energy-saving function is started up, "SE" will be shown on remote controller, and air conditioner will adjust the set temperature automatically according to ex-factory setting to reach to the best energy-saving effect.

Press "Mode" and "Timer" buttons simultaneously again to exit energy-saving function.

NOTE:

- Under energy-saving function, fan speed is defaulted at auto speed and it can't be adjusted.
- Under energy-saving function, set temperature can't be adjusted.
- Sleep function and energy-saving function can't operate at the same time. If energy-saving function has been set under cool mode, press "Sleep" button will cancel energy-saving function. If sleep function has been set under cool mode, start up the energy-saving function will cancel sleep function.


Child lock function


Hold " On/Off " and " - " buttons simultaneously for 3s to turn on or turn off child lock function. When child lock function is on, "  " icon is displayed on remote controller. If you operate the remote controller, the "  " icon will blink three times without sending signal to the unit.



Temperature display switchover function

Under OFF status, hold "Mode" and " - " buttons simultaneously for 3s to switch temperature display between °C and °F.


function

 function is for limiting power of the whole unit. Press "Mode" and "Sleep" buttons simultaneously, the remote controller will circularly display as the following:



- Maximum power limited under the  mode is lower than that of  mode.
- If you want to cancel the power limiting function, press "Mode" and "Sleep" buttons simultaneously till the icon in remote controller is not displayed.

• When the remote controller is turned off, power limiting function is cancelled. If you want to activate the function, please repress "Mode" and "Sleep" buttons simultaneously.


• If the current power is lower than the maximum power of  mode, then the power will not be limited after entering into such mode.

• For the model with one outdoor unit and two indoor units, if any one of indoor units enters into power limiting function, the outdoor unit will enter into the set limiting power mode of indoor unit; when two indoor units enter into power limiting mode, then the power of outdoor unit will be limited according to the lower power of the two indoor units.



NOTE:

- This button is only available for the model with such function.

Indoor ambient temperature or humidity display

By holding " On/Off " and "  " buttons simultaneously, you can see indoor ambient temperature or indoor ambient humidity on indoor unit's display. The setting on remote controller is selected circularly as below:





- When selecting "  " with remote controller, temperature indicator on indoor unit displays indoor ambient temperature.
- When selecting "  " with remote controller, temperature indicator on indoor unit displays indoor ambient humidity.

NOTE:

- The ambient humidity value is only for reference. Eg: If humidity value is "0%", there may be malfunction for the humidity detection board. Please contact local service provider.
- There may be some measuring deviation for humidity detection and photosensitiveness detection.


Clean reminder function of filter

The reminder function is defaulted to be OFF. Hold " On/Off " and "  " buttons simultaneously for 5s to turn it on. The buzzer will give out sound for 0.5s and the dual-8 nixie tube on the display will be on for 3s; Once the reminder function is turned on, when the air conditioner has reached to the set time, the dual-8 nixie tube will flash about 30s when the unit is turned on each time to remind the user to clean the filter; you can turn off this cycle reminder by holding " On/Off " and "  " buttons simultaneously for 5s and then the air conditioner will count time again.

NOTE:

- Once the reminder function is turned on, only this cycle reminder can be cleared.
- This function is only available for some models.

Volume control of IDU Buzzer

Press "Mode" and "  " buttons simultaneously to reduce the sound level of the indoor unit' buzzer.

NOTE:

- This function is only available for some models.

Fast cool function

Press " On/Off " and " + " buttons simultaneously under cooling mode can select 25°C(77°F) fast cooling mode, 16°C(61°F) fast cooling mode and normal cooling mode circularly. " " icon will be displayed on the remote controller under fast cooling mode.

Once it enters into fast cooling mode, the fan speed is auto fan and the set temperature is 25°C(77°F) or 16°C(61°F). At this time, the set temperature flashes to display for 5s. In the flashing period, press " + " or " - " button to adjust the set temperature.

Press "Fan" button to adjust the fan speed. If the set temperature and the fan speed haven't been adjusted during that time, the remote controller and the indoor unit will operate under current set temperature and fan speed for 20 minutes. 20 minutes later, the set temperature and the fan speed for the remote controller and the indoor unit will turn to the status before quick cooling.

NOTE:

- If the set temperature and the fan speed have been adjusted during the operation under fast cooling mode, the unit will exit from the fast cooling mode. Then the indoor unit operates continuously under the adjusted status.
- Fast cooling function is only applicable for some models. If this function is unavailable for this indoor unit, 20 minutes later, the remote controller will turn back to the status before fast cooling. Indoor unit operates continuously according to current status. At this time, status of indoor unit and the display status on the remote controller may be different.
- This function is only available for some models.

Auto clean function

Under unit off status, hold "Mode" and " " buttons simultaneously for 5s to turn on or turn off the auto clean function. When the auto clean function is turned on, indoor unit displays "CL" . During the auto clean process of evaporator, the unit will perform fast cooling or fast heating. There may be some noise, which is the sound of flowing liquid or thermal expansion or cold shrinkage. The air conditioner may blow cool or warm air, which is a normal phenomenon. During cleaning process, please make sure the room is well ventilated to avoid affecting the comfort.

NOTE:

- The auto clean function can only work under normal ambient temperature. If the room is dusty, clean it once a month; if not, clean it once every three months. After the auto clean function is turned on, you can leave the room. When auto clean is finished, the air conditioner will enter standby status.
- This function is only available for some models.

Night mode

Under cooling or heating mode, when turning on sleep mode and turn to low speed or quiet notch, the outdoor unit would enter into night mode.

NOTE:


- When you feel that the cooling and heating effect is poor, please press "Fan" button to other fan speed or press "Sleep" button to exit the night mode.
- The night mode can only work under normal ambient temperature.
- This function is only available for some models.

I FEEL function

Press "Health" and " + " buttons simultaneously to start I FEEL function and " " will be displayed on the remote controller. After this function is set, the remote controller will send the detected ambient temperature to the controller and the unit will automatically adjust the indoor temperature according to the detected temperature. Press "Health" and " + " buttons simultaneously again to turn off I FEEL function and " " will disappear.

- Please put the remote controller near user when this function is set. Do not put the remote controller near the object of high temperature or low temperature in order to avoid detecting inaccurate ambient temperature. When I FEEL function is turned on, the remote controller should be put within the area where indoor unit can receive the signal sent by the remote controller.

Replacement of batteries in remote controller




1. Press the back side of remote controller marked with " " , as shown in the fig, and then push out the cover of battery box along the arrow direction.
2. Replace two 7# (AAA 1.5V) dry batteries, and make sure the position of "+" polar and "-" polar are correct.
3. Reinstall the cover of battery box.

NOTICE:

- During operation, point the remote control signal sender at the receiving window on indoor unit.
- The distance between signal sender and receiving window should be no more than 8m, and there should be no obstacles between them.
- Signal may be interfered easily in the room where there is fluorescent lamp or wireless telephone; remote controller should be close to indoor unit during operation.
- Replace new batteries of the same model when replacement is required.
- When you don't use remote controller for a long time, please take out the batteries.
- If the display on remote controller is fuzzy or there's no display, please replace batteries.

6.3 GREE+ App Operation Manual

Control Flow Chart



Operating Systems

Requirement for User's smart phone:



iOS system
Support iOS7.0 and
above version



Android system
Support Android 4.4 and
above version

Download and installation




GREE+ App Download Linkage

Scan the QR code or search "GREE+" in the application market to download and install it. When "GREE+" App is installed, register the account and add the device to achieve long-distance control and LAN control of Gree smart home appliances. For more information, please refer to "Help" in App.

6.4 Ewpe Smart App Operation Manual

Control Flow Chart



Operating Systems

Requirement for User's smart phone:



iOS system
Support iOS7.0 and
above version



Android system
Support Android 4.4 and
above version

Download and installation



App Download Linkage

Scan the QR code or search "Ewpe Smart" in the application market to download and install it. When "Ewpe Smart" App is installed, register the account and add the device to achieve long-distance control and LAN control of smart home appliances. For more information, please refer to "Help" in App.

6.5 Brief Description of Models and Functions

●Indoor Unit

1.Basic function of system

(1)Cooling mode

(1) Under this mode, fan and swing operates at setting status. Temperature setting range is 16~30°C.

(2) During malfunction of outdoor unit or the unit is stopped because of protection, indoor unit keeps original operation status.

(2)Drying mode

(1) Under this mode, fan operates at low speed and swing operates at setting status. Temperature setting range is 16~30°C.

(2) During malfunction of outdoor unit or the unit is stopped because of protection, indoor unit keeps original operation status.

(3) Protection status is same as that under cooling mode.

(4) Sleep function is not available for drying mode.

(3)Heating mode

(1) Under this mode, Temperature setting range is 16~30°C.

(2) Working condition and process for heating mode:

When turn on the unit under heating mode, indoor unit enters into cold air prevention status. When the unit is stopped or at OFF status, and indoor unit has been started up just now, the unit enters into residual heat-blowing status.

(4)Working method for AUTO mode:

1.Working condition and process for AUTO mode:

a.Under AUTO mode, standard heating $T_{\text{preset}}=20^{\circ}\text{C}$ and standard cooling $T_{\text{preset}}=25^{\circ}\text{C}$. The unit will switch mode automatically according to ambient temperature.

2.Protection function

a. During cooling operation, protection function is same as that under cooling mode.

b. During heating operation, protection function is same as that under heating mode.

3. Display: Set temperature is the set value under each condition. Ambient temperature is ($T_{\text{amb.}} - T_{\text{compensation}}$) for heat pump unit and $T_{\text{amb.}}$ for cooling only unit.

4. If theres I feel function, $T_{\text{compensation}}$ is 0. Others are same as above.

(5)Fan mode

Under this mode, indoor fan operates at set fan speed. Compressor, outdoor fan, 4-way valve and electric heating tube stop operation. Indoor fan can select to operate at high, medium, low or auto fan speed. Temperature setting range is 16~30°C.

2. Other control

(1) Buzzer

Upon energization or availably operating the unit or remote controller, the buzzer will give out a beep.

(2) Auto button

If press this auto button when turning off the unit, the complete unit will operate at auto mode. Indoor fan operates at auto fan speed and swing function is turned on. Press this auto button at ON status to turn off the unit.

(3) Auto fan

Heating mode: During auto heating mode or normal heating ode, auto fan speed will adjust the fan speed automatically according to ambient temperature and set temperature.

(4) Sleep

After setting sleep function for a period of time, system will adjust set temperature automatically.

(5) Timer function:

General timer and clock timer functions are compatible by equipping remote controller with different functions.

(6) Memory function

memorize compensation temperature, off-peak energization value. Memory content: mode, up&down swing, light, set temperature, set fan speed, general timer (clock timer can't be memorized).

After power recovery, the unit will be turned on automatically according to memory content.

(7) Health function

During operation of indoor fan, set health function by remote controller. Turn off the unit will also turn off health function.

Turn on the unit by pressing auto button, and the health is defaulted ON.

(8)I feel control mode

After controller received I feel control signal and ambient temperature sent by remote controller, controller will work according to the ambient temperature sent by remote controller.

(9)Entry condition for compulsory defrosting function

When turn on the unit under heating ode and set temperature is 16°C (or 16.5°C by remote controller), press "+, -, +, -, +, -"button successively within 5s and then indoor unit will enter into compulsory defrosting setting status:

(1) If theres only indoor units controller, it enters into indoor normal defrosting mode.

(2) If theres indoor units controller and outdoor units controller, indoor unit will send compulsory defrosting mode signal to outdoor unit and then outdoor unit will operate under normal defrosting mode. After indoor unit received the signal that outdoor unit has entered into defrosting status, indoor unit will cancel to send compulsory mode to outdoor unit. If outdoor unit hasn't received feedback signal from outdoor unit after 3min, indoor unit will also cancel to send compulsory defrosting signal.

(10)Refrigerant recovery function:

Enter into Freon recovery mode actively: Within 5min after energization, turn on the unit at 16°C under cooling mode, and press light button for 3 times within 3s to enter into Freon recovery mode. Fo is displayed and Freon recovery mode will be sent to outdoor unit.

(11)Ambient temperature display control mode

1. When user set the remote controller to display set temperature (corresponding remote control code: 01), current set temperature will be displayed.

2. Only when remote control signal is switched to indoor ambient temperature display status (corresponding remote control code: 10) from other display status (corresponding remote control code: 00, 01,11),controller will display indoor ambient temperature for 3s and then turn back to display set temperature.

Under this mode, indoor fan operates at set fan speed. Compressor, outdoor fan, 4-way valve and electric heating tube stop operation. Indoor fan can select to operate at high, medium, low or auto fan speed. Temperature setting range is 16~30°C.

(12)Off-peak energization function:

Adjust compressors minimum stop time. The original minimum stop time is 180s and then we change to:

The time interval between two start-ups of compressor can't be less than $180+T_s(0\leq T_s\leq 15)$. T is the variable of controller. Thats to say the minimum stop time of compressor is 180s~195s. Read-in T into memory chip when refurbish the memory chip each time.

After power recovery, compressor can only be started up after $180+T$ s at least.

(13) SE control mode

The unit operates at SE status.

(14) X-fan mode

When X-fan function is turned on, after turn off the unit, indoor fan will still operate at low speed for 2min and then the complete unit will be turned off. When x-fan function is turned off, after turn off the unit, the complete unit will be turned off directly.

(15) 8°C heating function

Under heating mode, you can set 8°C heating function by remote controller. The system will operate at 8°C set temperature.

(16) Turbo function

Turbo function can be set under cooling and heating modes. Press Fan Speed button to cancel turbo setting. Turbo function is not available under auto, drying and fan modes.

●Outdoor Unit

1. Cooling mode:

Working condition and process of cooling mode:

① When $T_{\text{indoor ambient temperature}} \geq T_{\text{preset}}$, unit enters into cooling mode. Indoor fan, outdoor fan and compressor start operation. Indoor fan operates according to set fan speed.

② When $T_{\text{indoor ambient temperature}} \leq T_{\text{preset}} - 2^{\circ}\text{C}$, compressor stops operation and outdoor fan will stop 30s later. Indoor fan operates according to set fan speed.

③ When $T_{\text{preset}} - 2^{\circ}\text{C} < T_{\text{indoor ambient temperature}} < T_{\text{preset}}$, unit operates according to the previous status.

Under cooling mode, 4-way valve is not energized. Temperature setting range is 16~30°C. If compressor stops because of malfunction in cooling mode, indoor fan and swing motor will work according to the original status.

2. Drying mode

(1) Working condition and process of drying mode

① When $T_{\text{indoor ambient temperature}} > T_{\text{preset}}$, unit will be in drying mode. Outdoor fan and compressor start operation while indoor fan will operate at low fan speed.

② When $T_{\text{preset}} - 2^{\circ}\text{C} \leq T_{\text{indoor ambient temperature}} \leq T_{\text{preset}}$, unit operates according to the previous status.

③ When $T_{\text{indoor ambient temperature}} < T_{\text{preset}} - 2^{\circ}\text{C}$, compressor stops operation and outdoor fan will stop 30s later.

(2) Under drying mode, 4-way valve is not energized. Temperature setting range is 16~30°C.

(3) Protection function: same as in cooling mode.

3. Fan mode

(1) Under this mode, indoor fan can select different fan speed (except Turbo) or auto fan speed. Compressor, outdoor fan and 4-way valve all stop operation.

(2) In fan mode, temperature setting range is 16~30°C.

4. Heating mode

Working condition and process of heating mode:

① When $T_{\text{preset}} - (T_{\text{indoor ambient temperature}} - T_{\text{compensation}}) \geq 1^{\circ}\text{C}$, unit enters into heating mode. Compressor, outdoor fan and 4-way valve start operation.

② When $-2^{\circ}\text{C} < T_{\text{preset}} - (T_{\text{indoor ambient temperature}} - T_{\text{compensation}}) < 1^{\circ}\text{C}$, unit operates according to the previous status.

③ When $T_{\text{preset}} - (T_{\text{indoor ambient temperature}} - T_{\text{compensation}}) \leq -2^{\circ}\text{C}$, compressor

stops operation and outdoor fan will stop 30s later. Indoor fan will be in residual-heat blowing status.

④ When unit is turned off under heating mode or changed to other modes from heating mode, 4-way valve will be power-off 2min after compressor stops working (compressor is in operation status under heating mode).

⑤ When $T_{\text{outdoor ambient temperature}} > 30^{\circ}\text{C}$, compressor stops operation immediately. Outdoor fan will stop 30s later.

⑥ Under the condition that compressor is turned on, when unit is changed to heating mode from cooling or drying mode, 4-way valve will be energized in 2~3mins delay.

Note: Tcompensation is determined by IDU and ODU. If IDU controls the compensation temperature, then Tcompensation is determined according to the value sent by IDU to ODU; If IDU does not control the compensation temperature, then Tcompensation will default to 3°C by the ODU.

5. Freon recovery mode

After the Freon recovery signal from IDU is received, cooling at rated frequency will be forcibly turned on to recover Freon.

Indoor unit will display Fo. If any signal from remote controller is received, unit will exit from Freon recovery mode and indoor unit stops displaying Fo.

6. Compulsory defrosting

If unit is turned on under heating mode and set temperature is 16°C (by remote controller), press "+, -, +, -, +, -" within 5s, unit will enter into compulsory defrosting mode and send the signal to ODU. When the compulsory defrosting signal from ODU is received, IDU will exit from the compulsory defrosting mode and stop sending the signal to ODU.

After ODU receives the compulsory defrosting code, it will start compulsory defrosting. Defrosting frequency and opening angle will be the same as in normal defrosting mode. When compulsory defrosting is finished, the complete unit resumes original status.

7. Auto mode

Auto mode is determined by controller of IDU. See IDU logic for details.

8. 8°C heating

Set temperature is 8°C. Display board of IDU displays 8°C. Under this mode, "Cold air prevention" function is shielded.

If compressor is operating under this mode, fan speed will adjust according to auto fan speed; if compressor stops operation under this mode, indoor fan will be in residual-heat blowing status.

When power on, communication light will be blinking in a normal way (after receiving a group of correct signals, blinking stops for 0.2s~0.3s). If there's no communication, communication light will be always on. If other ODU has malfunction, communication light will be on for 1s and off for 1s in a circular way.

7. Notes for Installation and Maintenance

Safety Precautions: Important!

Please read the safety precautions carefully before installation and maintenance.

The following contents are very important for installation and maintenance.

Please follow the instructions below.

- The installation or maintenance must accord with the instructions.
- Comply with all national electrical codes and local electrical codes.
- Pay attention to the warnings and cautions in this manual.
- All installation and maintenance shall be performed by distributor or qualified person.
- All electric work must be performed by a licensed technician according to local regulations and the instructions given in this manual.
- Be caution during installation and maintenance. Prohibit incorrect operation to prevent electric shock, casualty and other accidents.

WARNINGS

Electrical Safety Precautions:

1. Cut off the power supply of air conditioner before checking and maintenance.
2. The air condition must apply specialized circuit and prohibit share the same circuit with other appliances.
3. The air conditioner should be installed in suitable location and ensure the power plug is touchable.
4. Make sure each wiring terminal is connected firmly during installation and maintenance.
5. Have the unit adequately grounded. The grounding wire can't be used for other purposes.
6. Must apply protective accessories such as protective boards, cable-cross loop and wire clip.
7. The live wire, neutral wire and grounding wire of power supply must be corresponding to the live wire, neutral wire and grounding wire of the air conditioner.
8. The power cord and power connection wires can't be pressed by hard objects.
9. If power cord or connection wire is broken, it must be replaced by a qualified person.
10. If the power cord or connection wire is not long enough, please get the specialized power cord or connection wire from the manufacture or distributor. Prohibit prolong the wire by yourself.
11. For the air conditioner without plug, an air switch must be installed in the circuit. The air switch should be all-pole parting and the contact parting distance should be more than 3mm.

12. Make sure all wires and pipes are connected properly and the valves are opened before energizing.
13. Check if there is electric leakage on the unit body. If yes, please eliminate the electric leakage.
14. Replace the fuse with a new one of the same specification if it is burnt down; don't replace it with a cooper wire or conducting wire.
15. If the unit is to be installed in a humid place, the circuit breaker must be installed.

Installation Safety Precautions:

1. Select the installation location according to the requirement of this manual.(See the requirements in installation part)
2. Handle unit transportation with care; the unit should not be carried by only one person if it is more than 20kg.
3. When installing the indoor unit and outdoor unit, a sufficient fixing bolt must be installed; make sure the installation support is firm.
4. Ware safety belt if the height of working is above 2m.
5. Use equipped components or appointed components during installation.
6. Make sure no foreign objects are left in the unit after finishing installation.

Refrigerant Safety Precautions:

1. When refrigerant leaks or requires discharge during installation, maintenance, or disassembly, it should be handled by certified professionals or otherwise in compliance with local laws and regulations.
- 2.Avoid contact between refrigerant and fire as it generates poisonous gas; Prohibit prolong the connection pipe by welding.
3. Apply specified refrigerant only. Never have it mixed with any other refrigerant. Never have air remain in the refrigerant line as it may lead to rupture or other hazards.
4. Make sure no refrigerant gas is leaking out when installation is completed.
5. If there is refrigerant leakage, please take sufficient measure to minimize the density of refrigerant.
6. Never touch the refrigerant piping or compressor without wearing glove to avoid scald or frostbite.

Improper installation may lead to fire hazard, explosion, electric shock or injury.

Safety Precautions for Installing and Relocating the Unit:

To ensure safety, please be mindful of the following precautions.

WARNINGS

1. When installing or relocating the unit, be sure to keep the refrigerant circuit free from air or substances other than the specified refrigerant.

Any presence of air or other foreign substance in the refrigerant circuit will cause system pressure rise or compressor rupture, resulting in injury.

2. When installing or moving this unit, do not charge the refrigerant which is not comply with that on the nameplate or unqualified refrigerant.

Otherwise, it may cause abnormal operation, wrong action, mechanical malfunction or even series safety accident.

3. When refrigerant needs to be recovered during relocating or repairing the unit, be sure that the unit is running in cooling mode. Then, fully close the valve at high pressure side (liquid valve). About 30-40 seconds later, fully close the valve at low pressure side (gas valve), immediately stop the unit and disconnect power. Please note that the time for refrigerant recovery should not exceed 1 minute.

If refrigerant recovery takes too much time, air may be sucked in and cause pressure rise or compressor rupture, resulting in injury.

4. During refrigerant recovery, make sure that liquid valve and gas valve are fully closed and power is disconnected before detaching the connection pipe.

If compressor starts running when stop valve is open and connection pipe is not yet connected, air will be sucked in and cause pressure rise or compressor rupture, resulting in injury.

5. When installing the unit, make sure that connection pipe is securely connected before the compressor starts running.

If compressor starts running when stop valve is open and connection pipe is not yet connected, air will be sucked in and cause pressure rise or compressor rupture, resulting in injury.

6. Prohibit installing the unit at the place where there may be leaked corrosive gas or flammable gas.

If there leaked gas around the unit, it may cause explosion and other accidents.

7. Do not use extension cords for electrical connections. If the electric wire is not long enough, please contact a local service center authorized and ask for a proper electric wire.

Poor connections may lead to electric shock or fire.

8. Use the specified types of wires for electrical connections between the indoor and outdoor units. Firmly clamp the wires so that their terminals receive no external stresses.

Electric wires with insufficient capacity, wrong wire connections and insecure wire terminals may cause electric shock or fire.

Safety Precautions for Refrigerant

- To realize the function of the air conditioner unit, a special refrigerant circulates in the system. The used refrigerant is the fluoride R32, which is specially cleaned. The refrigerant is flammable and inodorous. Furthermore, it can lead to explosion under certain conditions. But the flammability of the refrigerant is very low. It can be ignited only by fire.
- Compared to common refrigerants, R32 is a nonpolluting refrigerant with no harm to the ozonosphere. The influence upon the greenhouse effect is also lower. R32 has got very good thermodynamic features which lead to a really high energy efficiency. The units there fore need a less filling.

WARNING:

Do not use means to accelerate the defrosting process or to clean, other than those recommended by the manufacture. Should repair be necessary, contact your nearest authorized Service Centre. Any repairs carried out by unqualified personnel may be dangerous. The appliance shall be stored in a room without continuously operating ignition sources. (for example: open flames, an operating gas appliance or an operating electric heater.) Do not pierce or burn.

Appliance shall be installed, operated and stored in a room with a floor area larger than Xm^2 . (Please refer to table "a" in section of " Safety operation of flammable refrigerant " for space X.)

Appliance filled with flammable gas R32.

For repairs, strictly follow manufacturer's instructions only. Be aware that refrigerants may not contain an odour. Read specialist's manual.



Safety Operation of Flammable Refrigerant

Qualification requirement for installation and maintenance man

- All the work men who are engaging in the refrigeration system should bear the valid certification awarded by the authoritative organization and the qualification for dealing with the refrigeration system recognized by this industry. If it needs other technician to maintain and repair the appliance, they should be supervised by the person who bears the qualification for using the flammable refrigerant.
- It can only be repaired by the method suggested by the equipment's manufacturer.

Installation notes

- The air conditioner must be installed in a room that is larger

than the minimum room area. The minimum room area is shown on the nameplate or following table a.

- It is not allowed to drill hole or burn the connection pipe.
- Leak test is a must after installation.

table a - Minimum room area (m^2)

| Charge amount (kg) | Floor location | Window mounted | Wall mounted | Ceiling mounted |
|--------------------|----------------|----------------|--------------|-----------------|
| ≤1.2 | 4 | 4 | 4 | 4 |
| 1.3 | 14.5 | 5.2 | 4 | 4 |
| 1.4 | 16.8 | 6.1 | 4 | 4 |
| 1.5 | 19.3 | 7 | 4 | 4 |
| 1.6 | 22 | 7.9 | 4 | 4 |
| 1.7 | 24.8 | 8.9 | 4 | 4 |
| 1.8 | 27.8 | 10 | 4 | 4 |
| 1.9 | 31 | 11.2 | 4 | 4 |
| 2.0 | 34.3 | 12.4 | 4 | 4 |
| 2.1 | 37.8 | 13.6 | 4.2 | 4 |
| 2.2 | 41.5 | 15 | 4.6 | 4 |
| 2.3 | 45.4 | 16.3 | 5 | 4 |
| 2.4 | 49.4 | 17.8 | 5.5 | 4 |
| 2.5 | 53.6 | 19.3 | 6 | 4 |

Maintenance notes

- Check whether the maintenance area or the room area meet the requirement of the nameplate.
 - It's only allowed to be operated in the rooms that meet the requirement of the nameplate.
- Check whether the maintenance area is wellventilated.
 - The continuous ventilation status should be kept during the operation process.
- Check whether there is fire source or potential fire source in the maintenance area.
 - The naked flame is prohibited in the maintenance area; and the "no smoking" warning board should be hanged.
- Check whether the appliance mark is in good condition.
 - Replace the vague or damaged warning mark.

Welding

- If you should cut or weld the refrigerant system pipes in the process of maintaining, please follow the steps as below:
 - a. Shut down the unit and cut power supply
 - b. Eliminate the refrigerant
 - c. Vacuuming
 - d. Clean it with N_2 gas
 - e. Cutting or welding
 - f. Carry back to the service spot for welding
 - The refrigerant should be recycled into the specialized storage tank.
 - Make sure that there isn't any naked flame near the outlet of the vacuum pump and it's wellventilated.

Filling the refrigerant

- Use the refrigerant filling appliances specialized for R32. Make sure that different kinds of refrigerant won't contaminate with each other.
- The refrigerant tank should be kept upright at the time of filling refrigerant.
- Stick the label on the system after filling is finished (or haven't finished).
- Don't overfilling.
- After filling is finished, please do the leakage detection before test running; another time of leak detection should be done when it's removed.

Safety instructions for transportation and storage

- Please use the flammable gas detector to check before unload and open the container.
- No fire source and smoking.
- According to the local rules and laws.

Specialist's Manual

- The following checks shall be applied to installations using flammable refrigerants:
 - the charge size is in accordance with the room size within which the refrigerant containing parts are installed;
 - the ventilation machinery and outlets are operating adequately and are not obstructed;
 - if an indirect refrigerating circuit is being used, the secondary circuit shall be checked for the presence of refrigerant;
 - marking to the equipment continues to be visible and legible. Markings and signs that are illegible shall be corrected;
 - refrigeration pipe or components are installed in a position where they are unlikely to be exposed to any substance which may corrode refrigerant containing components, unless the components are constructed of materials which are inherently resistant to being corroded or are suitably protected against being so corroded.
- Repair and maintenance to electrical components shall include initial safety checks and component inspection procedures. If a fault exists that could compromise safety, then no electrical supply shall be connected to the circuit until it is satisfactorily dealt with. If the fault cannot be corrected immediately but it is necessary to continue operation, an adequate temporary solution shall be used. This shall be reported to the owner of the equipment so all parties are advised.
- Initial safety checks shall include:
 - that capacitors are discharged: this shall be done in a safe manner to avoid possibility of sparking;
 - that no live electrical components and wiring are exposed while charging, recovering or purging the system;
 - that there is continuity of earth bonding.
- Checking for presence of refrigerant
The area shall be checked with an appropriate refrigerant detector prior to and during work, to ensure the technician is aware of potentially toxic or flammable atmospheres. Ensure that the leak detection equipment being used is suitable for use with all applicable refrigerants, i.e. non-sparking, adequately sealed or intrinsically safe.
- Presence of fire extinguisher
If any hot work is to be conducted on the refrigeration equipment or any associated parts, appropriate fire extinguishing equipment shall be available to hand. Have a dry powder or CO2 fire

extinguisher adjacent to the charging area.

- Ventilated area
Ensure that the area is in the open or that it is adequately ventilated before breaking into the system or conducting any hot work. A degree of ventilation shall continue during the period that the work is carried out. The ventilation should safely disperse any released refrigerant and preferably expel it externally into the atmosphere.
 - Checks to the refrigeration equipment
Where electrical components are being changed, they shall be fit for the purpose and to the correct specification. At all times the manufacturer's maintenance and service guidelines shall be followed. If in doubt, consult the manufacturer's technical department for assistance.
 - Checks to electrical devices
 - that capacitors are discharged: this shall be done in a safe manner to avoid possibility of sparking;
 - that no live electrical components and wiring are exposed while charging, recovering or purging the system.
 - Repairs to sealed components
During repairs to sealed components, all electrical supplies shall be disconnected from the equipment being worked upon prior to any removal of sealed covers, etc. If it is absolutely necessary to have an electrical supply to equipment during servicing, then a permanently operating form of leak detection shall be located at the most critical point to warn of a potentially hazardous situation. Particular attention shall be paid to the following to ensure that by working on electrical components, the casing is not altered in such a way that the level of protection is affected. This shall include damage to cables, excessive number of connections, terminals not made to original specification, damage to seals, incorrect fitting of glands, etc.
 - Ensure that the apparatus is mounted securely.
 - Ensure that seals or sealing materials have not degraded to the point that they no longer serve the purpose of preventing the ingress of flammable atmospheres. Replacement parts shall be in accordance with the manufacturer's specifications.
- NOTE: The use of silicon sealant can inhibit the effectiveness of some types of leak detection equipment. Intrinsically safe components do not have to be isolated prior to working on them.
- Repair to intrinsically safe components
Do not apply any permanent inductive or capacitance loads to the circuit without ensuring that this will not exceed the permissible voltage and current permitted for the equipment in use. Intrinsically safe components are the only types that can be worked on while live in the presence of a flammable atmosphere. The test apparatus shall be at the correct rating. Replace components only with parts specified by the manufacturer. Other parts may result in the ignition of refrigerant in the atmosphere from a leak.
 - Cabling
Check that cabling will not be subject to wear, corrosion, excessive pressure, vibration, sharp edges or any other adverse environmental effects. The check shall also take into account the effects of aging or continual vibration from sources such as compressors or fans.
 - Detection of flammable refrigerants
Under no circumstances shall potential sources of ignition be used in the searching for or detection of refrigerant leaks. A halide torch (or any other detector using a naked flame) shall not be used.
 - Leak detection methods
Leak detection fluids are suitable for use with most refrigerants but the use of detergents containing chlorine shall be avoided as the chlorine may react with the refrigerant and corrode the copper

pipe-work.

- Decommissioning

Before carrying out this procedure, it is essential that the technician is completely familiar with the equipment and all its detail. It is recommended good practice that all refrigerants are recovered safely. Prior to the task being carried out, an oil and refrigerant sample shall be taken in case analysis is required prior to re-use of reclaimed refrigerant. It is essential that electrical power is available before the task is commenced.

- Become familiar with the equipment and its operation.
- Isolate system electrically.
- Before attempting the procedure, ensure that:
 - mechanical handling equipment is available, if required, for handling refrigerant cylinders;
 - all personal protective equipment is available and being used correctly;
 - the recovery process is supervised at all times by a competent person;
 - recovery equipment and cylinders conform to the appropriate standards.
- Pump down refrigerant system, if possible.
- If a vacuum is not possible, make a manifold so that refrigerant can be removed from various parts of the system.
- Make sure that cylinder is situated on the scales before recovery takes place.
- Start the recovery machine and operate in accordance with manufacturer's instructions.
- Do not overfill cylinders. (No more than 80% volume liquid charge).
- Do not exceed the maximum working pressure of the cylinder, even temporarily.
- When the cylinders have been filled correctly and the process completed, make sure that the cylinders and the equipment are removed from site promptly and all isolation valves on the equipment are closed off.
- Recovered refrigerant shall not be charged into another refrigeration system unless it has been cleaned and checked.

- Labelling

Equipment shall be labelled stating that it has been decommissioned and emptied of refrigerant. The label shall be dated

and signed. For appliances containing flammable refrigerants, ensure that there are labels on the equipment stating the equipment contains flammable refrigerant.

- Recovery

When removing refrigerant from a system, either for servicing or decommissioning, it is recommended good practice that all refrigerants are removed safely.

When transferring refrigerant into cylinders, ensure that only appropriate refrigerant recovery cylinders are employed. Ensure that the correct number of cylinders for holding the total system charge are available.

All cylinders to be used are designated for the recovered refrigerant and labelled for that refrigerant (i.e. special cylinders for the recovery of refrigerant).

Cylinders shall be complete with pressure-relief valve and associated shut-off valves in good working order. Empty recovery cylinders are evacuated and, if possible, cooled before recovery occurs.

The recovery equipment shall be in good working order with a set of instructions concerning the equipment that is at hand and shall be suitable for the recovery of all appropriate refrigerants including, when applicable, flammable refrigerants. In addition, a set of calibrated weighing scales shall be available and in good working order. Hoses shall be complete with leak-free disconnect couplings and in good condition. Before using the recovery machine, check that it is in satisfactory working order, has been properly maintained and that any associated electrical components are sealed to prevent ignition in the event of a refrigerant release. Consult manufacturer if in doubt.

The recovered refrigerant shall be returned to the refrigerant supplier in the correct recovery cylinder, and the relevant waste transfer note arranged. Do not mix refrigerants in recovery units and especially not in cylinders.

If compressors or compressor oils are to be removed, ensure that they have been evacuated to an acceptable level to make certain that flammable refrigerant does not remain within the lubricant. The evacuation process shall be carried out prior to returning the compressor to the suppliers. Only electric heating to the compressor body shall be employed to accelerate this process. When oil is drained from a system, it shall be carried out safely.

Main Tools for Installation and Maintenance



Level meter



Measuring tape



Screw driver



Impact drill



Drill head



Electric drill



Electroprobe



Universal meter



Torque wrench



Open-end wrench



Inner hexagon spanner



Electronic leakage detector



Vacuum pump



Pressure meter



Pipe pliers



Pipe pliers



Pipe cutter



Pipe expander



Pipe bender



Soldering appliance




Refrigerant container




Electronic scale

8. Installation

8.1 Installation Dimension Diagram



Installation Procedures



Note: this flow is only for reference; please find the more detailed installation steps in this section.

8.2 Installation Parts-checking

| No. | Name |
|-----|---|
| 1 | Indoor unit |
| 2 | Outdoor unit |
| 3 | Connection pipe |
| 4 | Drainage pipe |
| 5 | Wall-mounting frame |
| 6 | Connecting cable(power cord) |
| 7 | Wall pipe |
| 8 | Sealing gum |
| 9 | Wrapping tape |
| 10 | Support of outdoor unit |
| 11 | Fixing screw |
| 12 | Drainage plug(cooling and heating unit) |
| 13 | Owners manual, remote controller |

⚠ Note:

- 1.Please contact the local agent for installation.
- 2.Don't use unqualified power cord.

8.3 Selection of Installation Location

1. Basic Requirement:

Installing the unit in the following places may cause malfunction. If it is unavoidable, please consult the local dealer:

- (1) The place with strong heat sources, vapors, flammable or explosive gas, or volatile objects spread in the air.
- (2) The place with high-frequency devices (such as welding machine, medical equipment).
- (3) The place near coast area.
- (4) The place with oil or fumes in the air.
- (5) The place with sulfured gas.
- (6) Other places with special circumstances.
- (7) The appliance shall not be installed in the laundry.
- (8) It's not allowed to be installed on the unstable or motive base structure(such as truck) or in the corrosive environment (such as chemical factory).

2. Indoor Unit:

- (1) There should be no obstruction near air inlet and air outlet.
- (2) Select a location where the condensation water can be dispersed easily and won't affect other people.
- (3) Select a location which is convenient to connect the outdoor unit and near the power socket.
- (4) Select a location which is out of reach for children.
- (5) The location should be able to withstand the weight of indoor unit and won't increase noise and vibration.
- (6) The appliance must be installed 2.5m above floor.
- (7) Don't install the indoor unit right above the electric appliance.
- (8) Please try your best to keep way from fluorescent lamp.

3. Outdoor Unit:

- (1) Select a location where the noise and outflow air emitted by the outdoor unit will not affect neighborhood.
- (2) The location should be well ventilated and dry, in which the outdoor unit won't be exposed directly to sunlight or strong wind.

- (3) The location should be able to withstand the weight of outdoor unit.
- (4) Make sure that the installation follows the requirement of installation dimension diagram.
- (5) Select a location which is out of reach for children and far away from animals or plants.If it is unavoidable, please add fence for safety purpose.

8.4 Electric Connection Requirement

1. Safety Precaution

- (1) Must follow the electric safety regulations when installing the unit.
- (2) According to the local safety regulations, use qualified power supply circuit and air switch.
- (3) Make sure the power supply matches with the requirement of air conditioner. Unstable power supply or incorrect wiring may result in electric shock,fire hazard or malfunction. Please install proper power supply cables before using the air conditioner.
- (4) Properly connect the live wire, neutral wire and grounding wire of power socket.
- (5) Be sure to cut off the power supply before proceeding any work related to electricity and safety.
- (6) Do not put through the power before finishing installation.
- (7) If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard .
- (8) The temperature of refrigerant circuit will be high, please keep the interconnection cable away from the copper tube.
- (9) The appliance shall be installed in accordance with national wiring regulations.
- (10) Appliance shall be installed, operated and stored in a room with a floor area larger than Xm^2 (Please refer to table "a" in section of " Safety Operation of Inflammable Refrigerant" for Space X.)



Please notice that the unit is filled with flammable gas R32. Inappropriate treatment of the unit involves the risk of severe damages of people and material. Details to this refrigerant are found in chapter "refrigerant".

2. Grounding Requirement:

- (1) The air conditioner is the first class electric appliance.It must be properly grounding with specialized grounding device by a professional.
Please make sure it is always grounded effectively,otherwise it may cause electric shock.
- (2) The yellow-green wire in air conditioner is grounding wire, which can't be used for other purposes.
- (3) The grounding resistance should comply with national electric safety regulations.
- (4) The appliance must be positioned so that the plug is accessible.
- (5) An all-pole disconnection switch having a contact separation of at least 3mm in all poles should be connected in fixed wiring.
- (6) Including an air switch with suitable capacity, please note the following table. Air switch should be included magnet buckle and heating buckle function, it can protect the circuit-short and overload. (Caution: please do not use the fuse only for protect the circuit)

| Model | Air switch capacity | Power cord |
|--------|---------------------|------------|
| 09/12K | 10A | 3G1.0 |
| 18K | 16A | 3G1.5 |
| 24K | 25A | 3G2.5 |

8.5 Installation of Indoor Unit

1. Choosing Installation location

Recommend the installation location to the client and then confirm it with the client.

2. Install Wall-mounting Frame


(1) Hang the wall-mounting frame on the wall; adjust it in horizontal position with the level meter and then point out the screw fixing holes on the wall.

(2) Drill the screw fixing holes on the wall with impact drill (the specification of drill head should be the same as the plastic expansion particle) and then fill the plastic expansion particles in the holes.


(3) Fix the wall-mounting frame on the wall with tapping screws and then check if the frame is firmly installed by pulling the frame. If the plastic expansion particle is loose, please drill another fixing hole nearby.

3. Drill Piping Hole

(1) Choose the position of piping hole according to the direction of outlet pipe. The position of piping hole should be a little lower than the wall-mounted frame, shown as below. (As show in Fig.1)



(2) Drill a piping hole with the diameter of $\Phi 55\text{mm}$ or $\Phi 70\text{mm}$ on the selected outlet pipe position. In order to drain smoothly, slant the piping hole on the wall slightly downward to the outdoor side with the gradient of $5\text{-}10^\circ$. (As show in Fig.2)





⚠ Note:

Pay attention to dust prevention and take relevant safety measures when drilling the hole.

4. Outlet Pipe

(1) The pipe can be led out in the direction of right, rear right, left or rear left. (As show in Fig.3)

(2) When selecting leading out the pipe from left or right, please cut off the corresponding hole on the bottom case. (As show in Fig.4)






5. Connect the Pipe of Indoor Unit

(1) Aim the pipe joint at the corresponding bellmouth. (As show in Fig.5)

(2) Pretightening the union nut with hand.

(3) Adjust the torque force by referring to the following sheet. Place the open-end wrench on the pipe joint and place the torque wrench on the union nut. Tighten the union nut with torque wrench. (As show in Fig.6)

(4) Wrap the indoor pipe and joint of connection pipe with insulating pipe, and then wrap it with tape. (As show in Fig.7)



Refer to the following table for wrench moment of force:

| Piping size | Tightening torque(N·m) |
|-------------|------------------------|
| 1/4" | 15~20 |
| 3/8" | 30~40 |
| 1/2" | 45~55 |
| 5/8" | 60~65 |
| 3/4" | 70~75 |

6. Install Drain Hose

(1) Connect the drain hose to the outlet pipe of indoor unit.(As show in Fig.8)

(2) Bind the joint with tape.(As show in Fig.9)




Fig.8




Fig.9

⚠ Note:

(1) Add insulating pipe in the indoor drain hose in order to prevent condensation.

(2) The plastic expansion particles are not provided.

(As show in Fig.10)




Fig.10

7. Connect Wire of Indoor Unit

(1) Open the panel, remove the screw on the wiring cover and then take down the cover.(As show in Fig.11)




Fig.11

(2) Make the power connection wire go through the cable-cross hole at the back of indoor unit and then pull it out from the front side.(As show in Fig.12)




Fig.12

(3) Remove the wire clip; connect the power connection wiresignal control wire (only for cooling and heating unit) to the wiring terminal according to the color; tighten the screw and then fix the power connection wire with wire clip.(As show in Fig.13)




Fig.13

Note: The wiring connect is for reference only, please refer to the actual one.

(4) Put wiring cover back and then tighten the screw.

(5) Close the panel.

⚠ Note:

(1) All wires of indoor unit and outdoor unit should be connected by a professional.

(2) If the length of power connection wire is insufficient, please contact the supplier for a new one. Avoid extending the wire by yourself.

(3) For the air conditioner with plug, the plug should be reachable after finishing installation.

(4) For the air conditioner without plug, an air switch must be installed in the line. The air switch should be all-pole parting and the contact parting distance should be more than 3mm.

8. Bind up Pipe

(1) Bind up the connection pipe, power cord and drain hose with the band.(As show in Fig.14)

(2) Reserve a certain length of drain hose and power cord for installation when binding them. When binding to a certain degree, separate the indoor power and then separate the drain hose.(As show in Fig.15)

(3) Bind them evenly.

(4) The liquid pipe and gas pipe should be bound separately at the end.




Fig.14






Fig.15

⚠ Note:

- (1) The power cord and control wire can't be crossed or winding.
- (2) The drain hose should be bound at the bottom.

9. Hang the Indoor Unit

- (1) Put the bound pipes in the wall pipe and then make them pass through the wall hole.
- (2) Hang the indoor unit on the wall-mounting frame.
- (3) Stuff the gap between pipes and wall hole with sealing gum.
- (4) Fix the wall pipe.(As show in Fig.16)
- (5) Check if the indoor unit is installed firmly and closed to the wall.(As show in Fig.17)



⚠ Note:

Do not bend the drain hose too excessively in order to prevent blocking.



8.6 Installation of Outdoor Unit

1. Fix the Support of Outdoor Unit(Select it according to the actual installation situation)

- (1) Select installation location according to the house structure.
- (2) Fix the support of outdoor unit on the selected location with expansion screws.

⚠ Note:

- (1) Take sufficient protective measures when installing the outdoor unit.
- (2) Make sure the support can withstand at least four times the unit weight.
- (3) The outdoor unit should be installed at least 3cm above the floor in order to install drain joint.(As show in Fig.18)
- (4) For the unit with cooling capacity of 2300W~5000W, 6 expansion screws are needed; for the unit with cooling capacity of 6000W~8000W, 8 expansion screws are needed; for the unit with cooling capacity of 10000W~16000W, 10 expansion screws are needed.





2. Install Drain Joint(Only for cooling and heating unit)

- (1) Connect the outdoor drain joint into the hole on the chassis.
 - (2) Connect the drain hose into the drain vent.
- (As show in Fig.19)


3. Fix Outdoor Unit

- (1) Place the outdoor unit on the support.
 - (2) Fix the foot holes of outdoor unit with bolts.
- (As show in Fig.20)



4. Connect Indoor and Outdoor Pipes

- (1) Remove the screw on the right handle of outdoor unit and then remove the handle.(As show in Fig.21)
- (2) Remove the screw cap of valve and aim the pipe joint at the bellmouth of pipe.(As show in Fig.22)



- (3) Pretightening the union nut with hand.
- (4) Tighten the union nut with torque wrench .

Refer to the following table for wrench moment of force:

| Piping size | Tightening torque(N·m) |
|-------------|------------------------|
| 1/4" | 15~20 |
| 3/8" | 30~40 |
| 1/2" | 45~55 |
| 5/8" | 60~65 |
| 3/4" | 70~75 |

5. Connect Outdoor Electric Wire

(1) Remove the wire clip; connect the power connection wire and signal control wire (only for cooling and heating unit) to the wiring terminal according to the color; fix them with screws.(As show in Fig.23)




Fig.23

Note: the wiring connect is for reference only, please refer to the actual one.

(2) Fix the power connection wire and signal control wire with wire clip (only for cooling and heating unit).

⚠ Note:

- (1) After tightening the screw, pull the power cord slightly to check if it is firm.
- (2) Never cut the power connection wire to prolong or shorten the distance.

6. Neaten the Pipes

- (1) The pipes should be placed along the wall, bent reasonably and hidden possibly. Min. semidiameter of bending the pipe is 10cm.
- (2) If the outdoor unit is higher than the wall hole, you must set a U-shaped curve in the pipe before pipe goes into the room, in order to prevent rain from getting into the room.(As show in Fig.24)




Fig.24




Fig.25

⚠ Note:

- (1) The through-wall height of drain hose shouldnt be higher than the outlet pipe hole of indoor unit.(As show in Fig.25)
- (2) Slant the drain hose slightly downwards. The drain hose can't be curved, raised and fluctuant, etc.(As show in Fig.26)
- (3) The water outlet can't be placed in water in order to drain smoothly.(As show in Fig.27)




Fig.26




Fig.27

8.7 Vacuum Pumping and Leak Detection

1. Use Vacuum Pump

- (1) Remove the valve caps on the liquid valve and gas valve and the nut of refrigerant charging vent.
- (2) Connect the charging hose of piezometer to the refrigerant charging vent of gas valve and then connect the other charging hose to the vacuum pump.
- (3) Open the piezometer completely and operate for 10-15min to check if the pressure of piezometer remains in -0.1MPa .
- (4) Close the vacuum pump and maintain this status for 1-2min to check if the pressure of piezometer remains in -0.1MPa . If the pressure decreases, there may be leakage.
- (5) Remove the piezometer, open the valve core of liquid valve and gas valve completely with inner hexagon spanner.
- (6) Tighten the screw caps of valves and refrigerant charging vent.(As show in Fig.28)
- (7) Reinstall the handle.




Fig.28

2. Leakage Detection

- (1) With leakage detector: Check if there is leakage with leakage detector.
- (2) With soap water: If leakage detector is not available, please use soap water for leakage detection. Apply soap water at the suspected position and keep the soap water for more than 3min. If there are air bubbles coming out of this position, there's a leakage.

8.8 Check after Installation and Test Operation

1. Check after Installation

Check according to the following requirement after finishing installation.

| NO. | Items to be checked | Possible malfunction |
|-----|--|---|
| 1 | Has the unit been installed firmly? | The unit may drop, shake or emit noise. |
| 2 | Have you done the refrigerant leakage test? | It may cause insufficient cooling (heating) capacity. |
| 3 | Is heat insulation of pipeline sufficient? | It may cause condensation and water dripping. |
| 4 | Is water drained well? | It may cause condensation and water dripping. |
| 5 | Is the voltage of power supply according to the voltage marked on the nameplate? | It may cause malfunction or damage the parts. |
| 6 | Is electric wiring and pipeline installed correctly? | It may cause malfunction or damage the parts. |
| 7 | Is the unit grounded securely? | It may cause electric leakage. |
| 8 | Does the power cord follow the specification? | It may cause malfunction or damage the parts. |
| 9 | Is there any obstruction in air inlet and air outlet? | It may cause insufficient cooling (heating) capacity. |
| 10 | The dust and sundries caused during installation are removed? | It may cause malfunction or damaging the parts. |
| 11 | The gas valve and liquid valve of connection pipe are open completely? | It may cause insufficient cooling (heating) capacity. |
| 12 | Is the inlet and outlet of piping hole been covered? | It may cause insufficient cooling(heating) capacity or waster eletricity. |

2. Test Operation

(1) Preparation of test operation

- The client approves the air conditioner installation.
- Specify the important notes for air conditioner to the client.

(2) Method of test operation

- Put through the power, press ON/OFF button on the remote controller to start operation.
- Press MODE button to select AUTO, COOL, DRY, FAN and HEAT to check whether the operation is normal or not.
- If the ambient temperature is lower than 16°C, the air conditioner can't start cooling.

9. Maintenance

9.1 Error Code List

| Error code | Malfunction name | AC status | Possible causes |
|------------------|--|---|---|
| C5 | Malfunction of jumper cap | The complete unit stops operation | <ol style="list-style-type: none"> 1. Jumper cap is not installed in control panel; 2. Poor contact of jumper cap; 3. Jumper cap is damaged; 4. The tested circuit of jumper cap on control panel is abnormal. |
| E6 | Communication malfunction between indoor unit and outdoor unit | Cool: compressor stops operation, while indoor fan operates; Heat: all loads stops operation. | See "Communication malfunction" |
| H5 | IPM protection | Cool/Dry: compressor stops operation, while indoor fan operates. Heat: all loads stops operation. | See "IPM protection, over-phase current of compressor" |
| L3 LA | Malfunction of outdoor fan/ malfunction of DC motor | Cool/Dry: all loads stops operation except indoor fan. Heat: all loads stops operation. | <ol style="list-style-type: none"> 1. Outdoor condenser, air inlet and air outlet are blocked by filth or dirt; 2. Fan is blocked or loosened; 3. Motor or connection wire of motor is damaged; 4. Main board of outdoor unit is damaged; (As for dual-outdoor fan, L3 indicates fan 1; LA indicates fan 2) |
| H3 | Overload protection of compressor | Cool/Dry: compressor stops operation, while indoor fan operates. Heat: all loads stops operation. | <ol style="list-style-type: none"> 1. Overload wire of compressor is loose; 2. The overload protector is damaged. Under normal circumstances, the resistance between both ends of terminal is less than 1ohm. 3. See "Overload protection of compressor , High discharge temperature protection of compressor" |
| F0 | Refrigerant insufficient protection, cut-off protection of refrigerant | Cool: compressor and outdoor fan stops operation, while indoor fan operates; Heat: Compressor, outdoor fan and indoor fan stops operation. | <ol style="list-style-type: none"> 1. Is system cooling under high humidity environment, thus temperature difference of heat transfer is small; 2. Check whether the big valve and small valve of outdoor unit are opened completely; 3. Is the temperature sensor of evaporator of indoor unit loose? 4. Is the temperature sensor of condenser of outdoor unit loose? 5. Is the capillary or the electronic expansion valve blocked? 6. Is refrigerant leaking? |
| F1 | Indoor ambient temperature sensor is open/short-circuited | Cool/Dry: indoor fan operates, while compressor and outdoor fan stops operation; Heat: all loads stops operation. | <ol style="list-style-type: none"> 1. Temperature sensor is not well connected; 2. Temperature sensor is damaged 3. Main board of indoor unit is damaged. |
| F2 | Indoor evaporator temperature sensor is open/short-circuited | Cool/Dry: indoor fan operates, while compressor and outdoor fan stops operation; Heat: all loads stops operation. | <ol style="list-style-type: none"> 1. Temperature sensor is not well connected; 2. Temperature sensor is damaged 3. Main board of indoor unit is damaged. |
| H6 | No feedback from indoor unit's motor | The complete unit stops operation | <ol style="list-style-type: none"> 1. Is the fan blocked? 2. Is the motor terminal loose? 3. Is the connection wire of motor damaged? 4. Is the motor damaged? 5. Is the main board of indoor unit damaged? |
| LP | Indoor unit and outdoor can be matched with each other | Heat: compressor, outdoor unit and indoor fan stops operation. | Capacity of indoor unit and outdoor unit can't be matched. |
| C4 | Malfunction of jumper cap of outdoor unit | Heat: all loads are stopped; other modes: outdoor unit stops operation. | Jumper cap of outdoor unit hasn't been installed. |
| b7 | Gas valve temperature sensor is ON / short-circuited | | <ol style="list-style-type: none"> 1. Temperature sensor is not well connected or damaged; 2. The wire of temperature sensor is damaged, causing short circuit to copper pipe or outer casing; 3. Main board of outdoor unit is damaged. |

| Error code | Malfunction name | AC status | Possible causes |
|------------|--|---|--|
| b5 | Liquid valve temperature sensor is ON / short-circuited | | <ol style="list-style-type: none"> 1. Temperature sensor is not well connected or damaged; 2. The wire of temperature sensor is damaged, causing short circuit to copper pipe or outer casing; 3. Main board of outdoor unit is damaged. |
| E1 | High pressure protection of system | Cool/Dry: all loads stops operation except indoor fan; Heat: all loads stops operation. | <ol style="list-style-type: none"> 1. Heat exchange of outdoor unit is too dirty, or it blocked the air inlet/outlet; 2. Is power voltage normal; (three-phase unit) 3. Ambient temperature is too high; 4. Wiring of high pressure switch is loose or high pressure switch is damaged; 5. The internal system is blocked; (dirt blockage, ice blockage, oil blockage, angle valve is not completely opened) 6. Main board of outdoor unit is damaged; 7. Refrigerant is too much. |
| E3 | Low pressure/low system pressure protection/ compressor low pressure protection | Cool: compressor, outdoor fan and indoor fan stop operation; Heat: compressor and outdoor fan stop operation at first. About 1min later, indoor fan stops operation; 2mins later, the 4-way valve stop operation. | <ol style="list-style-type: none"> 1. Low pressure switch is damaged; 2. Refrigerant inside the system is insufficient. |
| E4 | High discharge temperature protection of compressor | Cool/Dry: compressor and outdoor fan stops operation, while indoor fan operates; Heat: all loads stops operation. | See "Overload protection of compressor , High discharge temperature protection of compressor" |
| E5 | AC overcurrent protection | Cool/Dry: compressor and outdoor fan stops operation, while indoor fan operates; Heat: all loads stops operation. | <ol style="list-style-type: none"> 1. Power voltage is unstable; 2. Power voltage is too low; 3. System load is too high, which leads to high current; 4. Heat exchange of indoor unit is too dirty, or it blocked the air inlet/outlet; 5. Fan motor operation is abnormal; the fan speed is too low or not functioning; 6. Compressor is blocked; 7. The internal system is blocked; (dirt blockage, ice blockage, oil blockage, angle valve is not completely opened) 8. Main board of outdoor unit is damaged. See "AC overcurrent protection" |
| E7 | Mode shock/sysmte mode shock | Load of indoor unit stops operation (indoor fan, E-heater, swing) | Malfunction of one-to-more system; there may be two indoor units which has set the shock mode, such as one is cooling and the other is heating. |
| E8 | High temperature prevention protection | Cool: compressor stops operation while indoor fan operates; Heat: all loads stops operation. | See "High temperature prevention protection; high power; system isabnormal" |
| EE | Malfunction of EEPROM | Cool/Dry: compressor stops operation, while indoor fan operates; Heat: all loads stops operation. | Main board of outdoor unit is damaged. |
| F0 | Refrigerant-recovery mode | Cool/Dry: compressor and outdoor fan stops operation, while indoor fan operates. | Refrigerant recovery. The maintenance personnel operate it when he is maintaining the unit. |
| F3 | Outdoor ambient temperature is open/short-circuited | Cool/Dry: compressor and outdoor fan stop operation, while indoor fan operates; Heat: all loads stops operation. | <ol style="list-style-type: none"> 1. Temperature sensor is not connected well or damaged; 2. Temperature sensor wire of outdoor unit is damaged; short circuit between the temperature sensor and copper pipe or outer case 3. Main board of outdoor unit is damaged; |

| Error code | Malfunction name | AC status | Possible causes |
|------------|--|--|--|
| F4 | Outdoor condenser temperature sensor is open/short-circuited | Cool/Dry: compressor and outdoor fan stop operation, while indoor fan operates; Heat: after operating for 3mins, all loads stops operation. | 1. Temperature sensor is not connected well or damaged; 2. Temperature sensor wire of outdoor unit is damaged; short circuit between the temperature sensor and copper pipe or outer case; 3. Main board of outdoor unit is damaged. |
| P8 | Module overheating protection | Cool: compressor stops operation, while indoor fan operates; Heat: all loads stops operation. | 1. Air inlet / air outlet of outdoor unit are blocked by filth or dirt; 2. Condenser of outdoor unit is blocked by filth or dirt; 3. IPM screw of main board is not tightened; 4. Main board of outdoor unit is damaged; |
| PF | Malfunction of ambient temperature sensor of drive board | Cool: compressor, outdoor fan and indoor fan stop operation; Heat: compressor and outdoor fan stop operation at first; about 1min later, indoor fan stops operation. | 1. The ambient temperature sensor of the drive board is not connected well; 2. Malfunction of the ambient temperature sensor of drive board. |
| PH | DC bus voltage is too high | Cool/Dry: compressor stops operation, while indoor fan operates; Heat: all loads stops operation. | 1. Measure the voltage between position L and position N on the wiring board (XT). If it's higher than 265 VAC, please turn on the unit until the power voltage is decreased to the normal range; 2. If the AC input is normal, please replace the outdoor control board. |
| PL | DC bus voltage is too low | Cool/Dry: compressor stops operation, while indoor fan operates; Heat: all loads stops operation. | 1. Measure the voltage between position L and position N on the wiring board (XT). If it's lower than 150 VAC, please turn on the unit until the power voltage is increased to the normal range; 2. If the AC input is normal, please replace the outdoor control board. |
| PU | Charging malfunction of capacitor | Cool/Dry: compressor stops operation, while indoor fan operates; Heat: all loads stops operation. | See "Charging malfunction of capacitor" |
| RF | Malfunction of RF module | Cool: compressor and outdoor fan stop operation; Heat: compressor and outdoor fan stop operation at first; about 1min later, indoor fan stops operation. | 1. The connection wire of RF module is not connected well. 2. Malfunction of RF module; |
| U1 | Phase current detection circuit malfunction of | Cool: compressor and outdoor fan stops operation, while indoor fan operates; Heat: compressor, outdoor fan and indoor fan stops operation. | The control board is damaged |
| U2 | Lost phase protection of compressor | Cool: compressor and outdoor fan stop operation; Heat: compressor and outdoor fan stop operation at first; about 1min later, indoor fan stops operation. | 1. The main board of outdoor unit is damaged; 2. The compressor is damaged; 3. The connection wire of compressor is not connected well. |
| U3 | DC bus voltage drop malfunction | Cool/Dry: compressor stops operation, while indoor fan operates; Heat: all loads stops operation. | The power voltage is unstable. |
| U5 | Current detection malfunction of unit | Cool: compressor and outdoor fan stops operation, while indoor fan operates; Heat: compressor, outdoor fan and indoor fan stops operation. | 1. Is the complete unit lacking of refrigerant? 2. There's malfunction for the circuit of control board of outdoor unit. Replace the control board of outdoor unit. |
| U7 | 4-way valve is abnormal | This malfunction occurs when the unit is heating. All loads stops operation. | 1. Power voltage is lower than AC175V; 2. Wiring terminal of 4-way valve is loose or broken;3. 4-way valve is damaged. Replace the 4-way valve. |

| Error code | Malfunction name | AC status | Possible causes |
|-------------------------------|--|---|---|
| U8 | Malfunction of zero-crossing signal of indoor unit | Compressor, outdoor fan and indoor fan stop operation. | 1. The power is abnormal; 2. Main board of indoor unit is damaged. |
| U9 | Zero-crossing malfunction of outdoor unit | Cool: compressor stops operation, while indoor fan operates; Heat: all loads stops operation. | Replace the control board of outdoor unit. |
| E2 | Evaporator anti-freezing protection | | Not error code, it is the status code in cooling process |
| E9 | Anti cold air protection | | Not error code, it is the status code in cooling process |
| Heat indicator Flash once/10s | Defrosting | | Not error code, it is the status code in cooling process |

Analysis or processing of some of the malfunction display:

1. Compressor discharge protection

Possible causes: shortage of refrigerant; blockage of air filter; poor ventilation or air flow short pass for condenser; the system has noncondensing gas (such as air, water etc.); blockage of capillary assy (including filter); leakage inside four-way valve causes incorrect operation; malfunction of compressor; malfunction of protection relay; malfunction of discharge sensor; outdoor temperature too high.

Processing method: refer to the malfunction analysis in the above section.

2. Low voltage overcurrent protection

Possible cause: Sudden drop of supply voltage.

3. Communication malfunction

Processing method: Check if communication signal cable is connected reliably.

4. Sensor open or short circuit

Processing method: Check whether sensor is normal, connected with the corresponding position on the controller and if damage of lead wire is found.

5. Compressor over load protection

Possible causes: insufficient or too much refrigerant; blockage of capillary and increase of suction temp.; improper running of compressor, burning in or stuck of bearing, damage of discharge valve; malfunction of protector.

Processing method: adjust refrigerant amount; replace the capillary; replace the compressor; use universal meter to check if the contactor of compress or is fine when it is not overheated, if not replace the protector.

6. System malfunction

i.e. overload protection. When tube temperature (Check the temperature of outdoor heat exchanger when cooling and check the temperature of indoor heat exchanger when heating) is too high, protection will be activated.


Possible causes: Outdoor temperature is too high when cooling; insufficient outdoor air circulation; refrigerant flow malfunction.

please refer to the malfunction analysis in the previous section for handling method .

7. IPM module protection

Processing method: Once the module malfunction happens, if it persists for a long time and can not be self-canceled, cut off the power and turn off the unit, and then re-energize the unit again after about 10 min. After repeating the procedure for several times, if the malfunction still exists, replace the module.

If malfunction occurs, corresponding code will display and the unit will resume normal until protection or malfunction disappears.




9.2 Procedure of Troubleshooting

1. Troubleshooting for jumper cap C5

Main check points:


- (1) jumper cap
- (2) control board of indoor unit



2. Communication malfunction E5

Main check points:

- (1) Connection wire between indoor unit and outdoor unit
- (2) Wiring inside the unit
- (3) Communication circuit of control board of indoor unit
- (4) Communication circuit of control board of outdoor unit




3. IPM protection H5, over-phase current of compressor P5

Main check points:

- (1) compressor COMP terminal
- (2) power supply voltage
- (3) compressor
- (4) charging amount of refrigerant
- (5) air inlet and air outlet of indoor/outdoor unit

NOTE: The control board as below means the control board of outdoor unit.




4. Overload protection of compressor H3, high discharge temperature, protection of compressor E4

Main check points:

- (1) electronic expansion valve (2) expansion valve terminal
- (3) charging amount of refrigerant (4) overload protector


NOTE: The control board as below means the control board of outdoor unit.



5. Troubleshooting for temperature sensor F1, F2, F3, F4, F5

Main check points:

- (1) connection terminal
- (2) temperature sensor
- (3) main board




6.High temperature prevention protection E8; high power L9; system is abnormal H4

Main check points:

(1) outdoor temperature (2) fan (3)air inlet and air outlet of indoor/outdoor unit

NOTE:The control board as below means the control board of outdoor unit.




7.Desynchronization diagnosis for compressor H7

Main check point:

(1) system pressure (2) power supply voltage

NOTE:The control board as below means the control board of outdoor unit.




8. Malfunction diagnosis for failure startup \perp c

Main check points:

(1) compressor wire (2) compressor (3) charging amount of refrigerant

NOTE: The control board as below means the control board of outdoor unit.




9. Charging malfunction of capacitor PU

Main check points:

(1) wiring board XT (2) reactor

NOTE: The control board as below means the control board of outdoor unit.





10. Troubleshooting-motor(indoor fan) doesn't operate H6


Main check points:

(1) connection terminal (2) motor (3) control board AP1 of indoor unit (4) blade


10.1 DC motor



10.2 PG motor



11. AC overcurrent protection E5



9.3 Troubleshooting for Normal Malfunction

1. Air Conditioner can't be Started Up

| Possible Causes | Discriminating Method (Air conditioner Status) | Troubleshooting |
|---|---|--|
| No power supply, or poor connection for power plug | After energization, operation indicator isn't bright and the buzzer can't give out sound | Confirm whether it's due to power failure. If yes, wait for power recovery. If not, check power supply circuit and make sure the power plug is connected well. |
| Wrong wire connection between indoor unit and outdoor unit, or poor connection for wiring terminals | Under normal power supply circumstances, operation indicator isn't bright after energization | Check the circuit according to circuit diagram and connect wires correctly. Make sure all wiring terminals are connected firmly |
| Electric leakage for air conditioner | After energization, room circuit breaker trips off at once | Make sure the air conditioner is grounded reliably Make sure wires of air conditioner is connected correctly Check the wiring inside air conditioner. Check whether the insulation layer of power cord is damaged; if yes, place the power cord. |
| Model selection for air switch is improper | After energization, air switch trips off | Select proper air switch |
| Malfunction of remote controller | After energization, operation indicator is bright, while no display on remote controller or buttons have no action. | Replace batteries for remote controller Repair or replace remote controller |

2. Poor Cooling (Heating) for Air Conditioner

| Possible Causes | Discriminating Method (Air conditioner Status) | Troubleshooting |
|--|--|---|
| Set temperature is improper | Observe the set temperature on remote controller | Adjust the set temperature |
| Rotation speed of the IDU fan motor is set too low | Small wind blow | Set the fan speed at high or medium |
| Filter of indoor unit is blocked | Check the filter to see its blocked | Clean the filter |
| Installation position for indoor unit and outdoor unit is improper | Check whether the installation position is proper according to installation requirement for air conditioner | Adjust the installation position, and install the rainproof and sunproof for outdoor unit |
| Refrigerant is leaking | Discharged air temperature during cooling is higher than normal discharged wind temperature; Discharged air temperature during heating is lower than normal discharged wind temperature; Units pressure is much lower than regulated range | Find out the leakage causes and deal with it. Add refrigerant. |
| Malfunction of 4-way valve | Blow cold wind during heating | Replace the 4-way valve |
| Malfunction of capillary | Discharged air temperature during cooling is higher than normal discharged wind temperature; Discharged air temperature during heating is lower than normal discharged wind temperature; Unit pressure is much lower than regulated range. If refrigerant isn't leaking, part of capillary is blocked | Replace the capillary |
| Flow volume of valve is insufficient | The pressure of valves is much lower than that stated in the specification | Open the valve completely |
| Malfunction of horizontal louver | Horizontal louver can't swing | Refer to point 3 of maintenance method for details |
| Malfunction of the IDU fan motor | The IDU fan motor can't operate | Refer to troubleshooting for H6 for maintenance method in details |
| Malfunction of the ODU fan motor | The ODU fan motor can't operate | Refer to point 4 of maintenance method for details |
| Malfunction of compressor | Compressor can't operate | Refer to point 5 of maintenance method for details |

3. Horizontal Louver can't Swing

| Possible Causes | Discriminating Method (Air conditioner Status) | Troubleshooting |
|---|--|--|
| Wrong wire connection, or poor connection | Check the wiring status according to circuit diagram | Connect wires according to wiring diagram to make sure all wiring terminals are connected firmly |
| Stepping motor is damaged | Stepping motor can't operate | Repair or replace stepping motor |
| Main board is damaged | Others are all normal, while horizontal louver can't operate | Replace the main board with the same model |

4. ODU Fan Motor can't Operate

| Possible causes | Discriminating method (air conditioner status) | Troubleshooting |
|---|---|--|
| Wrong wire connection, or poor connection | Check the wiring status according to circuit diagram | Connect wires according to wiring diagram to make sure all wiring terminals are connected firmly |
| Capacity of the ODU fan motor is damaged | Measure the capacity of fan capacitor with an universal meter and find that the capacity is out of the deviation range indicated on the nameplate of fan capacitor. | Replace the capacity of fan |
| Power voltage is a little low or high | Use universal meter to measure the power supply voltage. The voltage is a little high or low | Suggest to equip with voltage regulator |
| Motor of outdoor unit is damaged | When unit is on, cooling/heating performance is bad and ODU compressor generates a lot of noise and heat. | Change compressor oil and refrigerant. If no better, replace the compressor with a new one |

5. Compressor can't Operate

| Possible causes | Discriminating method (air conditioner status) | Troubleshooting |
|---|---|--|
| Wrong wire connection, or poor connection | Check the wiring status according to circuit diagram | Connect wires according to wiring diagram to make sure all wiring terminals are connected firmly |
| Capacity of compressor is damaged | Measure the capacity of fan capacitor with an universal meter and find that the capacity is out of the deviation range indicated on the nameplate of fan capacitor. | Replace the compressor capacitor |
| Power voltage is a little low or high | Use universal meter to measure the power supply voltage. The voltage is a little high or low | Suggest to equip with voltage regulator |
| Coil of compressor is burnt out | Use universal meter to measure the resistance between compressor terminals and it's 0 | Repair or replace compressor |
| Cylinder of compressor is blocked | Compressor can't operate | Repair or replace compressor |

6. Air Conditioner is Leaking

| Possible causes | Discriminating method (air conditioner status) | Troubleshooting |
|-----------------------|---|---|
| Drain pipe is blocked | Water leaking from indoor unit | Eliminate the foreign objects inside the drain pipe |
| Drain pipe is broken | Water leaking from drain pipe | Replace drain pipe |
| Wrapping is not tight | Water leaking from the pipe connection place of indoor unit | Wrap it again and bundle it tightly |


7. Abnormal Sound and Vibration

| Possible causes | Discriminating method (air conditioner status) | Troubleshooting |
|--|--|---|
| When turn on or turn off the unit, the panel and other parts will expand and theres abnormal sound | Theres the sound of "PAPA" | Normal phenomenon. Abnormal sound will disappear after a few minutes. |
| When turn on or turn off the unit, theres abnormal sound due to flow of refrigerant inside air conditioner | Water-running sound can be heard | Normal phenomenon. Abnormal sound will disappear after a few minutes. |
| Foreign objects inside the indoor unit or therere parts touching together inside the indoor unit | Theres abnormal sound fro indoor unit | Remove foreign objects. Adjust all parts position of indoor unit, tighten screws and stick damping plaster between connected parts |
| Foreign objects inside the outdoor unit or therere parts touching together inside the outdoor unit | Theres abnormal sound fro outdoor unit | Remove foreign objects. Adjust all parts position of outdoor unit, tighten screws and stick damping plaster between connected parts |
| Short circuit inside the magnetic coil | During heating, the way valve has abnormal electromagnetic sound | Replace magnetic coil |
| Abnormal shake of compressor | Outdoor unit gives out abnormal sound | Adjust the support foot mat of compressor, tighten the bolts |
| Abnormal sound inside the compressor | Abnormal sound inside the compressor | If add too much refrigerant during maintenance, please reduce refrigerant properly. Replace compressor for other circumstances. |

10. Exploded View and Parts List

10.1 Indoor Unit

AUC




The component picture is only for reference; please refer to the actual product.

| NO. | Description |
|-----|------------------------------|
| 1 | Front Panel |
| 2 | Filter Sub-Assy |
| 3 | Screw Cover |
| 4 | Front Case |
| 5 | Guide Louver (upper) |
| 6 | Guide Louver (lower) |
| 7 | Plug Pin |
| 8 | Swing Lever |
| 9 | Air Louver (left) |
| 10 | Helicoid Tongue |
| 11 | Left Axile Bush |
| 12 | Rear Case |
| 13 | Drainage Hose |
| 14 | Ring of Bearing |
| 15 | O-Gasket sub-assy of Bearing |
| 16 | Evaporator Support |
| 17 | Wall Mounting Frame |
| 18 | Wall Mounting Frame |
| 19 | Cross Flow Fan |
| 20 | Motor Press Plate |
| 21 | Brushless DC Motor |
| 22 | Connecting pipe clamp |

| NO. | Description |
|-----|--------------------------|
| 23 | Rubber Plug (Water Tray) |
| 24 | Stepping Motor |
| 25 | Crank |
| 26 | Stepping Motor |
| 27 | Plasmacluster Ion |
| 28 | Air Louver |
| 29 | Stepping Motor |
| 30 | Air Louver(right) |
| 31 | Electric Box |
| 32 | Main Board |
| 33 | Jumper |
| 34 | Supporter |
| 35 | Terminal Board |
| 36 | Cable Clamp 2 |
| 37 | Electric Box Assy |
| 38 | Electric Box Cover |
| 39 | Display Board |
| 40 | Front Panel Assy |
| 41 | Remote Controller |
| 42 | Temperature Sensor |
| 43 | Connecting Cable |

Some models may not contain some parts, please refer to the actual product.

AUD



The component picture is only for reference; please refer to the actual product.


| NO. | Description |
|-----|------------------------------|
| 1 | Front Panel |
| 2 | Front Case Assy |
| 3 | Guide Louver Sub-assy 1 |
| 4 | Guide Louver Sub-assy 2 |
| 5 | Plug Pin |
| 6 | Left Axile Bush |
| 7 | Rear Case |
| 8 | Cross Flow Fan |
| 9 | Ring of Bearing |
| 10 | O-Gasket sub-assy of Bearing |
| 11 | Evaporator Support |
| 12 | Evaporator Assy |
| 13 | Fan Motor |
| 14 | Motor Press Plate |
| 15 | Wall Mounting Frame Sub-assy |
| 16 | Electric Box Assy |
| 17 | Connecting pipe clamp |
| 18 | Rubber Plug (Water Tray) |
| 19 | Supporter |
| 20 | Electric Box |

| NO. | Description |
|-----|------------------------|
| 21 | Main Board |
| 22 | Jumper |
| 23 | Stepping Motor |
| 24 | Stepping Motor |
| 25 | Crank |
| 26 | Drainage Hose |
| 27 | Filter Sub-Assy |
| 28 | Screw Cover |
| 29 | Electric Box Cover |
| 30 | Remote Controller |
| 31 | Connecting Cable |
| 32 | Connecting Cable |
| 33 | Power Cord |
| 34 | Temperature Sensor |
| 35 | Plasmacluster Ion |
| 36 | Stepping Motor |
| 37 | Terminal Board |
| 38 | Display Board |
| 39 | Right Decorative Board |
| 40 | Left Decorative Board |

Some models may not contain some parts, please refer to the actual product.

10.2 Outdoor Unit

GWH09AUCXB-K6DNA1A/O




The component is only for reference; please refer to the actual product

| NO. | Description |
|-----|----------------------------|
| 1 | Coping |
| 2 | 4-Way Valve |
| 3 | 4-Way Valve Assy |
| 4 | Sponge(Condenser) |
| 5 | Temperature Sensor Support |
| 6 | Condenser Assy |
| 7 | Capillary Sub-assy |
| 8 | Sensor Insert |
| 9 | Right Side Plate |
| 10 | Earthing Plate Sub-Assy |
| 11 | Wire Clamp |
| 12 | Valve Cover |
| 13 | Silencer |
| 14 | Cut-off valve 3/8(N) |
| 15 | Cut-off valve 1/4(N) |
| 16 | Valve Support |
| 17 | Compressor and Fittings |

| NO. | Description |
|-----|---------------------|
| 18 | Chassis Sub-assy |
| 19 | Motor Support |
| 20 | Fan Motor |
| 21 | Axial Flow Fan |
| 22 | Cabinet |
| 23 | Front Grill |
| 24 | Drainage Joint(ODU) |
| 25 | Left Side Plate |
| 26 | Clapboard |
| 27 | Electric Box Assy |
| 28 | Electric Box |
| 29 | Main Board |
| 30 | Electric Box Cover |
| 31 | Terminal Board |
| 32 | Temperature Sensor |
| 33 | Raidator |
| 34 | Handle (Right) |

Some models may not contain some parts, please refer to the actual product.



The component is only for reference; please refer to the actual product


| NO. | Description |
|-----|-------------------------------|
| 1 | Coping |
| 2 | Supporting Board(Condenser) |
| 3 | 4-Way Valve |
| 4 | Temperature Sensor Support |
| 5 | Condenser Assy |
| 6 | Temp Sensor Sleevling |
| 7 | Sensor Insert |
| 8 | Handle |
| 9 | Right Side Plate |
| 10 | Earthing Plate Sub-assy |
| 11 | Wire Clamp |
| 12 | Electronic Expansion Valve |
| 13 | Electric Expand Valve Fitting |
| 14 | Valve Cover |
| 15 | Silencer |
| 16 | Cut off Valve Sub-Assy |
| 17 | Strainer |
| 18 | Cut off Valve Assy |
| 19 | Valve Support |

| NO. | Description |
|-----|-------------------------|
| 20 | 4-Way Valve Assy |
| 21 | Compressor and Fittings |
| 22 | Chassis Sub-assy |
| 23 | Motor Support |
| 24 | Brushless DC Motor |
| 25 | Axial Flow Fan |
| 26 | Cabinet |
| 27 | Front Grill |
| 28 | Drainage Joint(ODU) |
| 29 | Left Side Plate |
| 30 | Clapboard |
| 31 | Electric Box Assy |
| 32 | Electric Box |
| 33 | Main Board |
| 34 | Electric Box Cover |
| 35 | Terminal Board |
| 36 | Temperature Sensor |
| 37 | Radiator |

Some models may not contain some parts, please refer to the actual product.

GWH18AUDXD-K6DNA1A/O GWH12AUCXD-K6DNA1C/O

(The front grill appearance is for reference only)



The component is only for reference; please refer to the actual product


| NO. | Description |
|-----|-----------------------------------|
| 1 | Top Cover Assy |
| 2 | Condenser Assy |
| 3 | 4-Way Valve |
| 4 | Tempreture Sensor clamp |
| 5 | 4-Way Valve Assy |
| 6 | Electric Expand Valve Fitting |
| 7 | Electric Expansion Valve Sub-Assy |
| 8 | Wire Clamp |
| 9 | Right Side Plate |
| 10 | Earthing Plate Sub-assy |

| NO. | Description |
|-----|-------------------------|
| 11 | Handle |
| 12 | Valve Cover |
| 13 | Cut-off valve 1/4(N) |
| 14 | Cut-off valve 1/2(N) |
| 15 | Valve Support |
| 16 | Compressor and Fittings |
| 17 | Chassis Sub-assy |
| 18 | Cabinet |
| 19 | Front Grill |
| 20 | Axial Flow Fan |
| 21 | Brushless DC Motor |

| NO. | Description |
|-----|--------------------|
| 22 | Motor Support |
| 23 | Left Side Plate |
| 24 | Clapboard Assy |
| 25 | Electric Box Assy |
| 26 | Electric Box |
| 27 | Main Board |
| 28 | Electric Box Cover |
| 29 | Terminal Board |
| 30 | Temperature Sensor |
| 31 | Radiator |

Some models may not contain some parts, please refer to the actual product.






The component picture is only for reference; please refer to the actual product.

| NO. | Description | NO. | Description | NO. | Description |
|-----|----------------------------|-----|---------------------------------|-----|--------------------|
| 1 | Front Panel Assy | 13 | Electronic Expansion Valve assy | 25 | Motor Support Sub |
| 2 | Front grill | 14 | Right Side Plate Assy | 26 | Top Cover Sub-Assy |
| 3 | Front Panel | 15 | Valve Support | 27 | Left Side Plate |
| 4 | Axial Flow Fan | 16 | Cut-off valve 1/2(N) | 28 | Terminal Board |
| 5 | Drainage hole Cap | 17 | Cut-off valve 1/4(N) | 29 | Electric Box Cover |
| 6 | Chassis Sub-assy | 18 | Valve Support Block | 30 | Main Board |
| 7 | Drainage Joint | 19 | Valve Cover | 31 | Radiator |
| 8 | Compressor and Fittings | 20 | Electronic Expand Valve Fitting | 32 | Electric Box Assy |
| 9 | Compressor Gasket | 21 | Sensor Insert | 33 | Electric Box |
| 10 | 4-way valve | 22 | Temp Sensor Sleevling | 34 | Brushless DC Motor |
| 11 | 4-way valve Sub-assy | 23 | Condenser Assy | 35 | Handle |
| 12 | Electronic Expansion Valve | 24 | Clapboard Sub-Assy | | |

Some models may not contain some parts, please refer to the actual product.

GWH24AUDXF-K6DNA1A/O



The component is only for reference; please refer to the actual product

| NO. | Description |
|-----|---------------------------------|
| 1 | Front Grill |
| 2 | Front Panel |
| 3 | Axial Flow Fan |
| 4 | Chassis Sub-assy |
| 5 | Compressor and Fittings |
| 6 | Electronic Expansion Valve Assy |
| 7 | Right Side Plate |
| 8 | Valve Support |
| 9 | Cut-off valve 1/4(N) |
| 10 | Cut-off valve 5/8(N) |
| 11 | Valve Cover |
| 12 | Handle |
| 13 | Terminal Board |

| NO. | Description |
|-----|-----------------------------|
| 14 | 4-Way Valve Assy |
| 15 | Condenser Assy |
| 16 | Clapboard Assy |
| 17 | Motor Support |
| 18 | Brushless DC Motor |
| 19 | Top Cover Assy |
| 20 | Left Side Plate |
| 21 | Condenser Left Border Plate |
| 22 | Electric Box Assy |
| 23 | Radiator |
| 24 | Electric Box |
| 25 | Main Board |
| 26 | Electric Box Cover |

Some models may not contain some parts, please refer to the actual product.

11. Removal Procedure




11.1 Removal Procedure of Indoor Unit




09/12K





Note: Take A1 blue panel for example.








Caution: discharge the refrigerant completely before removal.

| Step | Procedure |
|--|--|
| Before disassemble | <p data-bbox="185 585 675 646">Turn off the air conditioner and disconnect the power before disassemble the air conditioner.</p>  |
| 1. Remove filter | <p data-bbox="185 1159 708 1251">Hold the handle on the filter, pull it upwards to let the clasp at the top part of the filter loose, push it forwards and then the filter can be pulled out.</p>  |
| 2. Remove upper and lower guide louver | <p data-bbox="185 1734 786 1856">Push out the plug pin on upper and lower guide louver, Bend the guide louver with hand and then separate the guide louver from the crank shaft of step motor to remove it.</p>  |

| Step | Procedure |
|--|---|
| <p>3.Remove panel</p> | <p>Open the front panel; separate the panel rotation shaft from the groove fixing the front panel and then removes the front panel.</p> <p>Note: The display of some models is fixed on the panel; unscrew the screws fixing the display on the panel before removing the panel.</p>  |
| <p>4.Remove electric box cover 2</p> | <p>Remove the screws on the electric box cover 2 to remove the electric box cover 2.</p>  |
| <p>5.Remove front case sub-assy</p> <p>a</p> <p>Remove the screws fixing front case.</p> <p>Note: (1) Open the screw caps before removing the screws around the air outlet. (2) The quantity of screws fixing the front case sub-assy is different for different models.</p> <p>b</p> <p>Loosen the clasps at left, middle and right sides of front case. Lift the front case sub-assy upwards to remove it.</p> |  |




| Step | Procedure |
|----------------------------|---|
| 6.Remove electric box assy | |
| a | <p>Remove the screw fixing electric box assy.</p>  |
| b | <p>① Cut off the wire binder and pull out the indoor tube temperature sensor. ② Screw off one grounding screw. ③ Remove the wiring terminals of motor, cold plasma generator and stepping motor. ④ Remove the electric box assy. ⑤ Screw off the screws that are locking each.</p>  |
| c | <p>Rotate the electric box assy. Twist off the screws that are locking the wire clip and loosen the power cord. Remove the wiring terminal of power cord. Lift up the main board and take it off.</p>  <p>Instruction:Some wiring terminal of this products is with lock catch and other devices.The pulling method is as below: 1.Remove the soft sheath for some terminals at first, hold the circlip and then pull out the terminals, 2.Pull out the holder for some terminals at first(holder is not available for some wiring terminal).hold the connector and then pull the terminal.</p>  |





| Step | Procedure |
|----------------|---|
| 5.Remove panel | |
| a | <p>Remove 3 screws fixing evaporator assy.</p>  |
| b | <p>At the back of the unit, Loosen the clasp of the connection pipe clamp and then remove the connection pipe clamp.</p>  |
| c | <p>First remove the left side of evaporator from the groove of bottom shell and then remove the right side from the clasp on the bottom shell.</p>  |
| d | <p>Adjust the position of connection pipe on evaporator slightly and then lift the evaporator upwards to remove it.</p>  |





| Step | Procedure | Procedure |
|---|--|--|
| 8. Remove motor and cross flow fan | | |
| a | Remove the screw fixing motor clamp and then remove the motor clamp. |  <p data-bbox="1312 576 1386 598">Screw</p> |
| b | Loose the screws (2-3 circles) used for fixing the cross flow fan, pull right to pull out the motor. |  <p data-bbox="1312 679 1386 701">Screw</p> |
| 9. Remove swing motor | | |
| | Screw off the screws that are locking the swing motor and take the motor off. |  <p data-bbox="1013 1814 1094 1836">Screws</p> |







Caution: discharge the refrigerant completely before removal.




| Step | Procedure |
|--|--|
| <p>Before disassemble</p> | <p>Turn off the air conditioner and disconnect the power before disassemble the air conditioner.</p>  |
| <p>1. Remove filter</p> | <p>Hold the handle on the filter, pull it upwards to let the clasp at the top part of the filter loose, push it forwards and then the filter can be pulled out.</p>  |
| <p>2.Remove upper and lower guide louver</p> | <p>Push out the plug pin on upper and lower guide louver, Bend the guide louver with hand and then separate the guide louver from the crank shaft of step motor to remove it.</p>  |

| Step | Procedure |
|--|--|
| <p>3.Remove panel</p> | <p>Open the front panel; separate the panel rotation shaft from the groove fixing the front panel and then removes the front panel.</p> <p>Note: The display of some models is fixed on the panel; unscrew the screws fixing the display on the panel before removing the panel.</p>  |
| <p>4.Remove electric box cover 2</p> | <p>Remove the screws on the electric box cover 2 to remove the electric box cover 2.</p>  |
| <p>5.Remove front case sub-assy</p> <p>a</p> | <p>Remove the screws fixing front case.</p> <p>Note: (1) Open the screw caps before removing the screws around the air outlet. (2) The quantity of screws fixing the front case sub-assy is different for different models.</p>  <p>b</p> <p>Loosen the clasps at the top of front case. Lift the front case sub-assy upwards to remove it.</p>  |

| Step | Procedure |
|----------------------------|--|
| 6.Remove electric box assy | |
| a | <p>Remove the screw fixing electric box assy.</p>  |
| b | <p>① Cut off the wire binder and pull out the indoor tube temperature sensor. ② Screw off one grounding screw. ③ Remove the wiring terminals of motor, cold plasma generator and stepping motor. ④ Remove the electric box assy. ⑤ Screw off the screws that are locking each.</p>  |
| c | <p>Rotate the electric box assy. Twist off the screws that are locking the wire clip and loosen the power cord. Remove the wiring terminal of power cord. Lift up the main board and take it off.</p>  <p>Instruction:Some wiring terminal of this products is with lock catch and other devices.The pulling method is as below: 1.Remove the soft sheath for some terminals at first, hold the circlip and then pull out the terminals, 2.Pull out the holder for some terminals at first(holder is not available for some wiring terminal).hold the connector and then pull the terminal.</p>  |

| Step | Procedure |
|----------------|--|
| 5.Remove panel | |
| a | <p>Remove 3 screws fixing evaporator assy.</p> |
| b | <p>At the back of the unit, Loosen the clasp of the connection pipe clamp and then remove the connection pipe clamp.</p> |
| c | <p>First remove the left side of evaporator from the groove of bottom shell and then remove the right side from the clasp on the bottom shell.</p> |
| d | <p>Adjust the position of connection pipe on evaporator slightly and then lift the evaporator upwards to remove it.</p> |






| Step | Procedure |
|---|---|
| 8. Remove motor and cross flow fan | |
| a | <p>Remove the screw fixing motor clamp and then remove the motor clamp.</p>  |
| b | <p>Loose the screws (2-3 circles) used for fixing the cross flow fan, pull right to pull out the motor.</p>  |
| 9. Remove swing motor | |
| | <p>Screw off the screws that are locking the swing motor and take the motor off.</p>  |




11.2 Removal Procedure of Outdoor Unit




GWH09AUCXB-K6DNA1A/O






Caution: discharge the refrigerant completely before removal.




| Step | Procedure |
|---|---|
| 1. Before disassembly |  |
| 2. Remove big handle and valve cover | <p>Remove the screws fixing big handle, valve cover and then remove them.</p>  |
| 3. Remove top cover | <p>Remove the screws fixing top panel and then remove the top panel.</p>  |




| Step | Procedure |
|---|---|
| <p>4. Remove front panel assy</p> | <p>Remove connection screws connecting the front panel assy with the chassis and the motor support, and then remove the front panel assy.</p>  |
| <p>5. Remove right side plate assy</p> | <p>Rescrew the ground screws, remove the ground wires, loosen the screws fixing terminal board, remove the terminal board, rescrew the screws fixing the right plate, and remove the right side plate assy.</p>  |
| <p>6. Remove axial flow fan</p> | <p>Remove the nut on the fan and then remove the axial flow fan.</p>  |




| Step | Procedure |
|---|---|
| <p>7. Remove motor support and motor</p> | <p>Remove the screws fixing the motor support and lift the motor support to remove it. Remove the screws fixing the motor and then remove the motor.</p>  |
| <p>8. Remove electric box assy</p> | <p>Remove the terminals, lift up and rotate the electrical box assy to the right so that the snaps on the clapboard are removed and the electrical box assy are removed.</p>  |
| <p>9. Remove clapboard assy</p> | <p>Remove the screws fixing the clapboard assy and then remove the clapboard assy.</p>  |




| Step | Procedure |
|--|--|
| <p>10. Remove gas valve and liquid valve</p> <p>Remove the valve support block, remove the screws fixing the gas valve and the liquid valve, unsolder the welding joint connecting the gas valve and the liquid valve, remove them.</p> <p>Note: Discharge the refrigerant completely before unsoldering; when unsoldering, wrap the gas valve with a wet cloth completely to avoid damage to the valve caused by high temperature.</p> |  |
| <p>11. Remove 4-way valve and capillary</p> <p>Unsolder the welding joints connecting capillary, and then remove it.</p> <p>Unsolder the welding joints connecting the 4-way valve assembly with capillary sub-assembly, compressor and condenser; remove the 4-way valve. Cooling only unit removes Discharge Tube and Inhalation Tube.</p> <p>Note: Before unsoldering the welding joint, wrap the 4-way valve with a wet cloth completely to avoid damage to the valve caused by high temperature.</p> |  |
| <p>12. Remove compressor</p> <p>Remove the 3 foot nuts on the compressor and then remove the compressor.</p> |  |




 **Caution: discharge the refrigerant completely before removal.**

| Step | Procedure |
|--|--|
| <p>1. Before disassembly</p> |  |
| <p>2. Remove top cover</p> | <p>Remove the screws fixing top panel and then remove the top panel.</p>  |
| <p>3. Remove big handle and valve cover</p> | <p>Remove the screws fixing big handle, valve cover and then remove them.</p>  |

| Step | Procedure |
|---|---|
| <p>4. Remove front panel assy</p> | <p>Remove connection screws connecting the front panel assy with the chassis and the motor support, and then remove the front panel assy.</p>  |
| <p>5. Remove right side plate assy</p> | <p>Rescrew the ground screws, remove the ground wires, loosen the screws fixing terminal board, remove the terminal board, rescrew the screws fixing the right plate, and remove the right side plate assy.</p>  |
| <p>6. Remove valve support</p> | <p>Remove the valve support block, remove the screws fixing valve support, remove the screws fixing the liquid valve and gas valve then remove the valve support.</p>  |




| Step | Procedure |
|--|--|
| <p>7. Remove gas valve and liquid valve</p> <p>Unsolder the welding joint connecting the gas valve and the liquid valve, remove them.</p> <p>Note: Discharge the refrigerant completely before unsoldering; when unsoldering, wrap the gas valve with a wet cloth completely to avoid damage to the valve caused by high temperature.</p> |  <p>liquid valve</p> <p>welding joint</p> <p>gas valve</p> |
| <p>8. Remove electronic expansion valve</p> <p>Remove the terminals of the electronic expansion valve coil and rotate to remove the electronic expansion valve coil.</p> <p>Unsolder the welding joint connecting the electronic expansion Valve and then remove the electronic expansion valve.</p> |  <p>electric expand valve fitting</p> <p>electric expansion valve sub-Assy</p> <p>welding joint</p> |
| <p>9. Remove electric box assy</p> <p>Unplug the terminals, unscrew 1 screw that secures the electrical box assy, release the two snaps on the electrical box assy (in the clapboard and condenser angle), pull outwards, and remove the electrical box assy.</p> |  <p>Electric Box Assy</p> |




| Step | Procedure |
|---|---|
| <p>10. Remove axial flow fan</p> | <p>Remove the nut on the fan and then remove the axial flow fan.</p>  |
| <p>11. Remove motor</p> | <p>Remove the screws fixing the motor and then remove the motor.</p>  |
| <p>12. Remove motor support</p> | <p>Remove the screws fixing the motor support and lift the motor support to remove it.</p>  |




| Step | Procedure |
|---|---|
| <p>13. Remove 4-way valve assy</p> | <p>Unsolder the welding joints connecting the 4-way valve assy, remove the 4-way valve.</p> <p>Note: Before unsoldering the welding joint, wrap the 4-way valve with a wet cloth completely to avoid damage to the valve caused by high temperature.</p>  |
| <p>14. Remove clapboard assy</p> | <p>Remove the screws fixing the clapboard assy and then remove the clapboard assy.</p>  |
| <p>15. Remove compressor</p> | <p>Remove the 3 foot nuts on the compressor and then remove the compressor.</p>  |









Caution: discharge the refrigerant completely before removal.

| Step | Procedure |
|---|---|
| 1. Before disassembly |  |
| 2. Remove big handle and valve cover | <p data-bbox="191 1146 787 1212">Remove the screws fixing big handle, valve cover and then remove them.</p>  |
| 3. Remove top cover | <p data-bbox="191 1729 787 1795">Remove the screws fixing top panel and then remove the top panel.</p>  |




| Step | Procedure |
|---|---|
| <p>4. Remove front panel assy</p> <p>Remove connection screws connecting the front panel assy with the chassis and the motor support, and then remove the front panel assy.</p> |  <p>front panel</p> |
| <p>5. Remove right side plate assy</p> <p>Rescrew the ground screws, remove the ground wires, loosen the screws fixing terminal board, remove the terminal board, rescrew the screws fixing the right plate, and remove the right side plate assy.</p> |  <p>right side plate</p> |
| <p>6. Remove axial flow fan</p> <p>Remove the nut on the fan and then remove the axial flow fan.</p> |  <p>axial flow fan</p> |




| Step | Procedure |
|---|---|
| <p>7. Remove electric box assy</p> | <p>Remove the terminals, lift up and rotate the electrical box assy to the right so that the snaps on the clapboard are removed and the electrical box assy are removed.</p>  |
| <p>8. Remove motor</p> | <p>Remove the screws fixing the motor and then remove the motor.</p>  |
| <p>9. Remove motor support</p> | <p>Remove the screws fixing the motor support and lift the motor support to remove it.</p>  |




| Step | Procedure |
|--|---|
| <p>10. Remove gas valve and liquid valve</p> <p>Remove the valve support block, remove the screws fixing the gas valve and the liquid valve, unsolder the welding joint connecting the gas valve and the liquid valve, remove them.</p> <p>Note: Discharge the refrigerant completely before unsoldering; when unsoldering, wrap the gas valve with a wet cloth completely to avoid damage to the valve caused by high temperature.</p> |  <p>The diagram shows a side view of a compressor unit with its copper piping and valves. Labels with leader lines point to a 'welding joint' on the top of the valve assembly, the 'liquid valve' below it, and the 'gas valve' at the bottom. The unit is mounted on a grey base.</p> |
| <p>11. Remove valve support</p> <p>Remove the screws fixing valve support, then remove the valve support.</p> |  <p>The diagram shows the same compressor unit as in step 10. A label with a leader line points to the 'valve support' block, which is a grey metal component mounted on the base of the unit.</p> |
| <p>12. Remove 4-way valve assy</p> <p>Unsolder the welding joints connecting the 4-way valve assy, remove the 4-way valve.</p> <p>Note: Before unsoldering the welding joint, wrap the 4-way valve with a wet cloth completely to avoid damage to the valve caused by high temperature.</p> |  <p>The diagram shows the compressor unit from a different angle, focusing on the 4-way valve assembly. A label with a leader line points to the '4-way valve assy', which is a black cylindrical component with four ports, connected to the copper piping.</p> |




| Step | Procedure |
|---|---|
| <p>13. Remove electronic expansion valve</p> | <p>Remove the terminals of the electric expand valve fitting and rotate to remove the electric expand valve fitting.</p> <p>Unsolder the welding joint connecting the electronic expansion Valve and then remove the electronic expansion valve.</p>  |
| <p>14. Remove clapboard assy</p> | <p>Remove the screws fixing the clapboard assy and then remove the clapboard assy.</p>  |
| <p>15. Remove compressor</p> | <p>Remove the 3 foot nuts on the compressor and then remove the compressor.</p>  |









| Step | Procedure |
|------------------------------|---|
| 1. Before disassembly |  |
| 2. Remove valve cover | <p>Remove the connection screw and then remove the valve cover.</p>  |
| 3. Remove big handle | <p>Remove the connection screw and then remove the big handle.</p>  |

| Step | Procedure |
|-------------------------------------|---|
| <p>4. Remove top cover</p> | <p>Remove connection screws connecting the top panel with the front panel and the right side plate, and then remove the top panel.</p>  |
| <p>5. Remove grille</p> | <p>Remove connection screws between the front grille and the front panel. Then remove the grille.</p>  |
| <p>6. Remove front panel</p> | <p>Remove connection screws connecting the front panel with the chassis and the motor support and then remove the front panel.</p>  |

| Step | Procedure |
|--|---|
| <p>7. Remove right side plate</p> | <p>Remove connection screws connecting the right side plate with the valve support and the electric box. Then remove the right side plate.</p>  |
| <p>8. Remove the nut and gasket on the blade and then remove the axial flow blade</p> | <p>Remove the nut and gasket on the blade and then remove the axial flow blade.</p>  |
| <p>9. Remove motor and motor support</p> | <p>Remove the tapping screws fixing the motor and disconnect the leading wire insert of the motor. Then remove the motor.</p> <p>Remove the tapping screws fixing the motor support and lift the motor support to remove it.</p>  |




| Step | Procedure |
|--|---|
| <p>10. Remove Electric Box Assy</p> | <p>Remove screws fixing the electric box subassembly; loosen the wire bundle and unplug the wiring terminals. Then lift the electric box to remove it.</p>  <p>Electric Box Assy</p> |
| <p>11. Remove isolation sheet</p> | <p>Remove the screws fixing the isolation sheet and then remove the isolation sheet.</p>  <p>isolation sheet</p> |
| <p>12. Remove cut-off valve</p> | <p>Unsolder the welding joints connecting the liquid valve and gas valve, and then remove them. Note: Before unsoldering the welding joint, wrap the cut-off valve with a wet cloth completely to avoid damage to the valve caused by high temperature.</p>  <p>liquid valve gas valve</p> |




| Step | Procedure |
|---|--|
| <p>13. Remove valve support</p> | <p>Remove the screws fixing valve support, then remove the valve support.</p>  |
| <p>14. Remove 4-way valve assy</p> | <p>Unsolder the welding joints connecting the 4-way valve assy, remove the 4-way valve.</p> <p>Note: Before unsoldering the welding joint, wrap the 4-way valve with a wet cloth completely to avoid damage to the valve caused by high temperature.</p>  |
| <p>15. Remove electronic expansion valve</p> | <p>Remove the terminals of the electric expand valve fitting and rotate to remove the electric expand valve fitting.</p> <p>Unsolder the welding joint connecting the electronic expansion Valve and then remove the electronic expansion valve.</p>  |




| Step | Procedure |
|---|--|
| <p>16. Remove left side plate</p> | <p>Remove the screws fixing the left side plate and then remove the left side plate.</p>  <p>left side plate</p> |
| <p>17. Remove condenser sub-assy</p> | <p>Remove the screws fixing the Remove condenser sub-assy and then remove the Remove condenser sub-assy.</p>  <p>condenser sub-assy</p> |
| <p>18. Remove compressor</p> | <p>Remove the 3 foot nuts on the compressor and then remove the compressor.</p>  <p>compressor</p> |









Caution: discharge the refrigerant completely before removal.

| Step | Procedure |
|--|--|
| <p>1. Before disassembly</p> |  |
| <p>2. Remove top cover</p> | <p>Remove the screws fixing top panel and then remove the top panel.</p>  |
| <p>3. Remove big handle and valve cover</p> | <p>Remove the screws fixing big handle, valve cover and then remove them.</p>  |

| Step | Procedure |
|--|---|
| <p>4. Remove front panel assy</p> | <p>Remove connection screws connecting the front panel assy with the chassis and the motor support, and then remove the front panel assy.</p>  |
| <p>5. Remove right side plate assy</p> | <p>Rescrew the ground screws, remove the ground wires, loosen the screws fixing terminal board, remove the terminal board, rescrew the screws fixing the right plate, and remove the right side plate assy.</p>  |
| <p>6. Remove gas valve and liquid valve</p> | <p>Remove the valve support block, remove the screws fixing the gas valve and the liquid valve, unsolder the welding joint connecting the gas valve and the liquid valve, remove them.</p> <p>Note: Discharge the refrigerant completely before unsoldering; when unsoldering, wrap the gas valve with a wet cloth completely to avoid damage to the valve caused by high temperature.</p>  |

| Step | Procedure |
|--|--|
| <p>7. Remove valve support</p> | <p>Remove the screws fixing valve support, then remove the valve support.</p>  |
| <p>8. Remove electronic expansion valve</p> | <p>Remove the terminals of the electronic expansion valve coil and rotate to remove the electronic expansion valve coil. Unsolder the welding joint connecting the electronic expansion Valve and then remove the electronic expansion valve.</p>  |
| <p>9. Remove electric box assy</p> | <p>Remove the terminals, lift up and rotate the electrical box assy to the right so that the snaps on the clapboard are removed and the electrical box assy are removed.</p>  |

| Step | Procedure |
|---|---|
| <p>10. Remove 4-way valve assy</p> | <p>Unsolder the welding joints connecting the 4-way valve assy, remove the 4-way valve.</p> <p>Note: Before unsoldering the welding joint, wrap the 4-way valve with a wet cloth completely to avoid damage to the valve caused by high temperature.</p>  |
| <p>11. Remove axial flow fan</p> | <p>Remove the nut on the fan and then remove the axial flow fan.</p>  |
| <p>12. Remove motor</p> | <p>Remove the screws fixing the motor and then remove the motor.</p>  |

| Step | Procedure |
|---|---|
| <p>12. Remove motor support</p> | <p>Remove the screws fixing the motor support and lift the motor support to remove it.</p>  |
| <p>14. Remove clapboard assy</p> | <p>Remove the screws fixing the clapboard assy and then remove the clapboard assy.</p>  |
| <p>15. Remove compressor</p> | <p>Remove the 3 foot nuts on the compressor and then remove the compressor.</p>  |

Appendix

Appendix 1: Reference Sheet of Celsius and Fahrenheit

Conversion formula for Fahrenheit degree and Celsius degree: $T_f = T_c \times 1.8 + 32$

Set temperature

| Fahrenheit display temperature (°F) | Fahrenheit (°F) | Celsius (°C) | Fahrenheit display temperature (°F) | Fahrenheit (°F) | Celsius (°C) | Fahrenheit display temperature (°F) | Fahrenheit (°F) | Celsius (°C) |
|-------------------------------------|-----------------|--------------|-------------------------------------|-----------------|--------------|-------------------------------------|-----------------|--------------|
| 61 | 60.8 | 16 | 69/70 | 69.8 | 21 | 78/79 | 78.8 | 26 |
| 62/63 | 62.6 | 17 | 71/72 | 71.6 | 22 | 80/81 | 80.6 | 27 |
| 64/65 | 64.4 | 18 | 73/74 | 73.4 | 23 | 82/83 | 82.4 | 28 |
| 66/67 | 66.2 | 19 | 75/76 | 75.2 | 24 | 84/85 | 84.2 | 29 |
| 68 | 68 | 20 | 77 | 77 | 25 | 86 | 86 | 30 |

Ambient temperature

| Fahrenheit display temperature (°F) | Fahrenheit (°F) | Celsius (°C) | Fahrenheit display temperature (°F) | Fahrenheit (°F) | Celsius (°C) | Fahrenheit display temperature (°F) | Fahrenheit (°F) | Celsius (°C) |
|-------------------------------------|-----------------|--------------|-------------------------------------|-----------------|--------------|-------------------------------------|-----------------|--------------|
| 32/33 | 32 | 0 | 55/56 | 55.4 | 13 | 79/80 | 78.8 | 26 |
| 34/35 | 33.8 | 1 | 57/58 | 57.2 | 14 | 81 | 80.6 | 27 |
| 36 | 35.6 | 2 | 59/60 | 59 | 15 | 82/83 | 82.4 | 28 |
| 37/38 | 37.4 | 3 | 61/62 | 60.8 | 16 | 84/85 | 84.2 | 29 |
| 39/40 | 39.2 | 4 | 63 | 62.6 | 17 | 86/87 | 86 | 30 |
| 41/42 | 41 | 5 | 64/65 | 64.4 | 18 | 88/89 | 87.8 | 31 |
| 43/44 | 42.8 | 6 | 66/67 | 66.2 | 19 | 90 | 89.6 | 32 |
| 45 | 44.6 | 7 | 68/69 | 68 | 20 | 91/92 | 91.4 | 33 |
| 46/47 | 46.4 | 8 | 70/71 | 69.8 | 21 | 93/94 | 93.2 | 34 |
| 48/49 | 48.2 | 9 | 72 | 71.6 | 22 | 95/96 | 95 | 35 |
| 50/51 | 50 | 10 | 73/74 | 73.4 | 23 | 97/98 | 96.8 | 36 |
| 52/53 | 51.8 | 11 | 75/76 | 75.2 | 24 | 99 | 98.6 | 37 |
| 54 | 53.6 | 12 | 77/78 | 77 | 25 | | | |

Appendix 2: Configuration of Connection Pipe

- Standard length of connection pipe (More details please refer to the specifications.)
- Min length of connection pipe for the unit with standard connection pipe of 5m, there is no limitation for the min length of connection pipe. For the unit with standard connection pipe of 7.5m and 8m, the min length of connection pipe is 3m.
- Max. length of connection pipe and max. high difference. (More details please refer to the specifications.)
- The additional refrigerant oil and refrigerant charging required after prolonging connection pipe
 - After the length of connection pipe is prolonged for 10m at the basis of standard length, you should add 5ml of refrigerant oil for each additional 5m of connection pipe.
 - The calculation method of additional refrigerant charging amount (on the basis of liquid pipe):
 - Basing on the length of standard pipe, add refrigerant according to the requirement as shown in the table. The additional refrigerant charging amount per meter is different according to the diameter of liquid pipe. See the following sheet.
 - Additional refrigerant charging amount = prolonged length of liquid pipe X additional refrigerant charging amount per meter

Additional refrigerant charging amount for R32

| Piping size | | Indoor unit throttle | Outdoor unit throttle | |
|--------------|--------------|---|-----------------------|--------------------------|
| Liquid pipe | Gas pipe | Cooling only, cooling and heating (g / m) | Cooling only(g/m) | Cooling and heating(g/m) |
| 1/4" | 3/8" or 1/2" | 14 | 12 | 16 |
| 1/4" or 3/8" | 5/8" or 3/4" | 40 | 12 | 40 |
| 1/2" | 3/4" or 7/8" | 80 | 24 | 96 |
| 5/8" | 1" or 1 1/4" | 136 | 48 | 96 |
| 3/4" | / | 200 | 200 | 200 |
| 7/8" | / | 280 | 280 | 280 |


Appendix 3: Pipe Expanding Method

⚠ Note:

Improper pipe expanding is the main cause of refrigerant leakage. Please expand the pipe according to the following steps:


A: Cut the pipe

- Confirm the pipe length according to the distance of indoor unit and outdoor unit.
- Cut the required pipe with pipe cutter.



B: Remove the burrs


- Remove the burrs with shaper and prevent the burrs from getting into the pipe.



C: Put on suitable insulating pipe.

D: Put on the union nut

- Remove the union nut on the indoor connection pipe and outdoor valve; install the union nut on the pipe.




E: Expand the port

- Expand the port with expander.

⚠ Note:


- "A" is different according to the diameter, please refer to the sheet below:

| Outer diameter(mm) | A(mm) | |
|--------------------|-------|-----|
| | Max | Min |
| Φ6 - 6.35 (1/4") | 1.3 | 0.7 |
| Φ9 - Φ9.52 (3/8") | 1.6 | 1.0 |
| Φ12 - 12.70 (1/2") | 1.8 | 1.0 |
| Φ16 - 15.88 (5/8") | 2.4 | 2.2 |



F: Inspection

- Check the quality of expanding port. If there is any blemish, expand the port again according to the steps above.



Appendix 4: List of Resistance for Temperature Sensor

Resistance Table of Ambient Temperature Sensor for Indoor and Outdoor Units(15K)

| Temp(°C) | Resistance(kΩ) |
|----------|----------------|
| -19 | 138.10 |
| -18 | 128.60 |
| -16 | 115.00 |
| -14 | 102.90 |
| -12 | 92.22 |
| -10 | 82.75 |
| -8 | 74.35 |
| -6 | 66.88 |
| -4 | 60.23 |
| -2 | 54.31 |

| Temp(°C) | Resistance(kΩ) |
|----------|----------------|
| 0 | 49.02 |
| 2 | 44.31 |
| 4 | 40.09 |
| 6 | 36.32 |
| 8 | 32.94 |
| 10 | 29.90 |
| 12 | 27.18 |
| 14 | 24.73 |
| 16 | 22.53 |
| 18 | 20.54 |

| Temp(°C) | Resistance(kΩ) |
|----------|----------------|
| 20 | 18.75 |
| 22 | 17.14 |
| 24 | 15.68 |
| 26 | 14.36 |
| 28 | 13.16 |
| 30 | 12.07 |
| 32 | 11.09 |
| 34 | 10.20 |
| 36 | 9.38 |
| 38 | 8.64 |

| Temp(°C) | Resistance(kΩ) |
|----------|----------------|
| 40 | 7.97 |
| 42 | 7.35 |
| 44 | 6.79 |
| 46 | 6.28 |
| 48 | 5.81 |
| 50 | 5.38 |
| 52 | 4.99 |
| 54 | 4.63 |
| 56 | 4.29 |
| 58 | 3.99 |

Resistance Table of Tube Temperature Sensors for Indoor and Outdoor (20K)

| Temp(°C) | Resistance(kΩ) |
|----------|----------------|
| -19 | 181.40 |
| -15 | 145.00 |
| -10 | 110.30 |
| -5 | 84.61 |
| 0 | 65.37 |
| 5 | 50.87 |
| 10 | 39.87 |
| 15 | 31.47 |

| Temp(°C) | Resistance(kΩ) |
|----------|----------------|
| 20 | 25.01 |
| 25 | 20.00 |
| 30 | 16.10 |
| 35 | 13.04 |
| 40 | 10.62 |
| 45 | 8.71 |
| 50 | 7.17 |
| 55 | 5.94 |

| Temp(°C) | Resistance(kΩ) |
|----------|----------------|
| 60 | 4.95 |
| 65 | 4.14 |
| 70 | 3.48 |
| 75 | 2.94 |
| 80 | 2.50 |
| 85 | 2.13 |
| 90 | 1.82 |
| 95 | 1.56 |

| Temp(°C) | Resistance(kΩ) |
|----------|----------------|
| 100 | 1.35 |
| 105 | 1.16 |
| 110 | 1.01 |
| 115 | 0.88 |
| 120 | 0.77 |
| 125 | 0.67 |
| 130 | 0.59 |
| 135 | 0.52 |

Resistance Table of Discharge Temperature Sensor for Outdoor(50K)

| Temp(°C) | Resistance(kΩ) |
|----------|----------------|
| -30 | 911.400 |
| -25 | 660.8 |
| -20 | 486.5 |
| -15 | 362.9 |
| -10 | 274 |
| -5 | 209 |
| 0 | 161 |
| 5 | 125.1 |

| Temp(°C) | Resistance(kΩ) |
|----------|----------------|
| 10 | 98 |
| 15 | 77.35 |
| 20 | 61.48 |
| 25 | 49.19 |
| 30 | 39.61 |
| 35 | 32.09 |
| 40 | 26.15 |
| 45 | 21.43 |

| Temp(°C) | Resistance(kΩ) |
|----------|----------------|
| 50 | 17.65 |
| 55 | 14.62 |
| 60 | 12.17 |
| 65 | 10.18 |
| 70 | 8.555 |
| 75 | 7.224 |
| 80 | 6.129 |
| 85 | 5.222 |

| Temp(°C) | Resistance(kΩ) |
|----------|----------------|
| 90 | 4.469 |
| 95 | 3.841 |
| 100 | 3.315 |
| 105 | 2.872 |
| 110 | 2.498 |
| 115 | 2.182 |
| 120 | 1.912 |
| 125 | 1.682 |

JF00305011



GREE ELECTRIC APPLIANCES, INC. OF ZHUHAI

Add: West Jinji Rd, Qianshan, Zhuhai, Guangdong, China, 519070

Tel: (+86-756) 8522219

Fax: (+86-756) 8669426

E-mail: global@cn.gree.com

For product improvement, specifications and appearance in this manual are subject to change without prior notice.