



(KF-70PW/NA1A KF-80PW/NA1A)




NOTE: ① Power cable: 3X2.5mm<sup>2</sup>  
② Connection cord: 3X2.5mm<sup>2</sup>  
③ Connection cord: 3X0.75mm<sup>2</sup>

(KFR-70PW/NA1A KFR-80PW/NA1A)




NOTE: ① Power cable: 3X2.5mm<sup>2</sup>  
② Connection cord: 3X2.5mm<sup>2</sup>  
③ Connection cord: 4X0.75mm<sup>2</sup>  
④ Signal cord: 2X0.75mm<sup>2</sup>

(KF-100PW/NA1A KF-120PW/NA1A)



NOTE: ① Power cable: 5X1.5mm<sup>2</sup>  
② Connection cord: 3X1.0mm<sup>2</sup>  
③ Connection cord: 3X0.75mm<sup>2</sup>  
④ Signal cord: 3X0.75mm<sup>2</sup>

(KFR-100PW/NA1A KFR-120PW/NA1A)



NOTE: ① Power cable: 5X1.5mm<sup>2</sup>  
② Connection cord: 3X1.0mm<sup>2</sup>  
③ Connection cord: 4X0.75mm<sup>2</sup>  
④ Signal cord: 6X0.75mm<sup>2</sup>