1.3 Installation

There are two Maintenance Tool setup methods:

Method 1) New setup.(See Section 1.3.1)

Method 2) Upgrading with existing setup.(See Section 1.3.2)

1.3.1 Setting Up the Maintenance Tools (New setup)

Caution:

- Before setting up, be sure to login with the login name authorized as administrator.


Request:

Before Setting up the MSDE, restart your computer and Ending software for application program and Anti-Virus.

（1）Starting the setup program

Execute **"SETUP.exe"** located in a CD-ROM.（**Not click on any other files.**）

Double clicking on **"SETUP.exe"** with the explorer displays theapplication install screen as shown right. Click on [**install**] button and start installation.



NOTE：

・The number of applications installed by the OS is different, but just click on **[install]** button**.**


（Right Figure is Screen of Windows XP.）

Caution:

- **It takes 15 minutes from about 10 minutes to install the application.**

NOTE:

・When it install Maintenance Tool in Windows Vista,warning such as the right is given. Click on [Allow].



（2）Installing the Maintenance Tools

When the installation of the application software is finished, the installation screen of the Maintenance Tool is displayed. Confirm the display contents, and if no problem was found on the content, click [**Next**] button.


* To stop setting up, click on [**Cancel**] button.



（3）Ready to the installation start

Confirm the starting and select an [**Install**] button.
Click on [Install] button starts installation.

* Clicking on [**Cancel**] button stops installation.




Caution:

・When a screen such as the right figure was displayed without installation start preparations screen being displayed, Select [Remove], and please click a [Next] button.

・Click [Remove] with the next screen, click on [Finish], and be completed.

・Execute **"SETUP.exe"** located in a CD-ROM once again.




（4）Confirming the completion of Maintenance Tools setup

1) Select [**Finish**] button.
Click on [**Finish**] button on the Installation Complete screen.

After completing installation, restart your computer.

Keep the CD-ROM used with you carefully.



Caution:

After installing Maintenance Tools, <u>be sure to restart your computer</u>.

1.3.2 Running Maintenance Tool Upgrade

The following describes how to upgrade the Maintenance Tool.

Step 1) Ending the Maintenance Tool and the MSDE
Step 2) Uninstalling the Maintenance Tool :**Restart your computer after completing the STEP 2.**
Step 3) Uninstalling the MSDE :**Restart your computer after completing the STEP 3.**
Step 4) Upgrade the Maintenance Tool :**Restart your computer after completing the STEP 4.**

Caution:
- **For setting up, be sure to practice 4 steps in order.** Otherwise, Maintenance Tools will not operate normally.
- Before setting up, be sure to login with the login name authorized as administrator.

Step 1) Ending the Maintenance Tool and the MSDE
End the Maintenance Tool program.
***Refer to 1.4.6 Ending the Maintenance Tool**
***Refer to 1.4.7 Ending the MSDE**

Step 2) Uninstalling the Maintenance Tool
Uninstall the Maintenance Tool program.
*** Refer to 1.3.3 Uninstalling the Maintenance Tool**

Caution:
- **After uninstalling Maintenance Tool program, be sure to restart your computer.**

Step 3) Uninstalling the Maintenance Tool and the MSDE
Uninstall the Maintenance Tool program and the MSDE program.
*** Refer to 1.3.4 Uninstalling the MSDE**

Caution:
- **After uninstalling MSDE program, be sure to restart your computer.**


Step 4) Upgrade the Maintenance Tool
Execute **"Setup.EXE"** located in CD-ROM. Double clicking on **" Setup.EXE "**.
*The Maintenance Tool program version upgrading procedure is the same as new setup.
Refer to 1.3.1 Setting Up the Maintenance Tools

Caution:
- **After installing Maintenance Tool program, be sure to restart your computer.**

1.3.3 Uninstalling the Maintenance Tool

It explains the method of uninstalling the **Maintenance Tool** as follows.

(1) Confirm the ending of **Maintenance Tool**.
Confirm that Maintenance Tool program has been ended.
If not, end the program.
***For the ending method, refer to Chapter 1.4.6.**



(2) Start [Add/Remove Programs].
Click on [Add/Remove Programs] from [Control panel] to start.

(3) Select [Maintenance Tool for windows 2000 and XP] and press [Change & Remove] button.
Select [Maintenance Tool for windows 2000 and XP] from the application, and click on [Remove] button.
The deletion of Maintenance Tools application starts.

NOTE:
- Recommend not to delete the common components.
- There are folders and files that can not be deleted with this uninstalling.
  (Example:C:¥Program files¥Mnttool32)

(4) Ending the [Add/Remove Programs].
After ending the deletion of application, end [Add/Remove Programs].
Select [Maintenance Tool for windows 2000 and XP] from the application, and click on [Remove] button.
The deletion of Maintenance Tools application starts.

4) Ending the [Add/Remove Programs].
After ending the deletion of application, end [Add/Remove Programs].

Caution:
- **After uninstalling Maintenance Tool program, be sure to restart your computer.**


1.3.4 Uninstalling the MSDE

It explains the method of uninstalling the **MSDE** as follows.


(1) Confirm the ending of **MSDE**.
Confirm that **MSDE** program has been ended. If not, end the program.
***For the ending method, refer to Chapter 1.4.7.**

(2) Start [Add/Remove Programs].
Click on [Uninstall] from [**MSDE**] to [All Programs] to start.
※It can start [Add/Remove Programs] from [Control Panel] to start.


『Confilm File Deletion』 is displayed, and Click on [Yes]
It starts Uninstallation.



(3) During uninstallation, a screen such as the right figure is displayed. Click on [**No to All**].



(4) Confirming the completion of Uninstall.
・Select [**OK**] button.
Click on [**OK**] button on the Remove Programs screen.




NOTE:
- Recommend not to delete the common components.
- There are folders and files that can not be deleted with this uninstalling.
  (Example:C:¥Program files¥MSDE)

Caution:
- **After uninstalling MSDE program, be sure to restart your computer.**

1.4.6 Ending the Maintenance Tool

1.4.6.1 Ending the On-Line Monitor




(1) Open the **Main Screen**.

(2) Click on [**File**] on the menu bar.

(3) Click on [**Return**] in the sub-menu.

(4) The message "**Are you sure you want to finish maintenance tool?**" will appear.
Click on [OK].




The On-Line Monitor will end and the Windows screen will appear.

*At ending of Maintenance Tools, the telephone circuit will automatically be disconnected.

* Clicking [Mode Select] returns to the [selection screen of Monitor mode].


1.4.6.2 Ending the Off-Line Monitor



(1) Open the **Off-line Analyze Screen**.

(2) Click on [Exit].

(3) The message "**Are you sure you want to finish maintenance tool?**" will appear.
Click on [OK].



* When finishing Offline Screen immediately after deleting data, a message of "Finishing Maintenance Tool !!" may sometime be displayed. The internal data is now under arrangement. Offline Screen will automatically be finished after completing this process. Please wait a while.

* Clicking [Mode Select] returns to the [selection screen of Monitor mode].

1.4.7 Ending the MSDE


(1) Click on［**Service Manager**］from［**MSDE**］to［**All Programs**］to start, and start it.

(2) When it start『SQL Server Service Manager』, a screen such as the right is displayed.
Click on ■ **, and stop Server**.




When it click on ■, the confirmation screen is displayed.
Click on [Yes], and『SQL Server Service Manager』is stop.

(3) When it stop, a screen such as the right is displayed.



(4) Close Window of『**SQL Server Service Manager**』and **click the right**  **of the task bar right-side end, and Click on[Exit]**.



『SQL Server Service Manager』**is finished**.